

Fotopro SJ-86 Pro

Fotopro SJ-86 Pro Phone Tripod Mount User Manual

Model: SJ-86 Pro

1. INTRODUCTION

The Fotopro SJ-86 Pro Phone Tripod Mount is a versatile and durable accessory designed to securely hold your smartphone for various photography and videography needs. This mount is compatible with a wide range of smartphones and can be attached to tripods, selfie sticks, and other camera accessories. Its adjustable design allows for flexible positioning, enhancing your mobile content creation experience.

2. WHAT'S IN THE BOX

- Fotopro SJ-86 Pro Phone Tripod Mount (1 unit)

3. KEY FEATURES

- Durable Construction:** Crafted from high-quality plastic with a one-way sawtooth structure for secure grip and enhanced durability.
- Wide Compatibility:** Accommodates smartphones with widths ranging from 2.20 to 3.39 inches (56-86 mm).
- Universal 1/4-Inch Screw Port:** Easily connects to mini tripods, monopods, selfie sticks, and other camera equipment.
- Flexible Adjustment:** Features 180° horizontal rotation and 90° vertical tilt for optimal shooting angles.
- Anti-Slip Protection:** Equipped with non-slip silicone inner pads to secure your phone and prevent scratches.
- Standalone Functionality:** Can be used as a convenient desktop phone stand when folded.

4. SETUP INSTRUCTIONS

4.1 Attaching the Mount to a Tripod or Accessory

The Fotopro SJ-86 Pro features a standard 1/4-inch screw interface at its base. To attach it to a tripod, monopod, or selfie stick:

1. Locate the 1/4-inch screw on your desired accessory.
2. Align the screw port on the bottom of the SJ-86 Pro mount with the screw on the accessory.
3. Rotate the mount clockwise until it is securely fastened. Do not overtighten.



Image: Detailed view of the Fotopro SJ-86 Pro mount, highlighting the 1/4-inch screw attachment point and the anti-slip rubber interior for phone protection.

4.2 Inserting Your Smartphone

The mount is designed to securely hold smartphones within its specified width range (2.20 to 3.39 inches).

1. Gently pull the top jaw of the phone clamp upwards to expand the opening.
2. Carefully place your smartphone into the clamp, ensuring it is centered.
3. Release the top jaw slowly, allowing the anti-slip silicone pads to firmly grip your phone. Ensure the phone is stable and secure before use.



Image: A smartphone is shown securely mounted in a vertical orientation on a tripod, demonstrating the stable grip of the Fotopro SJ-86 Pro mount.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Phone Width

The mount's clamp is designed to accommodate phones with widths between 2.20 inches (56mm) and 3.39 inches (86mm). The spring-loaded mechanism automatically adjusts to the phone's width once inserted.

FITS ALL PHONES

Range from 2.20" to 3.38", fits any phone.



Image: The Fotopro SJ-86 Pro mount is displayed in its minimum (2.20 inches) and maximum (3.38 inches) expanded states, illustrating its adjustable phone compatibility.

5.2 Rotating and Tilting Your Phone

The SJ-86 Pro offers significant flexibility for capturing various angles:

- **180° Horizontal Rotation:** Loosen the adjustment knob located on the side of the mount. Rotate your phone to the desired horizontal angle, then tighten the knob to secure it.
- **90° Vertical Tilt:** The mount allows for a 90° vertical tilt, enabling you to switch between horizontal and vertical shooting modes without needing a separate gimbal. Simply adjust the angle as needed.



360°
Adjustable



Horizontal



Vertical

Image: This image illustrates the 360° adjustable capabilities of the Fotopro SJ-86 Pro mount, showing how a phone can be positioned horizontally or vertically for diverse shooting needs.

ADAPTIVE DAMPING

90 degrees can be
rotated vertically, no gimbal required



Image: The mount is shown tilting a smartphone vertically by 90 degrees, highlighting its adaptive damping feature for easy angle adjustments without a gimbal.

5.3 Using as a Standalone Phone Holder

When not attached to a tripod, the SJ-86 Pro can be folded and used as a convenient desktop stand for hands-free viewing or video calls.



Image: A person is shown playing a guitar while their smartphone is securely held by the Fotopro SJ-86 Pro mount on a mini tripod, demonstrating a practical use case.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Fotopro SJ-86 Pro Phone Tripod Mount:

- **Cleaning:** Wipe the mount with a soft, dry cloth to remove dust and debris. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the mount in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check the screw threads and clamping mechanism for any signs of wear or damage.

7. TROUBLESHOOTING

- **Phone not holding securely:** Ensure your phone's width is within the 2.20-3.39 inch range. Check that the anti-slip

silicone pads are clean and free from obstruction.

- **Difficulty adjusting angle:** Loosen the adjustment knob slightly before attempting to rotate or tilt. If the mechanism feels stiff, ensure no debris is lodged in the joints.
- **Mount feels loose on tripod:** Ensure the 1/4-inch screw is fully tightened. If the issue persists, check the tripod's screw for damage.

8. SPECIFICATIONS

Feature	Detail
Brand	Fotopro
Model Number	SJ-86 Pro (FTV732781138657)
Compatible Devices	Cellphones
Compatible Phone Width	2.20–3.39 inches (56–86 mm)
Mounting Type	Tripod (1/4-inch screw)
Special Features	Non-Slip, Rotatable Adjustable, Slip Resistant
Horizontal Rotation	180°
Vertical Tilt	90°

9. WARRANTY INFORMATION

This Fotopro SJ-86 Pro Phone Tripod Mount is covered by a Manufacturer Limited Warranty. Please refer to the warranty card included with your product or contact Fotopro customer support for specific details regarding coverage and terms.

10. SUPPORT

For further assistance, technical support, or inquiries regarding your Fotopro SJ-86 Pro Phone Tripod Mount, please visit the official Fotopro website or contact their customer service department. You can also visit the [Fotopro Store on Amazon](#) for more product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F8MSHLKT>

More documents and user manuals: <https://manuals.plus/>