

[Manuals.plus](#) /

› [FOPETT](#) /

› FOPETT V2050 Wireless Keyboard and Mouse Combo User Manual

FOPETT V2050

FOPETT V2050 Wireless Keyboard and Mouse Combo User Manual

Model: V2050 | Brand: FOPETT

INTRODUCTION

Thank you for choosing the FOPETT V2050 Wireless Keyboard and Mouse Combo. This manual provides essential information for setting up, operating, and maintaining your new device. Please read it carefully before use to ensure optimal performance and longevity.

PACKAGE CONTENTS

- Wireless Keyboard (V2050) x 1
- Wireless Mouse x 1
- USB Receiver x 1
- User Manual x 1



Image: The FOPETT V2050 wireless keyboard and mouse combo, showing the included components: keyboard, mouse, USB receiver, and user manual.

SETUP INSTRUCTIONS

1. Installing Batteries

The keyboard requires 2 AAA batteries and the mouse requires 1 AA battery (not included). Ensure correct polarity when inserting batteries.

1. Open the battery compartment on the underside of the mouse.
2. Insert 1 AA battery, observing the polarity markings.
3. Close the battery compartment.
4. Open the battery compartment on the underside of the keyboard.
5. Insert 2 AAA batteries, observing the polarity markings.
6. Close the battery compartment.



Image: A visual guide demonstrating the insertion of batteries into both the wireless keyboard and mouse.

2. Connecting the USB Receiver

The keyboard and mouse share a single 2.4GHz USB receiver. This allows for a simple plug-and-play setup.

1. Locate the USB receiver, typically stored within the mouse's battery compartment.
2. Plug the USB receiver into an available USB-A port on your computer or device.
3. Wait for your operating system to automatically detect and install the necessary drivers. This usually takes a few seconds.

Note:

If your device only has USB-C ports (e.g., modern MacBooks), a USB-A to USB-C adapter (sold separately) will be required.
The wireless connection has a range of up to 10 meters (33 feet).



Image: A diagram illustrating the process of plugging the single USB receiver into a computer to connect both the keyboard and mouse.

OPERATING INSTRUCTIONS

Keyboard Features

- **Full-Sized Layout:** 104 round keys for a complete typing experience.
- **Indicator Lights:** Located in the upper right corner for Num Lock, Caps Lock, and low battery/2.4G connection status.
- **Adjustable Tilt:** Foldable stands on the underside allow for a 15-degree typing angle for ergonomic comfort.

INDICATOR IN UPPER RIGHT CORNER

1 Num lock indicator

A Low battery/ 2.4G connection indicator

 Uppercase and lowercase switch indicator

17 INCH / 45 CM

5.5 INCH / 13.9 CM



FN + ESC : Music Player

FN + F1 : Player/ Pause

FN + F2 : Previous One

FN + F3 : Next One

FN + F4 : Volume+

FN + F5 : Volume-

FN + F6 : Mute

FN + F7 : Web

FN + F8 : Search

FN + F9 : Favorites

FN + F10 : Email

FN + F11 : Lock

FN + F12 : Windows

Image: An overhead view of the FOPETT V2050 keyboard, highlighting the indicator lights for Num Lock, Caps Lock, and connection status, along with its dimensions.



Image: A side view of the FOPETT V2050 keyboard, showing the foldable stands extended to provide an ergonomic 15-degree tilt.

Multimedia Hotkeys (Fn + F1-F12)

The keyboard includes 12 hotkeys for quick access to various functions. Press the **Fn** key simultaneously with the corresponding **F-key**.

Hotkey Combination	Function
Fn + Esc	Music Player
Fn + F1	Play/Pause
Fn + F2	Previous Track
Fn + F3	Next Track
Fn + F4	Volume Down
Fn + F5	Volume Up
Fn + F6	Mute
Fn + F7	Web Browser
Fn + F8	Search
Fn + F9	Favorites
Fn + F10	Email
Fn + F11	Lock Screen

Hotkey Combination	Function
Fn + F12	My Computer/Windows

Note:

The hotkeys may not be fully compatible with Mac systems.



**Ergonomic Design
Excellent Click Feedback**

Image: A visual representation of the FOPETT V2050 keyboard, detailing the functions of the Fn key combinations (F1-F12) for multimedia and system controls.

Mouse Features

- **Adjustable DPI:** Cycle through 800, 1000, and 1600 DPI settings for varied cursor sensitivity.
- **Silent Click:** Designed for quiet operation, minimizing noise during use.




Image: A close-up view of the FOPETT V2050 wireless mouse, indicating its adjustable DPI settings (800/1000/1600) and physical dimensions.

MAINTENANCE

Cleaning

- Use a soft, dry cloth to clean the surfaces of the keyboard and mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- Do not use harsh chemicals or abrasive cleaners.

Battery Replacement

Replace batteries when the low battery indicator on the keyboard illuminates or when the mouse responsiveness decreases. Refer to the "Installing Batteries" section for instructions.

TROUBLESHOOTING

- **No Connection/Unresponsive:**
 - Ensure the USB receiver is securely plugged into a working USB-A port.
 - Check if the batteries in both the keyboard and mouse are correctly installed and have sufficient charge. Replace if necessary.
 - Move the keyboard and mouse closer to the USB receiver to rule out range issues.
 - Try plugging the USB receiver into a different USB port on your device.
 - Restart your computer.
- **Lagging/Intermittent Connection:**
 - Ensure there are no large metal objects or other wireless devices (e.g., Wi-Fi routers, other 2.4GHz devices) causing interference between the keyboard/mouse and the receiver.
 - Replace batteries.
- **Hotkeys Not Working on Mac:**
 - Some multimedia hotkeys may have limited or no functionality on Mac operating systems due to system differences. This is normal behavior.

SPECIFICATIONS

Feature	Detail
Model Number	V2050
Connectivity	2.4GHz Wireless (USB Receiver)
Keyboard Layout	104 Round Keys, Full-Sized
Mouse DPI Settings	800/1000/1600 DPI
Keyboard Battery	2 x AAA (not included)
Mouse Battery	1 x AA (not included)
Auto-Sleep (Keyboard)	After 5 minutes of inactivity
Auto-Sleep (Mouse)	After 3 seconds of inactivity
Wireless Range	Up to 10 meters (33 feet)
Product Dimensions (Keyboard)	13.5 x 4.2 x 1.2 inches
Item Weight (Keyboard)	1.5 pounds
Compatibility	Windows, Mac OS, Android, Chromebook, Smart TV, Laptops

WARRANTY AND SUPPORT

FOPETT offers a three-year worry-free warranty and a 60-day money-back guarantee or replacement option. For any inquiries or concerns regarding your wireless keyboard and mouse combo, please contact the FOPETT customer support team. They provide 24-hour online service.

Your satisfaction is our top priority.

FOPETT V2050 Wireless Keyboard and Mouse Setup

Your browser does not support the video tag.

Video: This video demonstrates the setup process for the FOPETT V2050 wireless keyboard and mouse, including battery installation and USB receiver connection.

FOPETT V2050 Wireless Keyboard and Mouse in Use

Your browser does not support the video tag.

Video: This video showcases the FOPETT V2050 wireless keyboard and mouse in active use, demonstrating typing and mouse functionality.