Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax SL-632-L

Snailax Shiatsu Neck and Back Massager with Heat

Model: SL-632-L

Brand: Snailax

Introduction

The Snailax Shiatsu Neck and Back Massager with Heat (Model SL-632-L) is designed to provide deep kneading massage and soothing heat therapy to various parts of the body. This manual provides essential information for the safe and effective use of your massager.



Image: Snailax Shiatsu Neck and Back Massager with Heat, showcasing its U-shaped design and control panel.

Safety Instructions

Please read all instructions carefully before using the massager. Failure to do so may result in injury or damage.

- Do not use the massager if you are pregnant.
- Do not use the massager on joints or bony parts of the body.

- Avoid using the massager on sensitive skin areas.
- The massager has an automatic shut-off feature after 15 minutes to prevent overuse.
- Always disconnect the power when not in use or before cleaning.
- Do not clean the massager with detergents or any sort of liquid. Wipe with a dry cloth.
- Do not use the massager near a fireplace, heater, stove, oven, or furnace.
- The massager is equipped with overheat protection. If it gets too hot, it will automatically turn off. Allow it to cool down before restarting.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Setup

1. Unpack the Snailax Shiatsu Neck and Back Massager (Model SL-632-L) and all accessories.
2. Connect the appropriate power cord (AC adapter for home/office or car adapter for vehicle) to the massager's input port.
3. Plug the power adapter into a suitable electrical outlet or the car's 12V socket.
4. Position the massager on the desired body area (neck, shoulders, back, waist, legs).

Operating Instructions

The massager features an intuitive control panel located on one of the arm straps.



Image: Close-up of the massager's control panel with buttons for Power, Direction, Speed, and Heat.

Control Panel Functions:

- **Power On/Off:** Press the power button to turn the massager on or off.
- **Massage Direction:** Press the direction button to switch between clockwise and counter-clockwise rotation of the massage nodes.
- **Intensity Adjustment:** The massager offers two intensity levels (high/low). Press the intensity button to cycle through

the desired level.

- **Heat Function:** The soothing heat function can be turned on or off independently by pressing the heat button. Red lights indicate heat is active.

Usage Tips:

- Place the massager over your neck, shoulders, back, waist, or legs.
- Utilize the handle straps to adjust the pressure and position of the massage nodes for a deeper or more targeted massage.
- The massager features an automatic 15-minute timer for safety and to prevent overuse.




Image: Demonstrates the versatility of the massager for neck, back, waist, and leg areas.

Official Product Video:

Video: KNQZE Back and Neck Massager with Heat 4D Deep Kneading. This video demonstrates the massager's features and how it can be used on different body parts, including the 4D deep kneading and heat functions.

Maintenance

To ensure the longevity and hygiene of your massager, follow these maintenance guidelines:

- **Cleaning:** The massager features a detachable soft cover over the massage heads. Unzip the cover to remove it for cleaning. It can be hand-washed or machine-washed on a gentle cycle with cold water. Air dry only.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight and high humidity.



Image: Highlights the breathable mesh fabric and soft PU leather construction of the massager.

Troubleshooting

If you encounter any issues with your massager, please refer to the following common problems and solutions:

Problem	Cause	Solution
Massager is not turning on	Power plug is loose or adapter is not plugged in correctly	Reconnect the plug to the outlet. Ensure the adapter is securely plugged into the massager.
Massager turns off on its own	15-minute timer activated or overheat protection triggered	This is normal operation. If due to overheat, allow the massager to cool down before restarting.

Specifications

- **Product Dimensions:** 7.28 x 8.27 x 15.75 inches
- **Item Weight:** 4.28 Pounds
- **Model Number:** SL-632-L
- **Power Source:** Corded Electric (AC adapter and car adapter included)
- **Material:** Leather (Soft PU Leather and breathable mesh fabric)
- **Massage Nodes:** 8 deep-kneading and rotating nodes
- **Features:** 2-way rotation, 2 intensity levels, soothing heat, 15-minute auto-timer, overheat protection

Warranty and Support

This product is covered by a warranty against defects in materials and workmanship for 90 days from the date of purchase. Proof of purchase must be presented within 90 days from the date of purchase.

Defects not due to accidental damage or misuse may be repaired by qualified engineers.

For further assistance or to claim warranty, please contact Snailax customer support through their official website or the retailer where the product was purchased.

© 2025 Snailax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8N69FWN

More documents and user manuals: **https://manuals.plus/**