

Xlife P2

Xlife Cordless Vacuum Cleaner P2 Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Xlife Cordless Vacuum Cleaner P2. Please read it thoroughly before first use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this vacuum cleaner.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust cup and/or filters in place.

PRODUCT COMPONENTS

Your Xlife Cordless Vacuum Cleaner P2 comes with several components designed for versatile cleaning. Familiarize yourself with each part:

- Main Motor & Canister (Main Body)
- HEPA Filter
- Electric Floor Brush with V-shaped Anti-tangle Roller
- Adjusted Handle (Extension Wand)
- Crevice Tool
- 2-in-1 Dusting Brush
- Rechargeable Lithium-ion Battery
- Adapter
- Wall-Mounted Charging Dock



Figure 1: Xlife Cordless Vacuum Cleaner P2 and its included accessories.

SETUP AND ASSEMBLY

1. Assembly

1. **Attach the Extension Wand:** Insert the extension wand into the main motor body until it clicks securely.
2. **Attach the Floor Brush:** Connect the electric floor brush to the other end of the extension wand, ensuring it locks into place.
3. **Install Battery:** Slide the rechargeable battery into the designated slot on the main motor body until it clicks.

2. Initial Charging

Before first use, fully charge the battery. The charging time is approximately 4 hours.

- Connect the adapter to the battery or the wall-mounted charging dock.
- Plug the adapter into a power outlet.
- The battery indicator on the main unit will show charging status.



Figure 2: Battery charging and runtime display.

3. Wall Mount Installation

The vacuum includes a wall-mounted charging dock for convenient storage and charging.

- Choose a suitable location near a power outlet.
- Secure the wall mount to the wall using appropriate screws (not included, or check packaging for specific hardware).
- Hang the vacuum cleaner on the dock for storage and charging.

One-Touch Dust Emptying + Wall

Mess-Free & Space-Saving – Keep Your Home Tidy,
Even After Cleaning



Figure 3: Wall-mounted charging dock and dust cup emptying.

OPERATION

1. Powering On/Off and Speed Modes

- Press the power button to turn the vacuum on or off.
- The vacuum features multiple power levels (up to 3) for different cleaning needs. Use the mode selection button to switch between standard and max modes.
- The digital display shows the current battery percentage and selected power mode.

2. Green Light Dust Detection

The electric floor brush is equipped with a green light that illuminates dust and debris on various surfaces, making it easier to spot and clean.

180° Flexible Maneuverability – Reaches Every Nook

140° Wide-Angle Green Light Detection – Finds Dust You Can't See



Figure 4: Green light revealing hidden dust under furniture.

3. Multi-Surface Cleaning

The Xlife P2 is designed for effective cleaning on various floor types, including carpets, hardwood, and tile.



Figure 5: Multi-surface brush roller in action.

4. Using Attachments

Utilize the included attachments for specialized cleaning tasks:

- **Crevice Tool:** Ideal for narrow spaces, corners, and edges (e.g., between sofa cushions, along baseboards).
- **2-in-1 Dusting Brush:** Use the brush for delicate surfaces like curtains, keyboards, or car interiors, and the wide mouth for general dusting.

Versatile Attachments for Every Cleanup

Covers All Cleaning Needs – 50-Minute Runtime to Tackle Your Whole Home



Figure 6: Versatile attachments for various cleaning needs.

5. Product Demonstration Video

Your browser does not support the video tag.

Video 1: Official demonstration of the Xlife Cordless Vacuum Cleaner P2's features and cleaning capabilities.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. Dust Cup Emptying

Empty the dust cup regularly, especially when debris reaches the 'MAX' line.

- Hold the main unit over a trash bin.
- Press the one-touch release button to open the dust cup flap and release contents.
- Close the flap securely after emptying.

One-Touch Dust Emptying + Wall

Mess-Free & Space-Saving – Keep Your Home Tidy, Even After Cleaning



Figure 7: One-touch dust cup emptying mechanism.

2. Filter Cleaning

The 7-stage HEPA filtration system requires periodic cleaning to maintain suction power and air quality.

- Twist and remove the dust cup from the main unit.
- Remove the HEPA filter and other filter components.
- Tap off loose dirt or rinse under cold running water. Ensure all parts are completely dry before reassembling.

3. Anti-Tangle Roller Cleaning

The V-shaped anti-tangle roller minimizes hair wrap, but occasional cleaning may be necessary.

- Detach the electric floor brush from the extension wand.
- Locate the release mechanism for the roller brush.
- Remove the roller brush and clear any tangled hair or debris.
- Reinsert the roller brush and secure it.



Figure 8: V-shaped anti-tangle roller design.

TROUBLESHOOTING

If you encounter issues with your Xlife Cordless Vacuum Cleaner P2, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery not charged or improperly installed.	Ensure battery is fully charged and correctly inserted.
Reduced suction power	Dust cup full, filters clogged, or blockage in the hose/brush.	Empty dust cup, clean filters, check for and remove blockages.
Brush roller not spinning	Hair or debris tangled in the roller, or roller not properly installed.	Clean the anti-tangle roller, ensure it is correctly reinstalled.
Short battery runtime	Battery not fully charged, or operating in Max mode continuously.	Fully charge the battery. Use standard mode for longer runtime.

SPECIFICATIONS

Feature	Detail
Brand	Xlife
Model Name	Cordless Vacuum Cleaner (P2)
Special Feature	Compact, Cordless, Detachable Battery, HEPA, High Power
Filter Type	HEPA Filter (7-Stage)
Suction Power	Up to 45KPa
Wattage	550 watts
Is Cordless?	Yes
Capacity	0.6 Liters
Charging Time	4 Hours
Battery Life	Up to 40 minutes (Standard Mode)
Noise Level	68 Decibels
Item Weight	3.2 pounds
Product Dimensions	9.8"L x 6"W x 44"H
Battery Type	Rechargeable Lithium-ion Battery
Recommended Uses	Pet Hair, Multi-Surface Cleaning

WARRANTY AND SUPPORT

Warranty Information

Your Xlife Cordless Vacuum Cleaner P2 includes a 24-month protection plan. Please refer to the warranty card included in your packaging for full terms and conditions.

Customer Support


For any questions, technical assistance, or warranty claims, please contact Xlife customer support. Contact details can typically be found on the product packaging or the official Xlife website. Please have your model number (P2) and purchase information ready when contacting support.

Related Documents - P2



Mattress Vacuum Cleaner

Model: C026PRO



- One-Press Dust Disposal
- High Efficiency & Dual Motor
- Large Dustbin Capacity
- Lightweight and Easy to Use

Thank you for choosing Xlife. For optimal performance and safety, please read this manual before use and keep it for future reference. For any inquiries, please contact us at support@getxlife.com.

Xlife C026PRO Mattress Vacuum Cleaner User Manual

User manual for the Xlife C026PRO Mattress Vacuum Cleaner, detailing safety precautions, operating instructions, cleaning, maintenance, technical specifications, and troubleshooting.

Cordless Vacuum Cleaner

Model: P12



- Quiet Operation
- Long-Lasting Lithium Battery
- Easy-to-Use
- High Efficiency & Energy Saving

Thank you for choosing 888i. For optimal performance and safety, please read this manual thoroughly before first use and retain for future reference. Contact our support team at support@888i.com for any inquiries.

Xlife P12 Cordless Vacuum Cleaner User Manual

Comprehensive user manual for the Xlife P12 Cordless Vacuum Cleaner, covering features, safety, assembly, operation, maintenance, and troubleshooting.



Xlife X3 Smart Visual Ear Cleaning Rod: Setup, Features, and Troubleshooting Guide

Comprehensive guide to the Xlife X3 smart visual ear cleaning rod. Learn how to set up, connect, replace accessories, understand product specifications, troubleshoot common issues, and follow safety precautions for effective and safe ear cleaning.

Q3认证英文说明书20230103v1.0
尺寸: 63x154mm
材质: 105g+哑粉纸
工艺: 四色折
印刷: 连线哑粉, 双面四色



[XLIFE Q3 Smart Visual Ear-Clean Rod User Manual and Specifications](#)

Comprehensive user manual and technical specifications for the XLIFE Q3 Smart Visual Ear-Clean Rod. Includes setup instructions, Wi-Fi connection guide, troubleshooting tips, product parameters, safety warnings, and FCC compliance information.