

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MOTPK](#) /

› **MOTPK Gaming Desk with LED Lights & Power Outlet, 48 Inch Computer Desk with Drawer, Reversible Table with Monitor Shelf & Headphone Hook for Home Office, Black User Manual**

MOTPK B01170401006

MOTPK Gaming Desk with LED Lights & Power Outlet

Model: B01170401006

INTRODUCTION

Thank you for choosing the MOTPK Gaming Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk. Please read this manual thoroughly before assembly and use, and retain it for future reference.

SAFETY INFORMATION

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and retighten as necessary.
- Do not overload the desk or shelves beyond their weight capacity.
- Keep liquids away from the power outlet and LED light strip to prevent electrical hazards.
- Do not allow children to climb on or play with the desk.
- Use only the provided power cord and ensure it is properly routed to avoid tripping hazards.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Desk Top Panels
- Monitor Shelf
- Metal Frame Components
- Fabric Drawer
- Recessed Power Outlet with USB Ports
- RGB LED Light Strip with Controller
- Headphone Hook
- Adjustable Non-slip Foot Pads
- Assembly Hardware (screws, bolts, etc.)

- Assembly Tools (Allen wrench, screwdriver)
- Instruction Manual

SETUP & ASSEMBLY

This desk is designed for hassle-free assembly with clearly labeled parts and a detailed, step-by-step illustrated manual included in the package. All necessary assembly tools are provided.

Key Features for Assembly:

- **Reversible Design:** The fabric drawer and PC stand can be assembled on either the left or right side of the desk to suit your preference and room layout.
- **Monitor Shelf:** The integrated monitor shelf provides an ergonomic viewing height, reducing neck and eye strain.
- **Headphone Hook:** A convenient hook is included for hanging headphones or bags.

PRODUCT SIZE



Figure 1: Product Dimensions and Reversible Design. This diagram illustrates the overall dimensions of the desk and highlights the reversible nature of the side storage unit, allowing it to be installed on either the left or right side.



Figure 2: Assembled MOTPK Gaming Desk in a typical setup. This image provides a visual reference of the fully assembled desk with accessories, showcasing its functional design.


OPERATING INSTRUCTIONS

Recessed Power Outlet

The desk is equipped with a built-in power panel for convenient access to power for your devices.

- **3 AC Outlets:** 120V/12A
- **2 USB Ports:** 5V/2A

Simply plug your laptop, tablet, smartphone, or gaming peripherals directly into the outlets or USB ports located on the desk surface.



RECESSED POWER OUTLET



3 AC Outlets
120V/12A



2 USB Ports
5V/2A

Figure 3: Recessed Power Outlet. This image details the integrated power strip with AC and USB ports, designed for easy device charging and power access.

RGB LED Lights

The integrated RGB LED strip under the monitor shelf offers customizable lighting to enhance your workspace or gaming ambiance.

- **10 Static Colors:** Choose from a variety of solid colors.
- **10 Dynamic Modes:** Experience different lighting effects.

How to Control the LED Lights:



Figure 4: LED Light Controller. This diagram illustrates the control panel for the RGB LED lights, explaining the function of each button for color, mode, speed, and brightness adjustments.

- **Static Color Button (C):** Press once to switch to static color mode. Each subsequent press changes the color.
- **Dynamic Mode Button (M):** Press once to switch to dynamic effect mode. Each subsequent press changes the dynamic mode. Press and hold for 3 seconds to enter demo mode, where the strip cycles through various dynamic modes automatically.
- **Speed & Brightness & Power Button (S/B/Power):**
 - In static mode, press to adjust brightness levels.
 - In dynamic mode, press to adjust dynamic mode speed.
 - Press and hold to shut down the LED strip when it is on. Press briefly to turn it on.

The product features a power-off memory function, meaning the strip will restore the last color, brightness, and mode settings upon the next power-on.

Fabric Drawer

The fabric drawer provides discreet storage for your items.



FABRIC DRAWER



More easily to push & pull



Durable



Easy to assemble

Figure 5: Fabric Drawer. This image showcases the pull-out fabric drawer, emphasizing its ease of use, durability, and simple assembly.

- The drawer is designed for easy pushing and pulling.
- It is easy to clean.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the laminated finish.
- **Fabric Drawer:** The fabric drawer can be spot cleaned with a mild detergent and water. Allow to air dry completely.
- **Electrical Components:** Ensure the power outlet and LED strip are dry before use. Do not attempt to disassemble or repair electrical components yourself.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight and secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly after assembly.	Screws are not fully tightened. Uneven floor.	Ensure all assembly screws are tightened securely. Adjust the non-slip foot pads to level the desk on uneven surfaces.

Problem	Possible Cause	Solution
LED lights are not turning on.	Power cable not connected. Controller malfunction.	Check if the LED light strip's power cable is securely plugged into a working outlet. Ensure the controller is properly connected to the LED strip. Try pressing the power button on the controller.
Power outlets/USB ports not working.	Desk power cord not plugged in. Overload.	Verify the desk's main power cord is securely plugged into a functional wall outlet. Check if too many high-power devices are connected, potentially tripping a circuit breaker (if applicable).
Fabric drawer does not slide smoothly.	Improper installation. Obstruction.	Ensure the drawer frame is assembled correctly and free of obstructions. Check if the drawer is overloaded.

SPECIFICATIONS

Feature	Detail
Brand	MOTPK
Model Number	B01170401006
Product Dimensions (D x W x H)	18.9"D x 47.2"W x 29.9"H
Color	Black
Style	Modern
Base Material	Metal
Top Material Type	Engineered Wood
Finish Type	Laminated
Special Features	Built-In USB Outlet, Built-in Power Outlet, Compact, Reversible, Monitor Shelf, Headphone Hook
Number of Drawers	1 (Fabric Drawer)
Item Weight	12.8 Kilograms
Assembly Required	Yes (Tools Included)
Product Care Instructions	Wipe with Damp Cloth

WARRANTY & SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact MOTPK customer service directly. Please have your model number (B01170401006) and purchase details ready when contacting support.

Related Documents - B01170401006

	<p><u>MOTPK Gaming Desk User Manual and Assembly Guide</u></p> <p>Comprehensive user manual and assembly guide for the MOTPK Gaming Desk, featuring step-by-step instructions, parts list, troubleshooting, and customer service information.</p>
	<p><u>MOTPK L-Shaped Gaming Desk User Manual</u></p> <p>Comprehensive user manual for the MOTPK L-Shaped Gaming Desk, detailing pre-installation, assembly instructions, parts list, customer service information, and troubleshooting.</p>