

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [COSTWAY](#) /

› [COSTWAY Outdoor Daybed with Retractable Canopy Instruction Manual](#)

## COSTWAY Outdoor Daybed

# COSTWAY Outdoor Daybed with Retractable Canopy Instruction Manual

Model: Outdoor Daybed

## INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your COSTWAY Outdoor Daybed with Retractable Canopy. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product. Keep this manual for future reference.

## SAFETY INFORMATION

Adherence to the following safety guidelines is crucial for safe operation and to prevent injury or damage to the product.

- Always assemble according to the provided instructions.
- Be cautious of sharp edges when handling components during assembly.
- Keep the canopy away from open flames or heat sources to prevent fire hazards.
- Do not exceed the maximum weight capacity of 800 lbs (approximately 363 kg). Overloading can cause structural failure and injury.
- Ensure the product is stable and securely placed on a level surface before use, especially in outdoor environments where wind or uneven ground may pose a risk.
- Regularly inspect all fasteners and connections to ensure they remain tight. Tighten as necessary.
- Do not allow children to play on or around the daybed unsupervised.

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all parts listed in the packing list are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

Typical components include:

- Main frame sections (metal and rattan)
- Retractable canopy frame and fabric
- Seat cushions and back cushions
- Pneumatic rods for canopy and side tables
- Hardware pack (screws, washers, nuts, Allen wrench)
- Instruction manual

## SETUP AND ASSEMBLY

---

Assembly typically requires two people and takes approximately 1-2 hours. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list and diagrams in your specific packing list to identify each component.

# Product Dimensions

Overall Loading Capacity:



Please do not tighten all the screws until all the holes are aligned  
Please refer to the size instructions before purchasing to avoid unnecessary trouble

Figure 1: Product Dimensions. This diagram illustrates the overall dimensions of the daybed and its components, including the seat height, cushion sizes, and canopy height.

3. **Assemble Frame:** Connect the main frame sections using the provided hardware. **Important: Do not fully tighten all screws until all holes are aligned and all components are loosely fitted.** This allows for easier adjustment.
4. **Attach Side Tables:** Secure the retractable side tables to the main frame. Ensure the pneumatic rods are correctly installed to allow for smooth operation.



Phone



Drink



Magazine



## Retractable Side Tables

Allow You to Keep Items Close to Hand

Figure 2: Retractable Side Tables. This image demonstrates the functionality of the side tables, which can be extended to hold items like phones, drinks, or magazines, and shows the internal pneumatic rod mechanism.

5. **Install Canopy:** Attach the retractable canopy frame and fabric to the daybed. The pneumatic rod system facilitates easy adjustment. Ensure the canopy fabric is securely fastened, often with fixed ropes.

# Retractable Canopy

Use the Pneumatic Rod for Safe and Easy Adjustment



Fixed Ropes

Figure 3: Retractable Canopy. This illustration shows the daybed with its canopy extended for shade and retracted, detailing the pneumatic rod mechanism for smooth adjustment and the fixed ropes used to secure the canopy fabric.

6. **Place Cushions:** Position the seat and back cushions on the daybed.

## Please always keep cushions dry to prolong the service time

Due to the light avoidance and light exposure, the color of the cushions is slightly different



Figure 4: Cushions Detail. This image provides a close-up of the daybed's cushions, emphasizing the high-density sponge for comfort and the smooth zippers for easy cover removal and cleaning.

7. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws and bolts. Do not overtighten.
8. **Stability Check:** Gently shake the assembled daybed to ensure it is stable and all connections are secure.

## OPERATING INSTRUCTIONS

Your COSTWAY Outdoor Daybed is designed for comfortable outdoor relaxation. Here's how to use its key features:

- **Retractable Canopy:** To extend the canopy, gently pull it forward. To retract, push it back. The pneumatic rod system will assist in smooth movement. Ensure the canopy is fully extended or retracted and secured with any provided ropes to prevent wind damage.
- **Retractable Side Tables:** To use a side table, gently pull it outwards until it locks into place. To fold it

down, push it inwards. The pneumatic rod will assist in its movement. These tables are designed to hold light items such as drinks, snacks, or small electronic devices.

- **General Use:** The daybed is intended for lounging and relaxation. Avoid standing on it or using it for purposes other than its design.

## MAINTENANCE

Proper maintenance will extend the life and appearance of your outdoor daybed.

- **Cushions:** The cushion covers feature smooth zippers for easy removal. Machine wash covers in cold water with mild detergent and air dry. **Always keep cushions dry to prolong their service life.** Store cushions indoors during inclement weather or prolonged periods of non-use.
- **Rattan:** Clean the PE rattan with a soft cloth, mild soap, and water. Rinse thoroughly and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Metal Frame:** The heavy-duty metal frame is rust-resistant. Wipe down with a damp cloth as needed. For stubborn dirt, use mild soap and water. Inspect the frame periodically for any signs of rust or damage and address promptly.
- **Canopy Fabric:** Clean the canopy fabric with a soft brush or cloth and mild soap and water. Ensure it is completely dry before retracting or storing to prevent mildew.
- **General Care:** Periodically check all nuts and bolts and tighten them as necessary to maintain structural integrity.

## TROUBLESHOOTING

If you encounter issues with your daybed, refer to the following common solutions:

| Problem                                    | Possible Cause  | Solution  |
|--|---|---|
| Daybed feels unstable or wobbly.           | Loose fasteners; uneven ground.                             | Ensure all screws and bolts are fully tightened. Move the daybed to a level surface. Adjust non-slip foot pads if applicable. |
| Canopy is difficult to extend or retract.  | Pneumatic rod obstruction; mechanism dirty; fabric snagged. | Check for any obstructions around the pneumatic rods. Clean the mechanism. Ensure canopy fabric is not caught.                |
| Side tables do not operate smoothly.       | Pneumatic rod issue; debris in mechanism.                   | Inspect the pneumatic rod for damage or obstruction. Clean any debris from the table's sliding mechanism.                     |
| Cushions appear flattened or worn quickly. | Prolonged exposure to elements; excessive weight.           | Store cushions indoors when not in use or during bad weather. Ensure weight capacity is not exceeded.                         |

If the problem persists after attempting these solutions, please contact customer support.

## SPECIFICATIONS

| Feature                | Detail  |
|------------------------|---|
| Material               | PE Rattan, Metal, Sponge, Polyester           |
| Overall Dimension      | 65" x 60.5" x 58.5" (Length x Width x Height) |
| Seat Cushion Dimension | 58" x 23.5" x 2" (Length x Width x Thickness) |
| Back Cushion Dimension | 16" x 16" x 5" (Length x Width x Thickness)   |
| Seat Height            | 12.5"   |
| Weight Capacity        | 800 lbs (approximately 363 kg)                |
| Net Weight             | 57.5 lbs (approximately 26 kg)                |
| Assembly Required      | Yes   |

## WARRANTY INFORMATION

COSTWAY products are manufactured to high-quality standards and are backed by a limited manufacturer's warranty. Please refer to the warranty card included with your product or visit the official COSTWAY website for detailed warranty terms and conditions. This warranty typically covers defects in materials and workmanship under normal use.

## CUSTOMER SUPPORT

For assistance with assembly, missing parts, or any other inquiries regarding your COSTWAY Outdoor Daybed, please contact COSTWAY customer service. Contact information can typically be found on the product packaging, the official COSTWAY website, or your purchase receipt.

When contacting support, please have your model number ("Outdoor Daybed") and purchase date available to expedite service.

