

[Manuals.plus](#) /

› [EBELLO](#) /

› EBELLO Power Lift Recliner Chair with Massage and Heat (Model B0F8NRR2QS) - Instruction Manual

EBELLO B0F8NRR2QS

EBELLO Power Lift Recliner Chair (Model B0F8NRR2QS) Instruction Manual

INTRODUCTION

Thank you for choosing the EBELLO Power Lift Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read these instructions thoroughly before use and retain them for future reference.



Image: The EBELLO Power Lift Recliner Chair, showcasing its plush design and side pocket.

Key Features:

- **Electric Power Lift Mechanism:** Assists users in standing up easily, reducing strain on the back and knees.
- **Massage and Heat Functions:** Provides relief to tired muscles and joints for enhanced relaxation.
- **Overstuffed Cushioning and Soft Fabric:** Offers superior comfort and durability for daily use.
- **Hidden Cup Holders and Side Pocket:** Convenient storage for beverages and personal items, keeping essentials within reach.

SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Keep hands and feet clear of the reclining mechanism during operation.
- Do not allow children to play on or around the recliner unsupervised.

- Avoid placing heavy objects on the footrest when it is extended.
- Only use the recliner on a flat, stable surface.
- Unplug the power cord from the outlet before cleaning or if the chair will not be used for an extended period.

PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Recliner Chair Backrest
- Recliner Chair Base
- Power Adapter and Cord
- Remote Control for Massage and Heat Functions

ASSEMBLY INSTRUCTIONS

Assembly of the EBELLO Power Lift Recliner Chair is designed to be straightforward, typically requiring two people. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Backrest to Base:** Align the metal brackets on the backrest with the corresponding slots on the recliner base. Push down firmly until the backrest clicks securely into place. Ensure both sides are fully engaged.



Image: Close-up view of the solid metal frame support and lifting device, illustrating the robust construction.

3. **Connect Power:** Locate the power cord from the chair and connect it to the power adapter. Plug the adapter into a standard electrical outlet.
4. **Verify Functionality:** Test the power lift and recline functions using the control panel or remote to ensure proper operation.

OPERATING INSTRUCTIONS

Power Lift and Recline Function:

The recliner is equipped with an electric control panel, typically located on the side of the chair, to manage the lift and recline functions. Use the buttons to smoothly adjust the chair to your desired position.

Product Function



All the angles you need include



Reading



Watching TV



Napping



Stand Up

Image: Diagram illustrating the various functions of the recliner, including lift, USB port, and recline positions for reading, watching TV, napping, and standing up assistance.

Massage and Heat Functions:

Use the provided remote control to activate and customize the massage and heat settings. The chair offers multiple massage points, various modes, and a lumbar heating option for targeted comfort.

Massage & Heating




Image: Visual representation of the massage and heating zones on the recliner, along with the remote control displaying options for lumbar heating, 8-point massage, 5 massage modes, and timing control.

Using Cup Holders and Side Pocket:

- **Cup Holders:** The recliner features hidden cup holders. Gently pull them out from the armrest when needed and push them back in for a clean appearance.
- **Side Pocket:** A convenient side pocket is integrated into the design for storing remote controls, magazines, or other small items.



Pullable Cup Holder

The cup holder is the key to a truly immersive cinema - like experience, allowing you to keep your drinks close at hand. When they're not in use, simply tuck them away for a sleek, uncluttered look.



Image: Close-up of the recliner's armrest showing a pullable cup holder extended for use.



Side Pocket

The side pocket is cleverly positioned on one side of the sofa, providing a convenient storage solution. Whether it's the remote control, a favorite magazine, or a pair of reading glasses, everything is within easy reach.

Image: Detail of the recliner's side pocket, designed for convenient storage of small items.

USB Charging Port:

A USB charging port is integrated into the control panel, allowing you to charge your electronic devices while relaxing.

CARE AND MAINTENANCE

Fabric Care (Microfiber):

- **Regular Cleaning:** Vacuum regularly using a soft brush attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild soap solution and a damp cloth, then blot dry. Test any cleaning solution on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or solvents, as these can damage the fabric.



Image: Close-up of the recliner's back cushion, highlighting the soft microfiber fabric.



Image: Close-up of the recliner's seat cushion, demonstrating the plush foam and synthetic fiber filling.

Mechanism Care:

- Periodically check all bolts and screws to ensure they are tight.
- Do not lubricate the reclining mechanism unless specifically instructed by the manufacturer.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not recline or lift.	Power cord unplugged or loose connection.	Ensure power cord is securely plugged into the chair and a working electrical outlet.

Problem	Possible Cause	Solution
Massage/Heat functions not working.	Remote control batteries low or power issue.	Check remote control batteries. Verify chair has power.
Unusual noises during operation.	Loose hardware or obstruction in mechanism.	Check for loose bolts and tighten if necessary. Ensure no objects are obstructing the mechanism.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact EBELLO customer support.

PRODUCT SPECIFICATIONS



Image: Diagram showing the dimensions of the EBELLO Power Lift Recliner Chair, including height, width, and depth measurements.

Feature	Detail
Brand	EBELLO

Feature	Detail
Model Number	B0F8NRR2QS
Color	Grey
Upholstery Fabric Type	Microfiber
Seating Capacity	1
Assembly Required	Yes
Seat Fill Material	Synthetic Fiber
Seat Back Fill Material	Synthetic Fiber
Item Firmness Description	Plush
Included Components	1 x Recliner Chair

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact EBELLO customer service directly. Keep your purchase receipt as proof of purchase.

Contact information for EBELLO can typically be found on their official website or through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question