

EV445

Accent Cabinet Farmhouse Style 4 Door Wooden Buffet Server Cabinet

Model: EV445 | Brand: Generic

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your new Generic Accent Cabinet, Model EV445. This cabinet features a farmhouse style with four doors, a distressed black finish, and a wooden construction. It is designed to offer both aesthetic appeal and functional storage with adjustable interior shelves.



Image 1: The Accent Cabinet in a typical home environment.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all hardware and small parts out of reach of children.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload shelves. Distribute weight evenly.
- For stability, consider anchoring the cabinet to a wall, especially if children are present. Wall anchoring hardware may not be included.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the parts list provided in the packaging. If any items are missing or damaged, contact customer support

immediately.

4. ASSEMBLY INSTRUCTIONS

The Accent Cabinet is designed for straightforward assembly. All necessary hardware and detailed instructions are included in the product packaging. Please follow the step-by-step guide provided with your cabinet for optimal results.

1. Unpack all components and lay them out on a protected surface.
2. Identify each part using the provided parts list.
3. Follow the graphical and written instructions to connect the panels and secure them with the designated hardware.
4. Attach the doors and install the metal door handles.
5. Insert the adjustable shelves into the desired positions.
6. Ensure all screws and fasteners are tightened for stability.



Image 2: Front view of the assembled Accent Cabinet, showcasing the hexagonal door pattern.

5. OPERATING INSTRUCTIONS

5.1 Opening and Closing Doors

The cabinet features four doors with modern style metal handles. To open, gently pull the handle. To close, push the door until it is flush with the cabinet frame.

5.2 Adjusting Shelves

The interior of the cabinet contains adjustable shelves, allowing you to customize storage space. To adjust a shelf:

1. Empty the shelf completely.
2. Carefully lift the shelf and remove it from its supports.
3. Relocate the shelf supports to the desired height. Ensure they are level.

4. Place the shelf back onto the supports, ensuring it is stable.



Image 3: Interior view of the cabinet, demonstrating the adjustable shelves.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Accent Cabinet, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the distressed finish and wood.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a stable humidity level to prevent wood from warping or cracking.
- **Hardware:** Periodically check and tighten all screws and fasteners to maintain structural integrity.





Image 4: Detail of the distressed black wood texture and hexagonal pattern on the cabinet door.

7. TROUBLESHOOTING

- **Wobbly Cabinet:** Ensure the cabinet is on a level surface. Check all assembly screws and tighten them if loose.
- **Doors Not Aligning:** Adjust the door hinges if they are adjustable. Ensure the cabinet frame is square and all connections are tight.
- **Difficulty Opening/Closing Doors:** Check for any obstructions. Ensure hinges are properly installed and lubricated if necessary.
- **Scratches/Minor Damage:** Use a wood repair kit or touch-up pen matching the distressed black finish.

8. SPECIFICATIONS

Feature	Detail
Brand	Generic
Model	EV445
Color	Antique Black
Material	Engineered Wood, Wood
Product Dimensions (D x W x H)	15.7" x 59.84" x 31.49"
Mounting Type	Floor Mount
Base Type	Legs
Required Assembly	Yes



Image 5: Dimensional diagram of the Accent Cabinet.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact the seller directly. Keep your purchase receipt for any warranty claims.