

[Manuals.plus](#) /

› [Bugaboo](#) /

› Bugaboo Butterfly 2 Travel Stroller User Manual

Bugaboo Butterfly 2

Bugaboo Butterfly 2 Travel Stroller User Manual

Model: Butterfly 2

INTRODUCTION

This manual provides essential information for the safe and proper use, maintenance, and troubleshooting of your Bugaboo Butterfly 2 Travel Stroller. Please read this manual thoroughly before assembly and use, and keep it for future reference.

The Bugaboo Butterfly 2 is an ultra-compact, lightweight travel stroller designed for ease of use and portability, suitable for children from 0 to approximately 48 months (car seat recommended for newborn comfort) and up to 48.5 lbs (22 kg).

IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these instructions could result in serious injury or death.

- Always use the restraint system.
- Never leave your child unattended in the stroller.
- Ensure all locking devices are engaged before use.
- Do not overload the storage basket. Maximum capacity is 17.6 lbs (8 kg).
- Do not hang bags or items on the handle, as this can cause the stroller to tip over.
- This stroller is not suitable for running or skating.
- Always engage the brake when placing or removing your child from the stroller.
- Keep children clear of moving parts when adjusting the stroller.
- The stroller is designed for one child only.
- For newborns, a compatible car seat is recommended for optimal comfort and safety.

SETUP AND INITIAL ASSEMBLY

Your Bugaboo Butterfly 2 Travel Stroller comes largely pre-assembled. Follow these steps for initial setup.

Unfolding the Stroller

To unfold the stroller, release the folding latch and allow the frame to extend. Ensure all parts click into place securely

before use. The stroller features a one-second compact fold and unfold mechanism.



Image: The Bugaboo Butterfly 2 stroller demonstrating its one-second unfolding sequence. The image shows the stroller transitioning from its compact folded state to its fully extended, ready-to-use position, highlighting the ease of deployment.

Attaching the Canopy

The canopy attaches to the frame using designated clips. Ensure it is securely fastened to provide adequate shade and protection for your child.

Harness System Adjustment

The 5-point harness system is adjustable to ensure a snug and secure fit for your child. Adjust the shoulder straps and waist straps to fit comfortably without being too tight. Refer to the diagram below for key features.

Our most sustainable stroller, using bio-based material and recycled aluminum

One-second compact fold and unfold

IATA carry-on compliant for overhead bins

From newborn to 50 lbs

Fully upright seat, and one hand adjustable integrated footrest

Spacious under seat basket, and back pocket

Larger wheels for a smoother ride

Car seat compatible
(carseat adapters required)



Image: A detailed diagram of the Bugaboo Butterfly 2 stroller, pointing out its main features. These include the one-second compact fold, fully upright seat, adjustable integrated footrest, spacious underseat basket and back pocket, larger wheels for smoother rides, and car seat compatibility (with adapters).

OPERATING THE STROLLER

Folding the Stroller

To fold the Bugaboo Butterfly 2, ensure the seat is in the upright position. Locate the folding mechanism on the handlebar and activate it. The stroller will collapse into a compact, self-standing unit. This one-second fold is designed for quick and easy storage, making it ideal for travel and overhead compartments on planes.



Image: This image illustrates the compact size of the Bugaboo Butterfly 2 when folded, alongside its full dimensions when unfolded. The folded dimensions are approximately 21.26 inches (height) by 9.06 inches (width), demonstrating its suitability for travel.

Reclining the Seat

The seat offers multiple recline angles, allowing your child to sit fully upright to observe their surroundings or recline for a more comfortable nap. Adjust the recline using the lever located at the back of the seat.



Image: The Bugaboo Butterfly 2 stroller seat is shown adjusting its recline angle. This feature allows for easy transition between an upright position for active engagement and a more reclined position for rest or sleep.

Adjusting the Footrest

The integrated footrest is adjustable to provide optimal comfort as your child grows. Simply press the buttons on either side of the footrest to adjust its angle.

Using the Brake System

The stroller is equipped with a foot-operated brake system. Press down on the brake pedal located near the rear wheels to engage the brake. Lift the pedal to release. Always ensure the brake is fully engaged when the stroller is stationary.

Storage Basket

The extra-large underseat storage basket has a capacity of 17.6 lbs (8 kg), providing ample space for essentials. There is also a handy back storage pocket for smaller items.



Extra storage space

Image: A close-up view of the Bugaboo Butterfly 2's spacious underseat storage basket, demonstrating its capacity by holding various child essentials such as toys and a small bag. This highlights the practical storage solution for parents on the go.

MAINTENANCE AND CARE

Regular maintenance will extend the life and performance of your Bugaboo Butterfly 2 stroller.

Cleaning Fabrics

The fabric components, made of Polyester, are machine washable. Refer to the care label for specific washing instructions. Generally, use cold water and a mild detergent. Do not bleach. Air dry away from direct sunlight.

Cleaning Frame and Wheels

Wipe the aluminum frame with a damp cloth and mild soap. Dry thoroughly. Clean the rubber or rubber-reinforced plastic tires regularly to remove dirt and debris. Periodically check the wheels for smooth rotation and lubricate axles if necessary with a silicone-based lubricant.

Storage

When not in use, store the stroller in a dry place, away from direct sunlight and extreme temperatures, to prevent material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller does not fold/unfold smoothly.	Mechanism obstructed or not fully engaged.	Ensure no items are blocking the folding mechanism. Apply light pressure to the handlebar while activating the fold/unfold button.
Wheels are stiff or squeaky.	Accumulation of dirt/debris or lack of lubrication.	Clean wheels and axles thoroughly. Apply a silicone-based lubricant to the moving parts of the wheels.
Brake is not engaging/disengaging properly.	Debris in the brake mechanism or misalignment.	Check for any obstructions around the brake pedal and mechanism. Ensure the pedal is fully pressed down or lifted.
Harness straps are difficult to adjust.	Straps are twisted or buckle is jammed.	Untwist any straps. Ensure the buckle is clean and free of debris.

SPECIFICATIONS

Feature	Detail
Brand	Bugaboo
Model Number	8717447366379
Color	Black
Frame Material	Aluminum
Fabric Type	Polyester
Age Range Description	0-48 Months
Maximum Weight Recommendation	48.5 Pounds (22 kg)
Item Weight	16.1 Pounds (7.3 kg)
Folded Size (L x W x H)	37.2" x 17.64" x 40.47" (Unfolded) / Approx. 21.26" x 9.06" (Folded)
Harness Type	5 Point
Storage Basket Capacity	17.64 Pounds (8 kg)
Included Components	Storage basket, Canopy

WARRANTY INFORMATION

Bugaboo offers a standard warranty on its products. Additionally, you may be eligible for an extended 4-year warranty. To double your warranty, please register your product after purchase. For detailed warranty terms and conditions, please visit the official Bugaboo website or contact customer support.

CUSTOMER SUPPORT

For further assistance, spare parts, or service inquiries, please contact Bugaboo customer support. You can find contact information and frequently asked questions on the official Bugaboo website:

[Visit Bugaboo Official Website](#)

Please have your model number (8717447366379) and purchase details ready when contacting support.

© 2025 Bugaboo. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question