

Orient Electric Wall 97 HS

Orient Electric Wall 97 HS High Speed Wall Fan Instruction Manual

[Box](#) [Setup](#) [Operating](#) [Introduction](#) [Maintenance](#) [Safety Instructions](#) [Troubleshooting](#) [What's in the Box](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Orient Electric Wall 97 HS High Speed Wall Fan. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new fan. Please read these instructions carefully before use and retain them for future reference.

The Orient Electric Wall 97 HS is designed to provide powerful airflow with its 2100 RPM motor and 95 CMM air delivery. It features a durable 100% copper motor, 90-degree oscillation, and a tilt mechanism for customized cooling. Safety is enhanced with a military-grade guard and thermal overload protection.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the fan is securely mounted to a wall before operation.
- Do not insert fingers or any objects through the fan guards while the fan is operating.
- Unplug the fan from the power outlet before cleaning, maintenance, or when not in use.
- Keep children and pets away from the fan during operation.
- Do not operate the fan with a damaged cord or plug. Contact qualified service personnel for repairs.
- Ensure the power supply voltage matches the rating indicated on the fan's label.
- Avoid using the fan in wet or damp environments to prevent electrical hazards.
- The fan is equipped with thermal overload protection. If the fan stops unexpectedly, unplug it and allow it to cool down before restarting.



Built
to keep you safe



Thermal Overload
safety

Figure 2.1: The fan is built with Thermal Overload safety for enhanced protection.

3. WHAT'S IN THE BOX

Carefully unpack the contents and ensure all items are present:

- Motor & Bracket Assembly
- Front Guard
- Back Guard
- Blades
- Mounting hook (in knocked down condition)

4. SETUP AND INSTALLATION

Follow these steps for quick and easy assembly and installation:

1. **Attach Back Guard:** Fix the back guard onto the motor assembly and tighten securely.
2. **Fix the Blade:** Slide and secure the fan blade onto the motor spindle. Ensure it is firmly in place.
3. **Attach Front Guard:** Align the front guard with the back guard, ensuring the brand logo is correctly oriented. Tighten the screws to secure both guards together.
4. **Wall Mounting:** Use the provided mounting hook to securely attach the fan to a suitable wall surface. Ensure the wall can support the fan's weight and vibrations during operation.



Assemble in minutes

No tools needed




Figure 4.1: Step-by-step assembly guide for the wall fan.

5. OPERATING INSTRUCTIONS

Your Orient Electric Wall 97 HS fan offers customizable cooling options:

5.1 Speed Control

The fan features a 3-speed control mechanism. Adjust the speed using the pull cord or the piano switch located on the

fan body. Select from Low, Medium, or High settings to achieve your desired airflow.



Figure 5.1: Pull cord mechanism and 3-speed switch for fan control.

5.2 Oscillation and Tilt Adjustment

The fan provides 90-degree oscillation to cover a wide area with uniform cooling. You can also adjust the vertical tilt to direct airflow precisely where needed. Use the dedicated pull cord for oscillation control.



90° oscillation



Up & down tilt



Feel the breeze
wherever you need

Figure 5.2: Fan demonstrating 90-degree oscillation and vertical tilt for directional airflow.



Figure 5.3: The fan provides high-speed airflow with aerodynamic resin blades.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your fan.

6.1 Cleaning

- Always unplug the fan before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan.
- To clean the blades and inside the guards, carefully remove the front guard (refer to assembly instructions in Section 4). Wipe the blades and internal components with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the fan's finish.
- Ensure all parts are completely dry before reassembling and operating the fan.

6.2 Storage

If storing the fan for an extended period, clean it thoroughly and store it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

7. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on	No power supply; Plug not fully inserted; Thermal overload activated; Faulty switch.	Check power outlet and plug connection. Allow fan to cool down if thermal overload activated. Contact customer support if switch is faulty.
Fan makes excessive noise	Loose parts; Fan not mounted securely; Debris in blades/motor; Blades unbalanced.	Ensure all screws are tight and fan is securely mounted. Clean blades and motor area. Contact customer support if noise persists.
Weak airflow	Fan speed set too low; Obstruction in front/behind fan; Dirty blades.	Increase fan speed. Remove any obstructions. Clean fan blades.
Oscillation not working	Oscillation mechanism jammed; Pull cord issue.	Check for obstructions. Gently operate the pull cord. If issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact Orient Electric customer support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Orient Electric
Model Name	Wall 97 HS
Model Number	2121666110900
Colour	Black & Red
Power Source	Corded Electric
Wattage	110 Watts
Speed	2100 RPM
Air Flow Capacity	95 Cubic Meters Per Minute (CMM)
Number of Speeds	3
Oscillation	90 Degrees
Mounting Type	Wall Mount

Feature	Detail
Material	Plastic
Blade Length	400 Millimetres
Product Dimensions (D x W x H)	45.7D x 21W x 46H Centimeters
Item Weight	3.45 Kilograms
Country of Origin	India

9. WARRANTY AND CUSTOMER SUPPORT

9.1 Warranty Information

This product comes with a standard manufacturer's warranty against manufacturing defects. For specific warranty terms, duration, and conditions, please refer to the warranty card included with your purchase or visit the official Orient Electric website. Keep your purchase receipt as proof of purchase for warranty claims.

Extended warranty plans may be available for purchase separately. Please check with your retailer or Orient Electric for details on available protection plans.

9.2 Customer Support

For any queries, service requests, or technical assistance, please contact Orient Electric customer support:

- **Manufacturer:** Orient Electric Limited
- **Manufacturer Address:** 7, Ghore Bibi Lane, Kadapara, Kankurgachi, Kolkata, West Bengal 700054 & Plot No. S-85 to S-94, E-City Raviryala village, Maheshwaram Mandal, Ranga Reddy district, Telangana, 501359
- **Online Support:** Visit the official Orient Electric website for FAQs, service center locators, and contact forms.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question