

[Manuals.plus](#) /

› [Globlazer](#) /

› Globlazer FC50 Beige Cat Tree Instruction Manual

Globlazer FC50

Globlazer FC50 Beige Cat Tree Instruction Manual

Model: FC50 | Brand: Globlazer

INTRODUCTION

Thank you for choosing the Globlazer FC50 Beige Cat Tree. This multi-level cat activity center is designed to provide a comfortable and engaging space for your feline companions. Standing at 127 cm, it features spacious cat houses, perches, and scratching posts, suitable for kittens, adult cats, and senior cats. This manual provides essential information for assembly, usage, maintenance, and safety to ensure a long-lasting and enjoyable experience for your pets.

SAFETY INFORMATION

- **Regular Inspection:** Check the stability of all screws and connections at least once a month. Tighten any loose parts immediately to prevent accidents.
- **Placement:** Place the cat tree on a flat, stable surface. Avoid placing it near windows without screens or other potential hazards.
- **Anti-Tip Kit:** Utilize the included anti-tip kit to secure the cat tree to a wall, especially if you have active or large cats. This significantly enhances stability.
- **Supervision:** While the cat tree is designed for safety, supervise your pets during their initial use to ensure they adapt safely to the structure.
- **Damage:** If any part of the cat tree becomes damaged, discontinue use and replace the affected components to ensure your pet's safety.

PACKAGE CONTENTS

Before assembly, ensure all components are present. The package includes:

- Base plate (60 cm x 55 cm)
- Multiple platforms and perches
- Two spacious cat houses/caves
- Sisal scratching posts
- Plush toys (spring mouse, dangling ball, hanging mouse)

- Connecting posts and hardware (screws, bolts, Allen key)
- Anti-tip kit
- Assembly instructions

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Globlazer FC50 Cat Tree is designed to be straightforward. All necessary tools are included. Please follow the steps below:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all components are present against the package contents list.
2. **Attach Base Posts:** Secure the initial scratching posts to the large base plate using the provided screws and Allen key. Ensure they are tightly fastened.
3. **Assemble Lower Cat House:** Attach the walls and roof of the lower cat house to the base posts and platform.
4. **Add Middle Platforms and Posts:** Continue building upwards, attaching platforms and additional scratching posts as indicated in the diagram.
5. **Assemble Upper Cat House:** Construct the upper cat house, connecting it to the structure.
6. **Install Top Perch:** Secure the large, padded top perch to the uppermost posts.
7. **Attach Toys:** Hang the plush toys (spring mouse, dangling ball, hanging mouse) from the designated points on the cat tree.
8. **Final Tightening:** Once fully assembled, re-check and tighten all screws to ensure maximum stability.
9. **Install Anti-Tip Kit:** For enhanced safety, especially with active or multiple cats, use the anti-tip kit to secure the cat tree to a wall. Follow the specific instructions provided with the kit.




Image: Detailed dimensions (127cm height, 59cm base length, 55cm base width) and components of the anti-tip kit for securing the cat tree.



Corner Cat Tree

Skillfully utilizes the room corner, safe and stable



Image: Two cats utilizing the multi-level structure of the Globlazer FC50 Cat Tree, demonstrating its corner-fitting design and stability.

OPERATING INSTRUCTIONS (USAGE)

The Globlazer FC50 Cat Tree offers various features for your cat's enjoyment and well-being:

- **Scratching Posts:** Encourage your cat to use the sisal-covered posts for scratching to maintain claw health and protect your furniture.
- **Cat Houses/Caves:** The two spacious enclosed areas provide secure and private spots for resting, sleeping, or hiding, catering to shy cats.
- **Perches and Platforms:** Multiple levels and a large top perch offer elevated viewpoints for curious cats to observe their surroundings, as well as comfortable spots for lounging.
- **Play Toys:** The integrated plush toys (spring mouse, dangling ball, hanging mouse) provide interactive entertainment and stimulate your cat's hunting instincts.
- **Climbing and Jumping:** The multi-level design facilitates climbing and jumping, promoting physical activity and exercise for cats of all ages and sizes.



Two Large Caves

Perfect for Multi-Cats Household



Image: Two cats comfortably resting within the spacious double-layer caves, highlighting the dimensions (30cm and 40cm width, 80cm height for the lower cave entrance).



Perchoir supérieur
très grand



tement
en
uche
oux




Image: A cat lounging on the extra-large, plush top perch, demonstrating its ample space for relaxation.



Plus d'endroits confortables

Gérez facilement tous les instincts et besoins de votre chat



Poteaux à gratter pour chat



Jouet souris à ressort



Balle suspendue



Jouet souris suspendu

Image: A cat actively scratching a sisal post, with an inset showing the spring mouse toy, dangling ball, and hanging mouse toy.

MAINTENANCE

Proper maintenance ensures the longevity and hygiene of your cat tree:

- **Cleaning:** The plush surface can be machine washed at a low temperature or wiped with a damp cloth. Avoid harsh chemicals that may be harmful to pets.
- **Indoor Use:** This cat tree is designed for indoor use only. Exposure to outdoor elements can damage the materials and compromise stability.
- **Vacuuming:** Regularly vacuum the plush surfaces to remove loose fur and dust.
- **Toy Replacement:** Inspect the hanging toys periodically for wear and tear. Replace them if they become damaged to prevent choking hazards.

TROUBLESHOOTING

If you encounter any issues with your Globlazer FC50 Cat Tree, refer to the following common solutions:

- **Instability:** If the cat tree feels wobbly, re-check all screw connections and tighten them. Ensure the base is on a flat, even surface. Verify the anti-tip kit is correctly installed and secured to the wall.
- **Parts Missing/Damaged:** If any parts are missing or damaged upon arrival, contact customer support immediately for assistance.
- **Cat Not Using Tree:** Introduce your cat to the tree gradually. Place treats or familiar toys on different levels. Catnip can also be used to attract them. Ensure the tree is placed in an area your cat frequently visits.
- **Scratching Furniture Instead of Posts:** Gently redirect your cat to the sisal posts when they scratch furniture. You can use catnip spray on the posts or place treats near them to encourage use.

SPECIFICATIONS

Feature	Detail
Model Name	FC50
Brand	Globlazer
Color	Beige
Dimensions (L x W x H)	60 cm x 40 cm x 127 cm
Weight	11 Kilograms
Material	Engineered Wood, Plush, Sisal
Number of Levels	3
Special Features	Spacious Caves, Large Cat House, Plush Toys, Sisal Scratching Columns
Recommended Pet Type	Cat
Recommended Race Size	Large, Medium, Giant
Mounting Type	Floor Mount

WARRANTY AND SUPPORT

Globlazer products are manufactured to high-quality standards. For any questions, concerns, or warranty claims regarding your FC50 Cat Tree, please contact Globlazer customer support through your retailer or the official Globlazer website. Please retain your proof of purchase for warranty purposes.