

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Merax](#) /

› [Merax 6-Drawer Wood Dresser Instruction Manual \(Model WF319354\)](#)

## Merax WF319354

# Merax 6-Drawer Wood Dresser Instruction Manual

Model: WF319354

## 1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Anti-Tip Device:** This dresser is equipped with an anti-tip device. It is crucial to install this device securely to a wall to prevent accidental tipping, which can cause serious injury or death.
- **Weight Limit:** Do not exceed the recommended weight limit for each drawer or the top surface. Overloading can compromise stability and structural integrity.
- **Children Safety:** Do not allow children to climb on or play with the dresser. Keep small parts and assembly hardware out of reach of children.
- **Level Surface:** Always place the dresser on a flat, level surface to ensure stability.

## 2. PACKAGE CONTENTS

Before beginning assembly, ensure all parts and hardware are present. Refer to the included parts list in your package. If any items are missing or damaged, contact customer support.

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts, sides, backs, bottoms)
- Metal mirrored legs
- Drawer slides and hardware
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tip kit
- Assembly tools (e.g., Allen wrench)

## 3. SETUP AND ASSEMBLY

Assembly is required for this dresser. It is recommended to have two people for assembly, which may take several hours. Follow the step-by-step instructions provided in your package. Ensure all connections are tight before use.

## Assembly Tips:

- Clear a spacious area for assembly.
- Lay out all parts and hardware and identify them using the parts list.
- Do not overtighten screws to avoid damaging the wood.
- Install the anti-tip device as the final step to secure the dresser to a wall.



Image: The Merax 6-Drawer Wood Dresser in its assembled state, showcasing its modern design and grey finish.

# 6 Drawers



Image: The dresser with its six drawers partially open, illustrating the storage capacity and drawer mechanism.

## 4. OPERATING INSTRUCTIONS

The Merax 6-Drawer Wood Dresser is designed for convenient storage in bedrooms, living rooms, or home offices.

- **Drawer Use:** Gently pull and push the drawers using the integrated mirrored handles. Avoid forcing drawers open or closed.
- **Weight Distribution:** Distribute items evenly within drawers to prevent strain on the drawer slides and maintain balance.
- **Top Surface:** The top surface can be used for decorative items or frequently accessed belongings. Ensure items placed on top do not exceed the dresser's stability limits.



Image: The Merax dresser positioned in a bedroom, demonstrating its functional and aesthetic integration with other furniture.

## 5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Mirrored Surfaces:** Clean mirrored legs and handles with a glass cleaner and a soft, lint-free cloth.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood material.
- **Hardware:** Periodically check and tighten all assembly hardware to ensure the dresser remains stable.

## 6. TROUBLESHOOTING

If you encounter issues with your dresser, refer to the following common solutions:

- **Drawers not sliding smoothly:** Check if drawer slides are properly aligned and free of obstructions. Ensure all screws on the slides are tightened.
- **Dresser feels wobbly:** Verify that the dresser is on a level surface. Re-tighten all assembly hardware. Ensure the anti-tip device is securely installed.
- **Holes not aligning during assembly:** Double-check the orientation of the panels according to the assembly instructions. Sometimes, a slight adjustment or loosening of adjacent screws can help align parts.
- **Damaged parts:** If any parts arrived damaged, do not proceed with assembly. Contact customer support for replacements.

## 7. SPECIFICATIONS

Detailed product specifications for the Merax 6-Drawer Wood Dresser.

<b>Brand</b>	Merax
<b>Model Number</b>	WF319354
<b>Product Dimensions (D x W x H)</b>	17.7" x 47.2" x 30.3"
<b>Color</b>	Grey
<b>Material</b>	Metal, Wood (MDF)
<b>Number of Drawers</b>	6
<b>Item Weight</b>	135 Pounds
<b>Assembly Required</b>	Yes
<b>UPC</b>	196986684966



Image: A diagram illustrating the precise dimensions of the Merax 6-Drawer Wood Dresser, including depth, width, and height.

## 8. WARRANTY AND SUPPORT

Merax products are manufactured with quality and care. For specific warranty details, please refer to the warranty information included with your purchase or visit the official Merax website.

For customer support, missing parts, or technical assistance, please contact Merax customer service through their official channels. You can often find contact information on the packaging or the brand's website.

Visit the [Merax Store on Amazon](#) for more products and information.

© 2025 Merax. All rights reserved.