

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TEEVOGO](#) /

› [TEEVOGO Handheld Steam Cleaner SG-SC201 User Manual](#)

TEEVOGO SG-SC201

TEEVOGO Handheld Steam Cleaner SG-SC201 User Manual

Model: SG-SC201 | Brand: TEEVOGO

1. INTRODUCTION

Thank you for choosing the TEEVOGO Handheld Steam Cleaner SG-SC201. This device is designed to provide efficient and chemical-free cleaning for various surfaces in your home. It features a rapid 15-second heat-up time, delivers high-temperature steam up to 230°F, and includes a 650ml water tank for extended cleaning sessions. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not direct steam at people, pets, or electrical appliances. Steam is extremely hot and can cause burns.
- Ensure the appliance is unplugged before filling or emptying the water tank, or when not in use.
- Use only clean tap water. Do not add cleaning solutions, perfumes, or other chemicals to the water tank, as this can damage the appliance and void the warranty.
- Keep the appliance out of reach of children and pets.
- The steam cleaner is equipped with an automatic shut-off feature that activates when the water tank is empty to prevent overheating.
- Always ensure attachments are securely fastened before operating the steam cleaner.
- Do not operate the appliance if the cord or plug is damaged.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- TEEVOGO Handheld Steam Cleaner Main Unit
- 1 x Nylon Brush
- 1 x Grout Brush
- 1 x Ironing Cloth
- 1 x Extension Hose and Nozzle (Note: The extension hose is located at the back of the foam box packaging. Please check carefully.)
- 1 x Accessory Nozzle
- 1 x Bent Nozzle
- 1 x Scraper
- 1 x Window Squeegee
- 1 x Measuring Cup
- 1 x Funnel
- 1 x Scouring Pad Brush
- 1 x User Manual



Image: The TEEVOGO Handheld Steam Cleaner main unit shown with all 12 included accessories, such as brushes, nozzles, squeegee, and measuring cup.



Image: A visual representation of the various cleaning accessories, including the accessory nozzle, round brush, grout brush, scraper, extended hose, scouring pad brush, squeegee, and bent nozzle.



Image: The extension hose is securely placed within a dedicated compartment in the product's foam packaging for protection during shipping.

4. PRODUCT OVERVIEW

Familiarize yourself with the main components of your TEEVOGO Handheld Steam Cleaner:

- **Main Unit:** Contains the water tank, heating element, and control panel.
- **Nozzle:** Where steam is emitted. Various attachments connect here.
- **Water Tank:** Transparent reservoir for water, with a 650ml capacity.
- **Control Panel:** Features intuitive touch controls for power and steam intensity adjustment.
- **Power Cord:** Connects the unit to an electrical outlet.

5. SETUP AND ASSEMBLY

1. **Fill the Water Tank:** Ensure the steam cleaner is unplugged. Open the water tank cap. Use the provided measuring cup and funnel to fill the 650ml water tank with clean tap water. Do not overfill. Close the cap securely.
2. **Attach Desired Accessory:** Select the appropriate cleaning attachment for your task. Align the attachment with the main nozzle and twist it clockwise until it locks securely into place.
3. **Connect to Power:** Plug the power cord into a standard 110V electrical outlet.



Image: Instructions demonstrating the simple insert and twist motion required to securely attach cleaning accessories to the steam cleaner.


6. OPERATING INSTRUCTIONS

1. **Power On and Heat Up:** Once plugged in, the steam cleaner will begin heating. It reaches operating temperature (230°F) in approximately 15 seconds. An indicator light will signal when it's ready for use.
2. **Adjust Steam Intensity:** Use the intuitive touch control function on the handle to adjust the steam intensity. A gentle tap allows you to cycle through different steam levels.
3. **Begin Cleaning:** Direct the nozzle towards the surface you wish to clean. Press the steam trigger to release continuous steam. The large 650ml tank provides up to 35 minutes of continuous steam, allowing you to clean large areas without frequent refills.
4. **Pause Function:** For convenience and safety, the steam cleaner features a pause button. Simply tap it to temporarily stop steam emission, freeing your thumb and providing instant peace of mind, especially when children or pets are nearby.
5. **Cleaning Various Surfaces:** The TEEVOGO steam cleaner is effective on a wide range of surfaces including kitchen counters, stovetops, sinks, bathroom tiles, grout lines, windows, upholstery, and more. Always test on an inconspicuous area first.
6. **Chemical-Free Cleaning:** This steam cleaner uses only water, eliminating the need for harsh chemicals. This makes it ideal for sanitizing homes with children and pets, effectively breaking down grease, grime, and sticky messes.



Image: A visual representation highlighting the steam cleaner's rapid 15-second heat-up capability, indicating minimal waiting time before use.

**GREASE
GRIME?
GONE!**



**Removes Stubborn
Grease and Grime**

See the Difference Instantly!

Image: A user effectively removing stubborn grease and grime from a stovetop using the handheld steam cleaner, demonstrating its cleaning power.

CHEMICAL FREE CLEANING

99%
STERILIZATION



“
**BORN FROM STEAM
GUARDED BY PURITY**

↓
**THAT'S SAFE FOR KIDS, PETS
AND YOUR WHOLE HOME.**

”

Image: A user cleaning with the steam cleaner in a home environment with pets, illustrating the chemical-free and safe nature of the cleaning process.

STEAM CLEAN

Eliminates Hidden Bacteria Effectively



FROM TOXIC TRACES
ABSOLUTE PURITY ^{to}



General Clean
Bacteria still remain on surfaces

Image: The steam cleaner effectively sanitizing a sink faucet, demonstrating its ability to eliminate hidden bacteria and achieve a high level of purity compared to general cleaning methods.



Image: The steam cleaner's 650ml water tank, highlighting its capacity to provide up to 35 minutes of continuous steam for extensive cleaning tasks.



Image: The steam cleaner's pause button feature, designed for instant steam cessation, offering enhanced safety and control, especially when children are nearby.




Image: A visual comparison showing a dirty bathroom sink before and after cleaning with the steam cleaner, illustrating its effectiveness in removing grime and restoring cleanliness.

7. MAINTENANCE AND STORAGE

1. **Empty Water Tank:** After each use, ensure the unit is unplugged and cooled down. Carefully open the water tank cap and empty any remaining water.
2. **Clean Accessories:** Rinse all attachments with clean water and allow them to air dry completely before storing.
3. **Wipe Down Unit:** Wipe the main unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Descaling (Optional):** If you notice reduced steam output or mineral buildup, you may need to descale the unit. Consult the manufacturer's website for specific descaling instructions.
5. **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output	Water tank is empty Unit not heated sufficiently Nozzle or attachment is blocked	Refill water tank Allow 15 seconds for heat-up; wait for indicator light Clean nozzle/attachment; ensure no mineral buildup
Water leakage from nozzle	Attachment not securely fastened Overfilling water tank	Ensure attachment is twisted and locked into place Do not fill water tank beyond the maximum line
Unit automatically shuts off	Water tank is empty (overheat protection)	Unplug the unit, allow it to cool, then refill the water tank

9. SPECIFICATIONS

Brand: TEEVOGO

Model Name: SG-SC201

Wattage: 1200 watts

Voltage: 110V

Tank Volume: 650 Milliliters

Heat Time: 15 Seconds

Maximum Temperature: 230 Degrees Fahrenheit

Item Weight: 4.73 pounds

Product Dimensions: 3.35"D x 11.02"W x 8.67"H

Power Source: Corded Electric

Power Cord Length: 9.8 feet

UPC: 850063752787

Special Features: 15s Fast Heat Up, Powerful & High-pressure Steamer, Multi-surface Cleaning, Safe for Children & Pets, 650ml Large Water Tank, Dry Burning Auto Turn-off, Steam Control, Touch Screen.



Image: A user demonstrating the flexibility provided by the steam cleaner's 9.8-foot power cord, allowing for extended reach during cleaning tasks.

10. WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your product at the time of purchase.

Warranty terms and conditions may vary.

If you encounter any issues or have questions regarding your TEEVOGO Handheld Steam Cleaner, please contact the seller or manufacturer's customer support for assistance. Contact details are typically provided on the product packaging or the official brand website.