

AYJOIR JY-T12

AYJOIR 7-in-1 Folding Kids Trike

Model: JY-T12

[Safety Information](#) [Product Overview](#) [Assembly](#) [Operating](#)
[Modes](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. IMPORTANT SAFETY INFORMATION

Please read this entire manual before assembly and use of the AYJOIR 7-in-1 Folding Kids Trike. Failure to follow these instructions may result in serious injury to your child.

- Always supervise children when using the trike.
- Ensure all parts are securely fastened before each use.
- The 3-point safety harness must always be used to secure the child.
- Do not exceed the maximum weight capacity of 50 lbs (22.7 kg).
- Keep hands and feet clear of moving parts.
- Avoid using the trike on uneven surfaces, near stairs, or in traffic.
- Regularly check for loose screws, worn parts, or damage. Discontinue use if any damage is found.
- The rear wheel stopper should be engaged when the trike is stationary to prevent accidental movement.

Rear Wheel Stopper

Ensures safety by preventing the vehicle from moving on slopes or if a child accidentally tries to move it




Figure 1.1: Rear Wheel Stopper. This image illustrates the rear wheel stopper mechanism, showing both the locked and free modes. The stopper ensures the trike remains stationary when needed, preventing unintended movement.

2. PRODUCT OVERVIEW

The AYJOIR 7-in-1 Folding Kids Trike is a versatile mobility solution designed to adapt to your child's growth from 12 months to 6 years old. It transitions through various modes by adjusting or removing components, offering a long-lasting and functional design.

2.1. 7-in-1 Modes

This trike offers seven configurations to suit different developmental stages:

1. **Facing Forward (6-12 months):** Parent-controlled mode with child facing forward.
2. **Tricycle (1-2 years):** Parent-controlled mode with child facing forward, using pedals.
3. **With Safety Guard (2-3 years):** Child-controlled tricycle with safety guard.
4. **With Push Bar (2-3 years):** Child-controlled tricycle with parent push bar for assistance.

5. **Tricycle (3-4 years):** Independent child-controlled tricycle.
6. **Running Bike (4-5 years):** Balance bike mode with pedals removed.
7. **Bicycle (5-6 years):** Independent bicycle mode.



Figure 2.1: 7-in-1 Trike Modes. This diagram visually represents the seven different configurations of the trike, detailing the recommended age range for each mode, from parent-controlled to independent riding.

2.2. Key Features

- **Durable Aluminum Frame:** Supports up to 50 lbs.
- **3-Point Safety Harness:** Ensures child security.
- **Adjustable Canopy:** Multi-level deployment for sun protection, removable for storage.
- **135-Degree Rotatable & Detachable Push Handle:** Allows parent control and adjusts for height.
- **Quick Fold Design:** Compact storage and easy transport.
- **Lightweight:** Weighs approximately 13 lbs.
- **Storage Bag:** Convenient for carrying essentials.

- **Comfortable Cushion:** Ergonomically designed seat for comfort.
- **Foldable Footrests:** Provides support for younger riders.
- **Polyurethane Wheels:** Suitable for various terrains, shockproof.

Full of Features



Figure 2.2: Detailed Features. This image provides a close-up view of the trike's components, including the control bar, safety harness, storage bag, comfortable seat, durable wheels, folding footrests, and adjustable handle.

Thoughtful Features



Figure 2.3: Thoughtful Features. This composite image highlights key comfort and safety features: the extended sun canopy, foldable footrests, a comfortable seat cushion, and the secure 3-point harness.

3. ASSEMBLY INSTRUCTIONS

The AYJOIR 7-in-1 Folding Kids Trike requires minimal assembly. Please follow the steps below and refer to the official product video for visual guidance.

3.1. Unboxing and Component Check

Carefully remove all components from the packaging. Verify that all parts listed in the packing list are present. The main components include the trike frame, wheels, seat, canopy, push handle, and safety guard.

3.2. Attaching Wheels

Attach the front and rear wheels to the main frame. Ensure they click securely into place. Some models may require pressing a button to insert or remove pedals from the front wheel.

3.3. Installing the Seat and Safety Guard

Mount the seat onto the frame. Secure the safety guard around the seat if applicable for the chosen mode. Ensure the 3-point harness is accessible and functional.

3.4. Attaching the Push Handle and Canopy

Insert the adjustable push handle into its designated slot at the rear of the trike. Attach the canopy to the seat back. Adjust the canopy for desired sun protection.

3.5. Assembly Video Guide

For a detailed visual guide on assembly and component adjustments, please watch the official product video below.

Your browser does not support the video tag.

Video 3.1: AYJOIR 7-in-1 Folding Kids Trike Assembly and Features. This video provides a comprehensive demonstration of the trike's assembly process, various modes, and key features, including how to remove pedals and adjust components.

4. OPERATING INSTRUCTIONS

4.1. Switching Between Modes

The trike's versatility allows for easy conversion between its 7 modes. This typically involves removing or adjusting the canopy, push handle, safety guard, and pedals. Refer to the assembly video for specific steps on component removal and attachment.

4.2. Adjusting the Push Handle

The parent push handle is height-adjustable to accommodate different users. Locate the adjustment mechanism on the handle stem, typically a button or lever, and adjust to a comfortable height. The handle can also be rotated 135 degrees for steering control or detached when the child is ready for independent riding.

4.3. Using the Safety Harness

Always secure your child with the 3-point safety harness. Adjust the straps to ensure a snug fit without being too tight. The harness prevents the child from slipping or falling out of the seat.

4.4. Engaging the Rear Wheel Stopper

When the trike is stationary, or when loading/unloading your child, engage the rear wheel stopper. This prevents the trike from rolling. Push down on the lever located near the rear wheels to lock them. Lift the lever to release.

4.5. Folding for Storage

The trike features a quick-fold mechanism for compact storage and transport. Locate the folding latches or buttons on the frame (refer to the assembly video for exact locations). Engage these mechanisms to fold the trike. Ensure all components are properly aligned before folding to prevent damage.

Upgraded Storage Function



Figure 4.1: Quick Fold and Storage. This image sequence demonstrates how to quickly fold the trike for compact storage, showing it fitting into a car trunk and a small closet, highlighting its portability.

ADJUSTABLE CANOPY

For easy storage,
you could remove and fold it



Figure 4.2: Adjustable and Removable Canopy. This image illustrates the adjustable canopy and how it can be easily removed and folded for convenient storage or when not needed.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your AYJOIR 7-in-1 Folding Kids Trike.

- **Cleaning:** Wipe down the frame and plastic parts with a damp cloth and mild soap. Avoid harsh chemicals. The fabric canopy and seat cushion can be spot cleaned.
- **Inspection:** Periodically check all screws, bolts, and fasteners to ensure they are tight. Inspect wheels for wear and tear. Ensure the safety harness and buckles are in good working condition.
- **Storage:** When not in use, store the trike in a dry, cool place away from direct sunlight and extreme temperatures. Utilize its folding feature for compact storage.
- **Lubrication:** Moving parts, such as wheel axles or folding mechanisms, may benefit from occasional light lubrication with a silicone-based spray to ensure smooth operation.

6. TROUBLESHOOTING

If you encounter any issues with your AYJOIR 7-in-1 Folding Kids Trike, refer to the common solutions below:

Problem	Possible Cause	Solution
Trike does not roll smoothly.	Wheels are dirty or obstructed; axles need lubrication.	Clean wheels and remove any debris. Apply a small amount of silicone lubricant to the axles.
Push handle feels loose.	Adjustment mechanism not fully engaged; screws are loose.	Ensure the height adjustment mechanism is locked. Check and tighten any visible screws on the handle assembly.
Trike does not fold correctly.	Folding latches not fully disengaged/engaged; components obstructing the fold.	Ensure all folding latches are properly released. Check for any attached accessories (e.g., storage bag) that might be blocking the fold.
Safety harness is difficult to buckle/unbuckle.	Buckle is dirty or damaged.	Clean the buckle mechanism. If damaged, contact customer support for replacement parts.

7. SPECIFICATIONS

Detailed specifications for the AYJOIR 7-in-1 Folding Kids Trike, Model JY-T12.

- **Model Number:** JY-T12
- **Brand:** AYJOIR
- **Material:** Aluminum frame
- **Recommended Age:** 12 months to 6 years (5 to 72 months)
- **Maximum Weight Capacity:** 50 lbs (22.7 kg)
- **Item Weight:** Approximately 13.8 lbs (6.26 kg)
- **Dimensions (L x W x H):** 27.9" x 19.3" x 39.8" (70.9 cm x 49 cm x 101.1 cm)
- **UPC:** 786353505286
- **Assembly Required:** Yes

Size Unit: IN





Figure 7.1: Product Dimensions. This diagram provides detailed measurements of the trike in inches, illustrating its overall size and the dimensions of key components like the canopy, push handle, and wheel base.

8. WARRANTY AND CUSTOMER SUPPORT

AYJOIR is committed to providing high-quality products. For specific warranty information, please refer to the documentation included with your purchase or contact the retailer.

8.1. Customer Support

If you have any questions, require assistance with assembly, or need replacement parts, please contact AYJOIR customer support through the retailer's platform or the official AYJOIR website. Please have your model number (JY-T12) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question