Benass 10X12 FT Outdoor Storage Shed

Benass 10x12 FT Outdoor Storage Shed Instruction Manual

Model: 10X12 FT Outdoor Storage Shed

1. Important Safety Information

Please read and understand all instructions before beginning assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Assembly:** This shed requires assembly by 2-4 adults. Do not attempt to assemble alone.
- **Anchoring:** Ensure the shed is properly anchored to the ground to withstand environmental conditions. The shed is designed to withstand winds up to 24-30 mph and snow loads up to 6 inches.
- **Children and Pets:** Keep children and pets away from the assembly area and ensure they do not play inside or around the shed unsupervised.
- **Ventilation:** The shed features convection vents. Do not block these vents to ensure proper air circulation.
- **Sharp Edges:** Metal components may have sharp edges. Wear protective gloves during assembly.

2. Package Contents

Before starting assembly, verify that all parts are present and undamaged. Refer to the detailed parts list provided in your separate assembly guide. The shed is delivered in 3 boxes, which may arrive on different days.

The package includes:

- Galvanized steel panels and frame components
- Mounting gloves for protection during assembly
- Moisture-proof floor mat
- Sensor solar lights
- Leaf bag
- Door locks and hardware

- Detailed installation instructions



Image: Visual representation of the items included in the Benass 10x12 FT Outdoor Storage Shed package.




Image: Illustration indicating that the shed components are shipped in three separate boxes, which may arrive on different days.

3. Setup and Assembly

Follow the detailed step-by-step instructions provided in the separate assembly manual. All parts are labeled with numbers for easy identification.

3.1 Site Preparation

- Choose a level and stable surface for installation.
- Clear the area of any debris, rocks, or vegetation.
- Ensure adequate space around the shed for assembly and future access.

3.2 Assembly Steps Overview

1. Unpack all components and verify against the parts list.
2. Assemble the base frame according to the instructions.
3. Attach the wall panels, ensuring proper alignment and secure fastening.

4. Install the roof structure and panels, paying attention to the sloped design for water runoff.
5. Mount the doors and install the lockable mechanisms.
6. Install the convection vents and solar lights.
7. Anchor the shed securely to the ground using appropriate methods for your chosen site.



Image: Product dimensions for the Benass 10x12 FT Outdoor Storage Shed, illustrating overall measurements.



Image: Detailed view of structural features such as plastic screw sleeves, convection vents, roof protection corners, and reinforced door structure.

4. Operation

Your Benass 10x12 FT Outdoor Storage Shed is designed for versatile storage and ease of use.

4.1 Storage Capacity

The shed offers approximately 840 cubic feet of storage space, suitable for a variety of items including:

- Garden tools (shovels, lawnmowers, rakes)
- Outdoor equipment (bikes, tents, grills)
- Seasonal decorations
- Recycling bins



Image: Examples of multi-purpose use for the shed, including tool storage, general storage, and housing for pets or waste bins.



Image: Visual guide to the types of tools and equipment suitable for storage within the shed.

4.2 Access and Security

- The shed features lockable doors for enhanced security of your stored items. Ensure doors are properly closed and locked when not in use.
- The included sensor solar lights provide illumination for easy access during low-light conditions.



Image: The shed at night, demonstrating the functionality of the solar-powered sensor lights for visibility and security.

4.3 Ventilation

The unique convection four-vent design (two on the front, two on the rear) improves internal air circulation, helping to prevent moisture buildup and odors.



Image: Illustration of the bi-directional convection vents, demonstrating how they facilitate air circulation within the shed.

5. Maintenance

Regular maintenance will ensure the longevity and optimal performance of your Benass storage shed.

- **Cleaning:** The galvanized steel surfaces are easy to clean. Use a mild soap and water solution with a soft cloth or brush. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Rust Prevention:** The shed is constructed from thickened galvanized steel with an anti-rust treatment, providing excellent protection against corrosion. Periodically inspect for any signs of wear or damage to the coating and address promptly.
- **Waterproofing:** The shed is designed to be waterproof. The sloped roof prevents rainwater accumulation. Ensure all seams and fasteners remain tight to maintain water resistance.
- **Snow Load:** In areas with heavy snowfall, regularly clear snow from the roof to prevent exceeding the maximum allowable snow thickness of 6 inches.
- **Ventilation:** Keep the convection vents clear of obstructions (e.g., leaves, debris) to ensure continuous air circulation.




Image: Detailed view of the special galvanized steel construction, emphasizing its solid structure, ease of cleaning, wind protection, and water resistance.



Image: The shed demonstrating its high load capacity and wind resistance under snowy conditions.

6. Troubleshooting

If you encounter any issues during the installation or use of your Benass storage shed, please refer to the following general advice:

- **Missing Parts:** Double-check the package contents against the parts list in the assembly manual. If parts are genuinely missing, contact customer support.
- **Assembly Difficulties:** Review the assembly instructions carefully. Ensure all components are oriented correctly. Do not force parts together. If a step is unclear, refer to the support section for assistance.
- **Water Leakage:** Inspect all roof and wall panel seams, as well as around doors and vents, for proper sealing and tight fasteners. Ensure the shed is level and the roof slope is effective for water runoff.
- **Door Malfunction:** Check that the door tracks are clear of debris and that the doors are properly aligned. Lubricate hinges if necessary.

For specific problems not covered here, please contact Benass customer support.

7. Specifications

Brand	Benass
Model	10X12 FT Outdoor Storage Shed
Material	Alloy Steel (Galvanized)
Color	Brown
Product Dimensions (D x W x H)	86.5" x 145" x 86.5"
Storage Capacity	Approx. 840 cubic feet
Water Resistance Level	Waterproof
Maximum Wind Rating	6 (24-30 mph)
Maximum Allowable Snow Thickness	6 inches
Assembly Required	Yes (2-4 adults recommended)

8. Warranty Information

Specific warranty details are not provided within this instruction manual. For information regarding the product warranty, please refer to your purchase documentation or contact Benass customer support directly.

9. Customer Support

If you have any questions, require assistance with assembly, or encounter any issues with your Benass 10x12 FT Outdoor Storage Shed, please do not hesitate to contact our customer support team.

- **Manufacturer:** Benass World
- **Online Store:** Visit the Benass Store on Amazon for more information and contact options.

Please have your model number (10X12 FT Outdoor Storage Shed) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question