

**Bugaboo 8717447366379**

## Bugaboo Butterfly 2 Travel Stroller

Model: 8717447366379 | Brand: Bugaboo

### INTRODUCTION

Welcome to the Bugaboo Butterfly 2 Travel Stroller user manual. This guide provides essential information for the safe and effective use, setup, operation, and maintenance of your new stroller. The Bugaboo Butterfly 2 is designed for ultimate convenience, featuring an ultra-compact one-second fold, making it lightweight and airplane-friendly. It offers superior comfort for your child and ease of use for parents on the go.



Image: The Bugaboo Butterfly 2 Travel Stroller in its upright position, showcasing its sleek design and green fabric.

## SAFETY INFORMATION

Always prioritize your child's safety. Read and understand all instructions before using the stroller. Failure to follow these instructions could result in serious injury.

- **Never leave your child unattended** in the stroller.
- Always use the **5-point harness system** to secure your child. Ensure it is correctly adjusted and fastened.
- Engage the **brake system** whenever the stroller is stationary.
- Do not overload the stroller. Adhere to the maximum weight recommendations for the seat and storage basket. The maximum weight recommendation for the child is 48.5 pounds, and for the storage basket, it is 17.64 pounds.
- Ensure all locking devices are engaged before use.
- Keep children clear of moving parts when making adjustments.

- This stroller is suitable for children from 0 to approximately 48 months. For newborns, a compatible car seat (with adapters) is recommended for optimal comfort and safety.

## SETUP

### Unpacking and Initial Inspection

Carefully remove all components from the packaging. Inspect the stroller for any signs of damage or missing parts. If any issues are found, do not assemble or use the stroller, and contact Bugaboo customer support immediately.

### Unfolding the Stroller

The Bugaboo Butterfly 2 features a convenient one-second unfold mechanism. Follow these steps:

1. Place the folded stroller on a flat, stable surface.
2. Locate the release button/handle on the handlebar.
3. Press the button and lift the handlebar firmly upwards. The stroller frame will automatically extend and lock into place.
4. Ensure all parts are securely locked before placing a child in the stroller. You will hear an audible click when the frame is fully engaged.



Image: A visual sequence demonstrating the one-second unfolding process of the Bugaboo Butterfly 2 stroller, showing it transform from a compact fold to a fully open position.

## OPERATING THE STROLLER

### Folding the Stroller

To fold the Bugaboo Butterfly 2 for compact storage or travel, follow these steps:

1. Ensure the child is removed from the stroller.
2. Engage the brake.
3. Locate the folding mechanism on the handlebar.
4. Press the release button and push the handlebar downwards. The stroller will collapse into its ultra-compact folded state.
5. The stroller is designed to stand independently when folded.



Image: The Bugaboo Butterfly 2 stroller shown in its folded, compact state, with dimensions indicating its small footprint for travel and storage.

Our most sustainable stroller, using bio-based material and recycled aluminum

One-second compact fold and unfold

IATA carry-on compliant for overhead bins

From newborn to 50 lbs

Fully upright seat, and one hand adjustable integrated footrest

Spacious under seat basket, and back pocket

Larger wheels for a smoother ride

Car seat compatible  
(car seat adapters required)

Image: An infographic highlighting key features of the Bugaboo Butterfly 2, including its one-second compact fold, spacious underseat basket, adjustable footrest, and IATA carry-on compatibility.

## Harness System

The stroller is equipped with a 5-point adjustable harness. To secure your child:

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
3. Insert the buckle prongs into the central buckle until they click securely.
4. Adjust the straps to ensure a snug, comfortable fit, allowing no more than one finger to fit between the strap and your child's body.

## Seat Recline and Footrest Adjustment

The seat offers multiple recline angles, including a fully upright position, and features an adjustable footrest for growing children.

- To recline the seat, locate the recline mechanism behind the seat and adjust to the desired position.
- To adjust the footrest, use the lever or buttons located near the footrest to raise or lower it.

## **Brake System**

The stroller is equipped with a foot-operated brake system.

- To engage the brake, press down firmly on the brake pedal located near the rear wheels until it locks.
- To release the brake, lift the pedal upwards.
- Always ensure the brake is fully engaged when the stroller is stationary.

## **Storage Basket**

The stroller includes an extra-large underseat storage basket and a handy back storage pocket.

- The underseat basket can hold up to 17.64 pounds (8 kg) of items.
- Use the back pocket for smaller, easily accessible items.
- Do not exceed the maximum weight capacity to maintain stroller stability.





Image: A close-up view of the Bugaboo Butterfly 2's spacious underseat storage basket, filled with various items, demonstrating its capacity.

## MAINTENANCE

Regular maintenance will prolong the life of your Bugaboo Butterfly 2 stroller.

- **Cleaning Fabric:** The fabric components are made of polyester and can be machine washed. Refer to the care label for specific washing instructions. Use mild detergent and cold water. Do not bleach.
- **Frame Cleaning:** Wipe the aluminum frame with a damp cloth and mild soap. Dry thoroughly. Avoid abrasive cleaners.
- **Wheel Maintenance:** Regularly check the wheels for debris and clear any obstructions. Lubricate moving parts of the wheels and axles periodically with a silicone-based lubricant.
- **Storage:** Store the stroller in a dry, well-ventilated area, away from direct sunlight and extreme temperatures.



## TROUBLESHOOTING

If you encounter any issues with your Bugaboo Butterfly 2 stroller, please refer to the common problems and solutions below. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Stroller does not unfold/fold smoothly.	Mechanism obstructed or not fully engaged.	Ensure all release points are pressed simultaneously. Check for any fabric or debris obstructing the folding mechanism. Apply a small amount of silicone lubricant to moving joints if stiff.
Wheels squeak or are difficult to turn.	Dirt/debris in wheel bearings or lack of lubrication.	Clean wheels and axles thoroughly. Apply silicone lubricant to the wheel axles.
Brake not engaging/disengaging properly.	Debris in the brake mechanism or misalignment.	Clear any debris from the brake pedal and mechanism. Ensure the brake pedal is fully pressed or lifted.

## SPECIFICATIONS

Feature	Detail
Brand	Bugaboo
Model Number	8717447366379
Color	Green
Material (Frame)	Aluminum
Fabric Type	Polyester
Age Range Description	0-48 Months
Item Weight	16.1 Pounds
Maximum Weight Recommendation (Child)	48.5 Pounds
Basket Weight Capacity Maximum	17.64 Pounds
Folded Size (H x W)	Approx. 21.26" x 9.06"
Unfolded Dimensions (L x W x H)	37.2"L x 17.64"W x 40.47"H
Included Components	Storage basket
Harness Type	5 Point
Stroller Type	Umbrella Stroller

Feature	Detail
Car Seat Compatible	Yes (adapters required)

## WARRANTY AND SUPPORT

Bugaboo offers a comprehensive warranty for your Butterfly 2 Travel Stroller.

- **Standard Warranty:** Your stroller comes with a standard warranty.
- **Extended Warranty:** Register your product to receive a free extended 4-year warranty, effectively doubling your coverage. Product registration details can typically be found on the Bugaboo official website or through the included product registration card.
- For technical support, spare parts, or warranty claims, please visit the official Bugaboo website or contact their customer service department. Keep your proof of purchase and model number handy when contacting support.