

[Manuals.plus](#) /

> [Vicco](#) /

> Vicco Claus Wardrobe, White, Model 26974 - Instruction Manual

Vicco 26974

Vicco Claus Wardrobe (Model 26974) - Instruction Manual

White, 111x191.5cm with 6 Doors

INTRODUCTION

This instruction manual provides important information for the safe and correct assembly, use, and maintenance of your new Vicco Claus Wardrobe. Please read this manual thoroughly before beginning assembly and keep it for future reference.

SAFETY INFORMATION

Important! Retain for future reference. Read carefully!

TIPPING HAZARD!

Unanchored furniture can tip over. To prevent this furniture from tipping, it **must be anchored to the wall**. Use appropriate mounting hardware for your home's walls. If you have questions, consult your local specialized dealer. Please follow each step of the instructions carefully during assembly.

PACKAGE CONTENTS

Your Vicco Claus Wardrobe package includes:

- Wardrobe components (as illustrated)
- Assembly instructions
- Mounting hardware

Please note that decorations shown in product images are not included.

ASSEMBLY INSTRUCTIONS

Assembly of the Vicco Claus Wardrobe requires careful attention to detail. We recommend two people for assembly.

1. **Unpack and Verify:** Carefully unpack all components and check them against the parts list provided in the separate assembly instructions. Ensure all parts are present and undamaged.
2. **Prepare Workspace:** Assemble the wardrobe on a clean, flat, and soft surface to prevent scratches.

3. **Follow Instructions:** Refer to the detailed assembly instructions provided in your package. Follow each step sequentially. Pay close attention to diagrams and hardware usage.
4. **Secure Connections:** Ensure all screws, dowels, and connectors are tightened securely, but do not overtighten to avoid damaging the particle board.
5. **Wall Anchoring:** Once assembled, it is crucial to anchor the wardrobe to a solid wall using the provided anti-tip hardware. This prevents accidental tipping and ensures safety. Choose appropriate wall plugs for your wall type (not always included).

Note: Some users have reported that assembly can be challenging. Take your time, carefully review each step, and do not hesitate to seek assistance if needed.

PRODUCT OVERVIEW & DIMENSIONS

The Vicco Claus Wardrobe is a versatile storage solution featuring 6 swing doors, offering ample space for clothing and accessories. It includes a clothes rail and multiple shelves for organized storage.



Figure 1: Assembled Vicco Claus Wardrobe, white, with 6 doors in a room setting.



Figure 2: Dimensional diagram of the Vicco Claus Wardrobe. Overall dimensions are approximately 111 cm (width) x 40 cm (depth) x 191.5 cm (height).



Figure 3: Interior view of the wardrobe with doors open, showing the clothes rail and various shelves.



Figure 4: Close-up detail of the interior shelving and clothes rail.

OPERATING THE WARDROBE

The Vicco Claus Wardrobe is designed for straightforward use:

- **Opening/Closing Doors:** Gently pull the door handles to open the swing doors. Push them firmly to close. Avoid slamming doors to prevent damage to hinges and the wardrobe structure.
- **Using the Clothes Rail:** Hang garments on standard hangers on the integrated clothes rail. Do not overload the rail beyond its weight capacity.
- **Adjusting Shelves:** The shelves are typically adjustable. Refer to your specific assembly instructions for details on how to reposition them using the pre-drilled holes and shelf pins. Ensure shelves are securely seated before placing items on them.
- **Weight Distribution:** Distribute weight evenly across shelves and the clothes rail. Avoid placing heavy items on the top shelves to maintain stability.

MAINTENANCE

To ensure the longevity and appearance of your Vicco Claus Wardrobe, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Dry immediately with a clean cloth. Avoid harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish.
- **Dusting:** Regularly dust the wardrobe with a soft, dry cloth.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Avoid Moisture:** Protect the wardrobe from excessive moisture and direct sunlight, which can cause warping or discoloration.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 40 kg for the entire unit. Distribute weight evenly.

TROUBLESHOOTING

If you encounter issues with your Vicco Claus Wardrobe, consider the following common solutions:

- **Difficulty Assembling:** If assembly is challenging, re-read the instructions carefully. Ensure all parts are correctly oriented and that you are using the correct hardware for each step. Sometimes, parts may appear similar but have subtle differences.
- **Instability/Wobbling:** This is often due to loose connections or improper wall anchoring. Ensure all screws are tightened and that the wardrobe is securely anchored to the wall as per the safety instructions. Check that the floor is level.
- **Damaged Parts Upon Arrival:** If any components are damaged during delivery, do not proceed with assembly. Contact the retailer or manufacturer's customer support immediately with details and photographic evidence of the damage.
- **Doors Not Aligning:** Check that the hinges are correctly installed and adjusted. Most hinges allow for minor adjustments to align doors. Refer to the assembly manual for hinge adjustment details.

If problems persist, contact customer support for further assistance.

SPECIFICATIONS

Attribute	Detail
Brand	Vicco
Model Number	26974
Color	White
Material	Engineered Wood (16 mm particle board)
Product Dimensions (L x W x H)	40 x 111 x 191.5 cm
Item Weight	80.7 Kilograms
Maximum Weight Capacity	40 Kilograms
Number of Doors	6
Type of Fastening	Floor Mount (with wall anchoring required)
Style	Modern

Door Style	Slab
Finish Type	Lacquered

WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or customer support, please refer to the purchase documentation or contact the retailer where you purchased the Vicco Claus Wardrobe. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question