Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Satechi ST-LFAWC_PAR

Satechi FindAll Wallet Card User Manual

Model: ST-LFAWC_PAR

Introduction

The Satechi FindAll Wallet Card is a smart location tracking device designed to help you keep track of your valuables using Apple's Find My network. Its ultra-slim profile allows it to fit seamlessly into wallets, bags, or other items, providing peace of mind with real-time tracking, sound alerts, and left-behind notifications. This manual provides detailed instructions on setting up, operating, and maintaining your FindAll Wallet Card.



Image: The Satechi FindAll Wallet Card, a sleek black card, shown next to a light-colored wallet, demonstrating its compact size and how it fits into a wallet.

Key Features

- **Smart Location Tracking:** Utilizes Apple's Find My technology for precise tracking of your wallet, bag, or other items.
- **Left Behind Notifications:** Receive real-time alerts on your Apple device if you leave your FindAll Card behind.
- **Sound Alert:** Trigger a loud, audible chime from the card to quickly locate misplaced items.
- **Wireless Charging:** Conveniently recharge the integrated 220mAh battery using Qi, Qi2, or MagSafe wireless chargers.
- **Long Battery Life:** Enjoy up to 16 months of use on a single charge.
- **Durable Design:** Crafted from aluminum and tempered glass with an IP66 waterproof and dust rating for enhanced durability.
- **Ultra-Thin Profile:** Credit card-sized (8.5 x 5.4 x 0.22 cm / 3.35 x 2.13 x 0.09 in) and lightweight (18gr/ 0.63oz) for seamless integration into any wallet.



Image: An overview of the Satechi FindAll Wallet Card's key features, including left-behind notifications, loud sound alerts, wireless charging, and IP66 waterproof rating. It also highlights compatibility with Apple Find My and notes it is not compatible with Android devices.

Setup

To begin using your Satechi FindAll Wallet Card, you must pair it with your iPhone or iPad using the Apple Find My app. Mac devices can locate items but cannot be used for initial setup.

Pairing Instructions:

1. **Open the 'Find My' App:** Launch the Find My application on your iPhone or iPad.
2. **Add Item:** Navigate to the 'Items' tab and tap 'Add Item'. Then, select 'Other Supported Item'.
3. **Connect:** Once your Satechi FindAll Card is detected by the app, tap 'Connect' to complete the pairing process.

Note: Do not close the Find My app while pairing. Ensure your FindAll Card appears in the 'Items' list. If it does not appear, perform a factory reset on the card and attempt to reconnect.



Image: A visual guide illustrating the three steps to pair the Satechi FindAll Wallet Card with an Apple device via the Find My app, showing screenshots of the app interface.

Operating Your FindAll Wallet Card

Tracking Your Item:

Once paired, you can track your FindAll Wallet Card's location directly within the Apple Find My app. The app uses a combination of ultra-wideband, GPS, Wi-Fi, and cellular signals to provide location data. The Bluetooth 5.4 LE connection offers a range of up to 20 meters indoors and up to 50 meters outdoors.



Image: A split image showing an iPhone displaying a "Wallet left behind" notification and the Find My app with the card's location on a map, illustrating real-time tracking and alerts.

Sound Alert:

If your item is nearby but out of sight, you can trigger an audible chime from the FindAll Wallet Card. Open the Find My app, select your FindAll Card, and tap 'Play Sound'. The card will emit a loud chime to help you pinpoint its exact location.



Image: A person using their iPhone to locate the FindAll Wallet Card, which is shown emitting a signal from within a couch cushion, highlighting the "ping it" feature.

Left Behind Notifications:

The FindAll Wallet Card can notify you if you accidentally leave it behind. This feature provides real-time alerts on your Apple device, indicating the last known location of your item. You can also securely share your FindAll Card's location with family or friends through the Find My app.

Power/Pairing Button:

The card features a single multi-function button for power on, pairing, power off, and resetting. These functions typically require a series of press and holds to prevent accidental activation.



Image: A detailed view of the Satechi FindAll Wallet Card, pointing out the LED charging light indicator and the power/pairing button, along with its ultra-thin dimensions and material composition (aluminum and tempered glass).

Charging

The Satechi FindAll Wallet Card features an integrated 220mAh rechargeable lithium-ion battery. It supports wireless charging via Qi, Qi2, or MagSafe compatible chargers.

Charging Instructions:

1. Place the FindAll Wallet Card flat on a compatible wireless charger.
2. The LED charging light indicator on the card will turn orange while charging.
3. Once fully charged, the LED indicator will turn green.

Note: Ensure the card is placed on a flat surface for optimal charging. The card is not magnetic.



Image: The Satechi FindAll Wallet Card resting on a wireless charging pad, illustrating its wireless charging capability and emphasizing its long battery life of up to 16 months.

Maintenance

The FindAll Wallet Card is designed for durability and ease of maintenance.

- **Cleaning:** Wipe the card with a soft, dry cloth to remove dust or fingerprints. Avoid abrasive cleaners.
- **Water and Dust Resistance:** The card has an IP66 rating, meaning it is protected against powerful water jets and is dust-tight. It can handle accidental spills, splashes, and brief submersion, but prolonged submersion is not recommended.
- **Temperature:** Avoid exposing the card to extreme temperatures.

Troubleshooting

Problem	Solution

Problem	Solution
Card not pairing with Find My app.	Ensure Bluetooth is enabled on your Apple device. Make sure the Find My app is open and you are following the correct pairing steps. If issues persist, perform a factory reset on the card and try again.
Cannot hear the sound alert.	Ensure the card is within Bluetooth range (up to 20m indoors, 50m outdoors). Check for obstructions that might muffle the sound. The sound may be less audible in noisy environments.
Card not charging wirelessly.	Verify that your wireless charger is Qi, Qi2, or MagSafe compatible and functioning correctly. Ensure the card is placed flat and centered on the charging pad.
"Left Behind" notifications not working.	Check your Find My app settings to ensure "Notify When Left Behind" is enabled for your FindAll Card. Ensure your Apple device has an active internet connection and location services are enabled for the Find My app.
Inaccurate location tracking.	Location accuracy can vary based on environmental factors (e.g., dense urban areas, indoors). Ensure your Apple device has a strong network connection. The card does not support ultra-wideband (UWB) detection for precision finding.

Specifications

Feature	Detail
Model Number	ST-LFAWC_PAR
Dimensions (L x W x Th)	8.5 x 5.4 x 0.22 cm / 3.35 x 2.13 x 0.09 inches
Weight	18gr / 0.635 ounces
Material	Aluminum and Tempered Glass
Battery	220mAh Lithium-Ion (rechargeable)
Battery Life	Up to 16 months
Charging	Wireless (Qi, Qi2, MagSafe compatible)
Connectivity	Bluetooth 5.4 LE (Works with Apple Find My)
Range	Up to 20m indoors, 50m outdoors
Water/Dust Rating	IP66
Compatibility	iPhone, iPad, Mac (Apple devices only; not compatible with Android)

Official Product Videos

Satechi FindAll Card Overview

Your browser does not support the video tag.

Video: This video provides a comprehensive overview of the Satechi FindAll Wallet Card, demonstrating its features such as tracking, sound alerts, and seamless integration with the Apple Find My network. It highlights how the card helps users locate their belongings and offers peace of mind.

Warranty and Support

Satechi products are covered by a 2-year limited warranty against defects in materials and workmanship under normal use. For customer service and support, please refer to the contact information provided with your product packaging or visit the official Satechi website.
For additional information and resources, you may visit the Satechi Store on Amazon.

© 2025 Satechi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8T8BQJK

More documents and user manuals: **https://manuals.plus/**