

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Romorgniz](#) /
- › [Romorgniz 57" 16-Drawer Fabric Dresser Instruction Manual \(Grey\)](#)

Romorgniz 16 Drawer

Romorgniz 57" 16-Drawer Fabric Dresser Instruction Manual (Grey)

Model: 16 Drawer | Brand: Romorgniz

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Romorgniz 57" 16-Drawer Fabric Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all parts are present before beginning assembly.
- Do not overtighten screws during assembly.
- For stability, use the included anti-tipping kit to secure the dresser to a wall, especially in households with children or pets.
- Do not exceed the weight capacity of the drawers or the top surface.
- Keep small parts away from children during assembly.

PARTS LIST

Verify all components are included in your package before starting assembly. If any parts are missing or damaged, please contact customer support.



Image: An exploded diagram showing all components of the dresser, including the metal frame, fabric drawers, and hardware, along with a visual representation of the assembly steps.

SETUP AND ASSEMBLY

The Romorgniz 16-Drawer Fabric Dresser is designed for hassle-free assembly. A full set of tools and accessories are included in the package. Follow the instructions provided to complete the installation, typically within 30 minutes.

1. Unpack all components and lay them out on a clean, soft surface.
2. Assemble the metal frame according to the provided diagrams, ensuring all connections are secure.
3. Attach the solid wooden top to the assembled frame.
4. Insert the fabric drawers into their designated slots.
5. Adjust the leveling feet to ensure the dresser is stable on uneven surfaces.
6. Install the anti-tipping kit to secure the dresser to a wall for enhanced safety.

Your browser does not support the video tag.

Video: An overview of the 16-drawer dresser, highlighting its features and assembly process. This video demonstrates the product's structure and how it fits together.

Your browser does not support the video tag.

Video: A demonstration of the dresser's assembly and how it can replace older furniture, showcasing its vertical storage capabilities.

OPERATING INSTRUCTIONS

Your Romorgniz dresser features 16 fabric drawers in three different sizes (small, medium, and large) to accommodate various items. The drawers are designed for smooth operation and easy access.

- **Drawer Capacity:** The dresser offers generous capacity, capable of organizing over 100 t-shirts, 80 dresses, or 50 pairs of jeans.
- **Drawer Sizes:**
 - 8 large drawers (11.5"W x 10.9"D x 8.7"H)
 - 4 medium drawers (11.5"W x 10.9"D x 8.8"H)
 - 4 flat drawers (11.5"W x 10.9"D x 4.4"H)
- **Usage:** Utilize the varied drawer sizes to compartmentalize accessories, clothing, or household items for efficient tidying and easy access.



Image: A detailed diagram illustrating the overall dimensions of the dresser (57.1"H x 37.6"W x 11.9"D) and the specific dimensions of the small, medium, and large fabric drawers.



Image: An aerial view of the dresser with several drawers partially open, revealing different types of items neatly stored within, demonstrating the versatile storage possibilities.

MAINTENANCE

To ensure the longevity and appearance of your Romorgniz dresser, follow these simple care instructions:

- **Cleaning the Frame:** Wipe the metal frame with a dry cloth to remove dust.
- **Cleaning Fabric Drawers:** For general cleaning, wipe the fabric drawers with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Immediately blot any spills on the fabric drawers with a clean, dry cloth.
- **Drawer Integrity:** Avoid overstuffing drawers to prevent damage to the fabric or handles.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dresser feels wobbly.	Uneven floor or loose connections.	Adjust the leveling feet. Check and tighten all screws on the metal frame. Ensure the anti-tipping kit is properly installed.

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Overstuffed drawer or obstruction.	Reduce the contents of the drawer. Check for any items obstructing the drawer's path.
Missing or damaged parts.	Manufacturing defect or shipping damage.	Contact Romorgniz customer support for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	Romorgniz
Model Name	16 Drawer
Product Dimensions	11.9"D x 37.6"W x 57.1"H
Color	Grey
Room Type	Bedroom, Entryway, Dressing Room, Wardrobe, Living Room
Drawer Type	Fabric
Material	Metal frame, Wood top, Fabric drawers
Finish Type	Painted (frame)
Number of Drawers	16 (8 large, 4 medium, 4 flat)
Assembly Required	Yes
Product Care Instructions	Wipe with Damp Cloth, Wipe with Dry Cloth



Image: A detailed view highlighting the sturdy steel frame construction, adjustable feet for stability, the solid wooden top, and the anti-tipping kit for safety.

WARRANTY INFORMATION

For specific warranty details regarding your Romorgniz 16-Drawer Fabric Dresser, please refer to the documentation included with your purchase or contact Romorgniz customer support directly. Warranty terms may vary based on region and retailer.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Romorgniz customer support. You can typically find contact information on the product packaging or the official Romorgniz website.

For more information, visit the [Romorgniz Store on Amazon](#).