



[Manuals.plus](#) /

> [ChooChoo](#) /

> ChooChoo Arched Bookcase with Doors (Model BC2405-RT3) Instruction Manual

## ChooChoo BC2405-RT3

# ChooChoo Arched Bookcase with Doors

Model: BC2405-RT3 - Instruction Manual

## INTRODUCTION

---

Thank you for choosing the ChooChoo Arched Bookcase with Doors. This manual provides essential information for the safe assembly, setup, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

## SAFETY INFORMATION

---

Your safety is paramount. Please adhere to the following guidelines:

- Always use the anti-tip kit provided to securely anchor the cabinet to the wall. This prevents accidental tipping, ensuring safety, especially in homes with children or pets.
- Do not overload shelves. Ensure items are evenly distributed to maintain stability and prevent tipping or structural damage. The maximum load for each shelf is 44 lbs.
- Always follow the assembly instructions precisely for safe and correct installation. Incorrect assembly can compromise the structural integrity of the bookcase.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.

## PACKAGE CONTENTS

---

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Bookcase panels (top, bottom, sides, shelves, back panels, door panels)
- Hardware pack (screws, dowels, cam locks, hinges, handles, anti-tip kit)
- Adjustable shelf pins
- Illustrated instruction manual

## ASSEMBLY INSTRUCTIONS

---

Assembly is required for this product. Please follow the detailed illustrated instructions included in your package. Each part is clearly labeled with numbers or letters for easy identification.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the labels and the provided parts list.
2. **Assemble Frame:** Begin by assembling the main frame of the bookcase according to the step-by-step diagrams. Ensure all connections are secure.
3. **Install Shelves:** Insert fixed shelves into their designated positions.
4. **Attach Back Panels:** Secure the back panels to the frame.
5. **Assemble and Attach Doors:** Assemble the door panels and attach them to the lower cabinet section using the provided hinges. Adjust hinges as necessary for proper door alignment.
6. **Install Adjustable Shelf:** Place the adjustable shelf pins at your desired height within the lower cabinet and position the adjustable shelf.
7. **Secure Anti-Tip Kit:** Attach the anti-tip kit to the top rear of the bookcase and secure it to a wall stud using appropriate hardware. This step is critical for safety.

# Demensions and Load



Figure 1: Product Dimensions and Load Capacity. Overall dimensions are 11.81"D x 31.49"W x 70.86"H. Each shelf has a maximum load capacity of 44 lbs.

## SETUP

Once assembled, position your bookcase in its desired location.

- **Placement:** This bookcase is suitable for various rooms including bedrooms, dining rooms, kitchens, living rooms, and offices. Choose a flat, stable surface to place the bookcase.
- **Adjustable Shelf:** The lower enclosed cabinet features an adjustable shelf. To adjust its height, remove the shelf, reposition the shelf pins to the desired level, and then place the shelf back onto the pins. This allows for flexible storage of items of various sizes.



Figure 2: Bookcase in a living room environment, demonstrating its aesthetic and functional integration.



Figure 3: Bookcase utilized in a bathroom, illustrating its adaptability for different storage needs.

## OPERATING

---

The ChooChoo Arched Bookcase is designed for straightforward use.

- **Open Shelves:** The upper three tiers are open shelves, ideal for displaying books, decorative items, or frequently accessed materials.
- **Enclosed Cabinet:** The lower section features two doors, providing concealed storage for items you wish to keep out of sight. Gently pull the handles to open the doors.
- **Adjustable Shelf:** As mentioned in the Setup section, the shelf within the enclosed cabinet can be adjusted to accommodate items of varying heights.



Figure 4: Key design elements including the elegant arch, wood texture, adjustable shelf mechanism, and slatted door design.

## MAINTENANCE

---

To ensure the longevity and appearance of your bookcase, follow these maintenance tips:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood material.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

## TROUBLESHOOTING

---

If you encounter any issues during or after assembly, consider the following:

- **Wobbly Bookcase:** Ensure all screws are tightened. Check that the bookcase is on a level surface. Adjust the leveling feet if present.
- **Doors Not Aligning:** Recheck the hinge installation. Most hinges allow for minor adjustments to align the doors properly. Refer to the assembly instructions for hinge adjustment details.
- **Missing Parts:** Double-check the packaging. If parts are genuinely missing, contact ChooChoo customer service with your product model number and a description of the missing part.

## SPECIFICATIONS

---

Feature	Detail
Model Name	Bookcase
Item Model Number	BC2405-RT3
Product Dimensions	11.81"D x 31.49"W x 70.86"H
Material	Engineered Wood

Number of Shelves	3 (including 1 adjustable shelf in lower cabinet)
Special Feature	Adjustable Shelf, Doors, Anti-tip Kit
Finish Type	Natural Wood Grain
Item Weight	59.8 Pounds
Weight Capacity (Each Shelf)	44 Pounds
Assembly Required	Yes
Installation Type	Freestanding

## WARRANTY AND SUPPORT

---

ChooChoo is committed to providing quality products and customer satisfaction. If you have any questions regarding assembly, missing parts, or product functionality, please contact our professional customer service team. Refer to your purchase documentation or the ChooChoo official website for specific warranty details and contact information.

Typically, products purchased from ChooChoo Furniture come with a 30-day easy return policy. For any assistance, please reach out to the seller directly.