

Airpher K25-Brush

Airpher K25 Vacuum Cleaner Replacement V-Roller Brush Instruction Manual

Model: K25-Brush | Brand: Airpher

INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your Airpher K25 Vacuum Cleaner Replacement V-Roller Brush. This genuine replacement roller brush is designed with dual bristles (soft and hard) to effectively manage dust, crumbs, and pet hair, ensuring optimal cleaning performance for your Airpher K25 vacuum cleaner.

INSTALLATION

Follow these steps to correctly install the replacement V-Roller Brush into your Airpher K25 vacuum cleaner. No special tools are required for this process.

1. **Power Off:** Ensure your Airpher K25 vacuum cleaner is turned off and unplugged from the power outlet before beginning any maintenance or installation.
2. **Access Brush Head:** Locate the brush head assembly on the bottom of your vacuum cleaner. Depending on your specific K25 model, there may be a latch or button to release the brush cover.
3. **Remove Old Brush:** Carefully remove the existing roller brush. You may need to gently pull it out from its housing. Dispose of the old brush responsibly.
4. **Insert New Brush:** Align the ends of the new Airpher K25 V-Roller Brush with the corresponding slots in the vacuum's brush head. Ensure the brush is seated correctly and clicks into place. The V-shaped bristles should face downwards.
5. **Secure Cover:** Reattach the brush cover securely until it latches.
6. **Test:** Plug in and power on your vacuum cleaner to ensure the new brush rotates freely and operates correctly.

Wide 10.5" Anti-Tangle V-Brush

Soft/Hard bristles capture dust, crumbs & hair



90%
less clogs



Figure 1: Visual guide for installing the Airpher K25 V-Roller Brush. The image illustrates the brush being inserted into the vacuum head, emphasizing its V-shaped design and how it fits into the mechanism.

OPERATING WITH THE NEW BRUSH

The Airpher K25 Replacement V-Roller Brush is designed to enhance your vacuum's cleaning efficiency across various floor types. Its V-shaped anti-tangle design, combined with soft and stiff bristles, effectively captures dust, crumbs, and pet hair while minimizing hair wrap.

- **Optimal Performance:** For best results, ensure the brush is free from large debris or excessive hair buildup before each use.
- **Floor Types:** This brush is suitable for a wide range of floor surfaces, including hardwood, tile, and carpets. The dual bristles are engineered to protect delicate floors while effectively cleaning carpets.
- **Edge-to-Edge Cleaning:** The design of the brush supports thorough cleaning along edges and in corners.




Figure 2: Detailed view of the Airpher K25 V-Roller Brush. This image highlights the unique V-shaped bristle pattern and the combination of soft and hard bristles designed for effective cleaning and anti-tangle properties.

MAINTENANCE

Regular maintenance of your V-Roller Brush will ensure consistent cleaning performance and extend its lifespan.

- **Regular Cleaning:** Periodically inspect the brush for tangled hair, threads, or debris. Use scissors or a brush cleaning tool to carefully cut and remove any entangled material.
- **Washing:** The brush can be gently rinsed under cool water if necessary. Ensure it is completely dry before re-installing it into the vacuum cleaner to prevent damage or mold growth.
- **Replacement Frequency:** For optimal performance, it is recommended to replace the V-Roller Brush every 6-12 months, or sooner if you notice a decrease in cleaning effectiveness or visible wear and tear on the bristles.

TROUBLESHOOTING

If you encounter issues with your Airpher K25 V-Roller Brush, refer to the following common problems and solutions:

- **Brush Not Rotating:**
 - Ensure the vacuum is properly assembled and powered on.
 - Check for obstructions (hair, debris) preventing the brush from spinning. Clean the brush thoroughly.
 - Verify the brush is correctly seated in its housing.
- **Reduced Cleaning Performance:**
 - Clean the brush to remove any accumulated debris.
 - Inspect the bristles for wear. If they are significantly worn, it may be time for a replacement.
 - Check your vacuum's filter and dustbin; a full dustbin or clogged filter can affect overall suction.
- **Unusual Noise:**
 - Turn off the vacuum and inspect the brush for any foreign objects caught in the bristles or brush housing.
 - Ensure the brush is installed correctly and not rubbing against any internal components.

SPECIFICATIONS

Feature	Detail
Model Number	K25-Brush
Compatibility	Airpher K25 Vacuum Cleaners

Feature	Detail
Brush Type	V-Roller Brush with Dual Bristles (Soft & Stiff)
Dimensions	Approximately 9.7 x 2 x 2 inches (Package Dimensions)
Item Weight	4.5 ounces
Manufacturer	Airpher

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Airpher K25 Replacement V-Roller Brush, please refer to the documentation provided with your original Airpher K25 vacuum cleaner or visit the official Airpher website. You may also contact Airpher customer service directly for assistance.

Contact Information: Please refer to the contact details provided on the Airpher brand website or your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

