

[Manuals.plus](#) /

› [W-KING](#) /

› W-KING T8II Portable Bluetooth Speaker User Manual

W-KING T8II

W-KING T8II Portable Bluetooth Speaker User Manual

Model: T8II | Brand: W-KING

INTRODUCTION

Thank you for choosing the W-KING T8II Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1: W-KING T8II Portable Bluetooth Speaker (Black variant). This image shows the front view of the speaker with its central light bar and W-KING logo, highlighting its sleek design and portable handle.

SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and liquids to prevent damage.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for assistance.
- Use only the provided charging cable and a compatible power adapter.
- Keep out of reach of children.

WHAT'S IN THE BOX

- T8II Portable Loud Speaker
- 3.5mm Audio Cable
- Type-C Charging Cable
- User Manual (this document)



Figure 2: Contents of the W-KING T8II package, including the speaker, charging cable, audio cable, and user manual.

PRODUCT OVERVIEW AND FEATURES

Components and Controls

- **Top Panel Buttons:** Mode (M), Volume Down (-), Play/Pause (▶/||), Volume Up (+).
- **Rear Ports:** USB-A (for USB playback/power bank), AUX-in (3.5mm), Reset button, Type-C charging port, Bluetooth pairing button.
- **Handle:** Durable leather handle for easy portability.
- **Status Indicator Light:** A vertical light bar on the front grille indicates power and connection status.



Figure 3: Detailed view of the W-KING T8II's intuitive control buttons on the top panel, including Mode, Volume, and Play/Pause.



Figure 4: The rear panel of the W-KING T8II, illustrating the USB, AUX, and charging ports for versatile connectivity.

Key Features

- **Impactful Bass & Clear Sound:** Equipped with dual woofers and dual tweeters, an intelligent DSP chip, and a bass duct port for deep bass and crystal-clear audio.
- **Bass Reflex Tube:** Rear bass duct port enhances low-frequency sound for heavier and more powerful bass.
- **Small Size, Big Sound:** Delivers a maximum sound of 97dB, ensuring clear music even in noisy environments.
- **Type-C Fast Charging & Power Bank:** Supports up to 30W fast charging and can charge other devices via its Type-C port.
- **True Stereo Pairing (TWS):** Wirelessly pair two T8II speakers for true left and right channel separation and immersive surround sound.
- **All-Day Playback:** Built-in high-capacity battery for extended continuous playback.
- **Bluetooth 5.4:** High-speed wireless connection with faster transmission, stable performance, and lower power consumption.
- **Multiple Playback Modes:** Supports Bluetooth, USB flash drive playback, and 3.5mm AUX input.

Tiny Yet Mighty, W-KING T8II

Unleashing Power Booming Bass



Crystal Clear Sound, Immersive Audio Beyond Limits

Experience flawless, zero-distortion stereo sound with an expansive soundstage and powerful, impactful audio that transcends size. Perfect for audiophiles and enthusiasts.

Figure 5: An X-ray view of the W-KING T8II's internal structure, highlighting the dual woofers, dual tweeters, DSP technology, and bass reflex enclosure for superior sound.

W-KING T8II

BASS DUCT DESIGN

NATURAL, POWERFUL, DEEP BASS — UNFORGETTABLE SOUND QUALITY. THE W-KING T8II'S ADVANCED BASS DUCT EXPELS OVER 99% OF EXCESS AIR, ENHANCING BASS DEPTH AND IMPACT WITH EVERY BEAT. EXPERIENCE POWERFUL SOUND WITH OPTIMIZED SINGLE-DRIVER AIR DISPLACEMENT

AND **40%** MORE OUTPUT POWER.



Figure 6: Visual representation of the W-KING T8II's bass duct design, which optimizes airflow to enhance bass depth and power.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's Type-C port and the other end to a compatible USB power adapter (not included). The indicator lights will show charging progress.



Figure 7: The W-KING T8II speaker connected to a power outlet via its Type-C port, demonstrating its fast charging capability.

2. Powering On/Off

Press and hold the Power button on the rear panel for 2-3 seconds to turn the speaker on or off. The front indicator light will illuminate when powered on.

3. Bluetooth Pairing

1. Turn on the speaker. The front indicator light will flash blue, indicating it's in pairing mode.

2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "W-KING T8II" in your device's Bluetooth list and select it to connect.
4. Once connected, the indicator light will turn solid blue.

Your browser does not support the video tag.

Video 1: This video demonstrates the Bluetooth pairing process for the W-KING T8II speaker, showing how to connect it to a mobile device.

4. True Wireless Stereo (TWS) Pairing

To achieve a true stereo sound experience, you can pair two W-KING T8II speakers together:

1. Ensure both T8II speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the Bluetooth button on the rear panel for 2-3 seconds until you hear a prompt.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation tone.
4. Now, connect your device to the primary speaker via Bluetooth as described in step 3. Both speakers will play audio in stereo.

True Wireless Stereo

Connect two T8II portable speakers for wide stereo separation and immersive, theater-like sound with enhanced depth, clarity, and balance.



Figure 8: Two W-KING T8II speakers set up for True Wireless Stereo (TWS) pairing, creating an expansive soundstage for an immersive audio experience.

Your browser does not support the video tag.

Video 2: This video illustrates the True Wireless Stereo (TWS) pairing feature of the W-KING T8II speakers, demonstrating how two units can be linked for synchronized audio playback.

OPERATING INSTRUCTIONS

1. Basic Playback Controls

- **Play/Pause:** Press the Play/Pause (▶/||) button once to play or pause music.
- **Volume Up/Down:** Press the Volume Up (+) or Volume Down (-) buttons to adjust the volume.
- **Next Track:** Press and hold the Volume Up (+) button for 2 seconds.
- **Previous Track:** Press and hold the Volume Down (-) button for 2 seconds.

2. Switching Playback Modes

Press the Mode (M) button on the top panel to cycle through available input modes: Bluetooth, AUX, and USB.

- **AUX Mode:** Connect an audio device using the 3.5mm audio cable to the AUX port on the rear.
- **USB Mode:** Insert a USB flash drive containing audio files into the USB-A port on the rear.



Figure 9: The W-KING T8II supports multiple playback modes including Bluetooth, 3.5mm AUX, and USB playback, offering versatile audio input options.

3. Using as a Power Bank

The W-KING T8II can function as a power bank to charge your mobile devices. Connect your device's charging cable to the USB-A port on the rear of the speaker. The speaker will automatically begin charging your device.



Figure 10: The W-KING T8II speaker acting as a power bank, charging a smartphone via its USB-A output port.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing blue light). Turn on device Bluetooth. Move device closer to speaker (within 10 meters).
No sound.	Volume too low; incorrect input mode; device not connected.	Increase volume on speaker and device. Press 'M' button to select correct input mode. Re-pair Bluetooth or check AUX/USB connection.
Sound distortion.	Volume too high; low battery.	Reduce volume. Charge the speaker.
TWS pairing failed.	Speakers already connected to other devices; too far apart.	Ensure both speakers are disconnected from other devices. Place speakers close to each other during TWS pairing.

SPECIFICATIONS

- **Model Name:** T8II
- **Speaker Type:** Outdoor Wireless Portable Loud Speaker
- **Speaker Maximum Output Power:** 96 Watts
- **Connectivity Technology:** Bluetooth, Auxiliary, USB
- **Wireless Communication Technology:** Bluetooth 5.4
- **Maximum Range:** 10 Meters
- **Audio Output Mode:** Surround Stereo
- **Product Dimensions:** 10.91"D x 7.73"W x 3.9"H
- **Item Weight:** 5.5 pounds (2.5 Kilograms)
- **Batteries:** 1 12V battery required (built-in)
- **Signal-to-Noise Ratio:** 85 dB
- **Charging:** Type-C Fast Charging (up to 30W input, up to 18W USB-A output)

WARRANTY AND SUPPORT

W-KING products are designed and manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official W-KING website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I fix my W-KING T8II speakers if they cut out, have low volume, and the sound duct seems to have no bass?

Based on the W-KING T8II manual, intermittent sound (cutting out), low volume, and poor bass performance are often related to power or connection issues. Please try the following steps to resolve the problem:Charge the...

[Read full answer](#)