Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM B0F8WKSQTD

T4TREAM 60" Fluted Executive L Shaped Desk User Manual

Model: B0F8WKSQTD
Brand: T4TREAM

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM 60" Fluted Executive L Shaped Desk. Please read this manual thoroughly before assembly and use to ensure proper setup and long-term enjoyment of your new desk.

2. Safety Information

- Always follow assembly instructions carefully. Do not skip steps.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload the desk. The desktop supports up to 150 lbs.
- Keep small parts away from children during assembly.
- Use on a level surface to prevent tipping.
- Avoid exposing the desk to excessive moisture or direct sunlight.
- When moving the desk, lift it rather than dragging to prevent damage to the legs and floor.

3. Package Contents

Your T4TREAM L-Shaped Desk is shipped in two separate packages (Box A and Box B), which may arrive on different days. Please ensure you have received both packages before beginning assembly.
Verify all parts are present and undamaged against the included parts list in your physical instruction manual. If any parts are missing or damaged, please contact customer support.



Image: The item will be delivered in 2 packages and may NOT arrive on the same day.

4. Assembly Instructions (Setup)

Assembly is required for this product. We recommend two adults for efficient and safe assembly. All parts are labeled for easy identification. Please follow the step-by-step instructions provided in the physical assembly guide included with your desk.

- Unpack all components and lay them out on a clean, soft surface to prevent scratches.
- Identify all hardware and panels using the provided labels.
- Follow the numerical sequence of steps in the assembly manual.
- Use the included sticker patches to cover any visible holes for a clean finish.



Image: Fully assembled T4TREAM L-Shaped Executive Desk.

5. Operating Instructions

5.1 Integrated Charging Station

The desk features a built-in charging station for convenient power access. It includes:

- 1 x USB Port
- 1 x Type-C Port
- 2 x AC Outlets

Simply plug your devices into the appropriate ports to charge them directly from your desk. The power strip has a 6.6-foot power cord.




Image: Recessed 4-in-1 Power Strip with USB, Type-C, and AC outlets.

Your browser does not support the video tag.

Video: Demonstration of the integrated charging station and desk features.

5.2 Storage and Organization

The desk is designed with ample storage to keep your workspace tidy and organized:

- **File Drawer:** One letter-size file drawer for important documents.
- **Utility Drawers:** Three additional utility drawers for small items and supplies.
- **Storage Cabinet:** A cabinet with an adjustable shelf for larger items or a vertical CPU tower.



Image: Efficient workspace organization with various storage options.




Image: Large and customizable storage cabinet with adjustable shelf.



Image: Three box drawers and a letter-size file drawer for organized storage.

5.3 Workspace Surface

The 60" x 60" L-shaped tabletop provides a spacious work surface, accommodating dual monitors, paperwork, and other essentials for enhanced productivity.



Image: Spacious 60 x 60 inch work surface.

6. Maintenance

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean up spills immediately to prevent damage to the engineered wood finish.
- **Hardware:** Periodically check and tighten all screws and fasteners to maintain stability.
- **Protection:** Use coasters for drinks and desk pads for heavy objects or writing to protect the surface.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Desk is wobbly	Loose fasteners; Uneven floor	Check and tighten all screws. Ensure the desk is on a flat, level surface.
Drawers do not slide smoothly	Misaligned drawer slides; Obstruction	Ensure drawer slides are correctly installed and aligned. Check for any objects obstructing the slides.
Charging station not working	Not plugged in; Overload; Device issue	Ensure the desk's power cord is securely plugged into a working outlet. Check if the charging station is overloaded. Test with a different device.

8. Specifications

- **Brand:** T4TREAM
- **Model:** B0F8WKSQTD
- **Product Dimensions:** 60"D x 60"W x 30"H
- **Color:** Dark Walnut
- **Style:** Modern
- **Base Material:** Stable and attractive
- **Finish Type:** Engineered Wood
- **Special Features:** Charging Station, Fluted Panel
- **Room Type:** Office
- **Mounting Type:** Freestanding
- **Number of Drawers:** 4 (3 utility, 1 file)
- **Number of Shelves:** 1 (adjustable)
- **Number of Cabinets:** 1
- **Required Assembly:** Yes

9. Warranty and Support

T4TREAM stands behind the quality of its products. For any questions, missing parts, or assistance with assembly, please contact our dedicated support team. Refer to your purchase documentation for specific warranty details.
You can visit the official T4TREAM store for more information:T4TREAM Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8W9QC71

More documents and user manuals: **https://manuals.plus/**