

[Manuals.plus](#) /

› [Groovz](#) /

› Groovz Open-Ear True Wireless Headphones GRZ-OPN-SS User Manual

Groovz GRZ-OPN-SS

Groovz Open-Ear True Wireless Headphones

Model: GRZ-OPN-SS

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Groovz Open-Ear True Wireless Headphones, model GRZ-OPN-SS. These headphones are designed to provide a comfortable listening experience while maintaining awareness of your surroundings, featuring Bluetooth 5.3 connectivity, smart touch controls, and an IPX5 water-resistant rating.

PACKAGE CONTENTS

- Groovz Open-Ear True Wireless Headphones (Left and Right Earbuds)
- Charging Case with Smart Battery Display
- User Manual

PRODUCT OVERVIEW

The Groovz Open-Ear True Wireless Headphones offer a unique design that rests comfortably over your ear, allowing you to hear both your audio and ambient sounds. The included charging case features an LED display to show battery levels.



Figure 1: Groovz Open-Ear True Wireless Headphones and Charging Case. The earbuds feature an open-ear design with ear hooks, and the case has a digital battery display.



The Perfect Fit for Everyone

Designed for all-day wear
and full awareness



Lightweight, open-ear
headphones with
ergonomic silicone
earbuds and flexible
ear hooks for a secure,
comfortable fit

Figure 2: A woman wearing the Groovz Open-Ear Headphones, demonstrating their secure and comfortable fit over the ear.

Break Free from Wires

Simplify your life with one less cord to worry about!



Instant pairing
with **Bluetooth 5.3**
Technology



Navigate playlists
or answer calls with
Smart Touch Controls



Figure 3: A woman interacting with the smart touch controls on the Groovz Open-Ear Headphones, highlighting ease of use for managing music and calls.



Crystal Clear Sound & Premium Comfort


Experience flawless communication and immersive sound with technology that adapts to your life



Secure & Comfortable Fit



Dual Microphones & Noise Reduction



Easy Touch Controls

Figure 4: The Groovz charging case displaying a 100% battery charge, indicating the real-time LED battery display feature.

	Groovz Open Ear	Other Brands
 Connectivity	Bluetooth 5.3 with Instant Pairing and Smart Touch Controls	Basic wireless with older Bluetooth versions and unreliable controls
 Sound Experience	High-definition audio with balanced clarity and powerful bass	Bass-heavy or unbalanced sound; lacks clarity
 Call Quality	Dual mics with advanced noise reduction for crisp, clear calls	Single mic; muffled and noisy calls
 Battery Transparency	LED case display shows exact battery life in real-time	No visual battery indicator; unclear battery status
 Comfort & Fit	Ergonomic Open-Ear design with ergonomic and flexible ear hooks	One-size-fits-all fit with limited customization
 Personal Style	Bold colorways and prints designed to match your personal style	Mostly neutral or generic colors
 Durability	IPX5 Water Resistance – built for active lifestyles	No official water resistance rating
 Designed in the USA	Thoughtfully designed and developed in the USA	Generic overseas design with no localization

Figure 5: Groovz Open-Ear Headphones with water droplets, illustrating their IPX5 water-resistant durability for active use.

Your browser does not support the video tag.

Video 1: An overview of the Groovz True Wireless Earbuds in various usage scenarios, demonstrating their design, fit, and functionality for different activities and environments.

SETUP

1. Charging the Headphones and Case

- Before first use, fully charge the headphones and charging case.
- Place the earbuds into the charging case.
- Connect the charging case to a power source using a Type-C charging cable (not included).
- The LED Battery Display on the case will show the charging status. A full charge provides up to 4 hours of playtime for the earbuds and an additional 22 hours with the charging case.

2. Bluetooth Pairing

1. Ensure the headphones are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light on the earbuds.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "Groovz GRZ-OPN-SS" from the list.
5. Once connected, the LED indicator on the earbuds will stop flashing.
6. The headphones will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Smart Touch Controls

The Groovz Open-Ear Headphones feature intuitive touch controls on each earbud. Specific functions may vary slightly by device or application.

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap (Left/Right Earbud)	Activate Voice Assistant
Long Press (Left/Right Earbud)	End Call, Reject Call

Making and Receiving Calls

- **Answer Call:** Single tap either earbud.
- **End Call:** Long press either earbud.
- **Reject Call:** Long press either earbud.
- The dual microphones with noise reduction ensure clear conversations.

Music Playback

- **Play/Pause:** Single tap either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The headphones are IPX5-rated, meaning they are resistant to splashes and sweat. Do not submerge them in water or expose them to heavy rain. Ensure they are dry before placing them back in the charging case.
- **Storage:** Store the headphones in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.

TROUBLESHOOTING

Problem	Solution
Headphones not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and re-pair.
No sound or low volume	Check device volume and headphone volume. Ensure headphones are properly connected. Try adjusting settings on your phone as suggested by customer reviews.
Earbuds not charging	Ensure the charging cable is securely connected to both the case and power source. Check for debris in the charging ports. Ensure earbuds are correctly seated in the case.
Intermittent connection	Move closer to your device. Avoid environments with strong Wi-Fi or other wireless interference.

SPECIFICATIONS

Feature	Detail
Model Name	GRZ-OPN-SS
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	Open Ear
Water Resistance Level	IPX5 (Water Resistant)
Battery Life (Earbuds)	Up to 4 Hours
Total Playtime (with Case)	Up to 26 Hours
Control Method	Touch
Noise Control Features	Noise Reduction (Dual Microphones)
Material	Silicone
Item Weight	6.7 ounces
UPC	810186691776

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Groovz website. If you encounter any issues not covered in this manual, please contact Groovz customer service for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question