

[Manuals.plus](#) /

› [Doohoeek](#) /

› Doohoeek Universal Keyboard Case for 9-11 Inch Tablets Instruction Manual

Doohoeek B0F914SPF3

Doohoeek Universal Keyboard Case for 9-11 Inch Tablets

Instruction Manual

PRODUCT OVERVIEW

The Doohoeek Universal Keyboard Case is designed to enhance the functionality of 9-11 inch tablets. It features a detachable Bluetooth keyboard with a trackpad, multi-color backlighting, and a versatile stand. The case utilizes a unique washable and reusable adhesive mounting system for secure attachment to your tablet. This keyboard case is compatible with a wide range of tablets, specifically those measuring 9-11 inches with a top-left positioned camera. It offers seamless connectivity to two Bluetooth devices, allowing for efficient multitasking across different operating systems.

SETUP INSTRUCTIONS

1. Tablet Compatibility and Mounting

Ensure your tablet is between 9 and 11 inches in size and has its camera located in the top-left corner. This case is designed exclusively for such configurations.



Figure 1: Tablet Compatibility. The image displays three tablets of 9, 10, and 11 inches, illustrating how they fit into the case and emphasizing the requirement for a top-left camera position.

The case uses residue-free adhesive pads for secure tablet attachment. These pads are designed to leave no damage on your device. Four extra adhesive pads are included for long-term use.

DAMAGE-FREE & STRONG MOUNTING ADHESIVE



Figure 2: Adhesive Mounting Pads. This image highlights the four adhesive pads on the case, detailing their key features: residue-free, strong hold, reusable, and water-washable.

2. Bluetooth Connection

1. Ensure the keyboard is charged.
2. Turn on the keyboard.
3. Activate Bluetooth on your tablet.
4. Press and hold the **Fn** key and the **C** key simultaneously on the keyboard to enter pairing mode. The Bluetooth indicator light will flash.
5. On your tablet, search for available Bluetooth devices and select the keyboard (e.g., "Bluetooth

Keyboard").

6. Follow any on-screen prompts to complete the pairing process.

OPERATING INSTRUCTIONS

1. Multi-Device Connectivity

The keyboard supports connection to two Bluetooth devices simultaneously. To switch between connected devices:

- Press **Fn + 1** to switch to the first paired device.
- Press **Fn + 2** to switch to the second paired device.

2. Backlit Keyboard

The keyboard features 7-color backlighting with 3 brightness levels for use in various lighting conditions.

Detachable Keyboard & Adjust Up to 150°

Versatile for All Your Needs



Figure 3: Backlit Keyboard. The image shows the keyboard with its keys glowing, illustrating the multi-color backlit functionality.

- Press the **light bulb icon key** to cycle through the 7 backlight colors.
- Press **Fn + light bulb icon key** to adjust the brightness level (3 levels).

3. Integrated Trackpad

The integrated multi-touch trackpad supports various gestures for navigation and control.



Figure 4: Integrated Trackpad. This image provides a detailed view of the keyboard's trackpad, located centrally below the spacebar.

Refer to your tablet's operating system documentation for specific multi-touch gesture support.

4. Multi-Angle Adjustable Stand

The case features a flexible stand that allows for various viewing and typing angles. The keyboard is detachable via a strong magnetic snap-on mechanism.



Figure 5: Adjustable Stand. The image demonstrates the case's ability to hold a tablet at multiple angles, suitable for various activities like typing, viewing, or drawing.

MAINTENANCE

1. Cleaning the Adhesive Pads

The adhesive pads are water-washable and reusable. If the stickiness decreases due to dust or debris:

1. Gently detach the tablet from the case. Ensure the keyboard remains dry.
2. Rinse the adhesive pads with clean water.

3. Allow the pads to air-dry completely before reattaching your tablet. Do not use cloths or paper towels, as fibers may reduce stickiness.

2. Cleaning the Case and Keyboard

- The case itself is washable. You can wipe it with a damp cloth.
- The keyboard is **not submersible**. To clean the keyboard, detach it from the case and wipe it gently with a dry or slightly damp cloth. Avoid getting moisture into the keys or ports.

TROUBLESHOOTING

1. Keyboard Not Connecting via Bluetooth

- Ensure the keyboard is charged and turned on.
- Make sure Bluetooth is enabled on your tablet.
- Re-enter pairing mode by pressing **Fn + C**.
- Forget the device from your tablet's Bluetooth settings and attempt to pair again.
- Ensure the keyboard is within the effective Bluetooth range (typically 10 meters).

2. Keys or Trackpad Not Responding

- Check the keyboard's battery level. Charge if necessary.
- Reconnect the Bluetooth connection.
- Restart your tablet.
- Ensure no debris is obstructing the keys or trackpad surface.

3. Backlight Not Working

- Ensure the keyboard is turned on and charged.
- Press the **light bulb icon key** to activate or change backlight settings.
- Adjust brightness using **Fn + light bulb icon key**.

SPECIFICATIONS

Brand	Doohoeek
Compatible Devices	9-11 inch tablets with top-left cameras (NOT center-positioned)
Connectivity Technology	Bluetooth
Keyboard Description	Universal Keyboard Case
Additional Features	Backlit, Integrated Stand, Rechargeable, Trackpad, Universally Fit
Power Source	Battery Powered
Keyboard Layout	QWERTY

Number of Keys	84
Enclosure Material	Silicone
Model Number (ASIN)	B0F914SPF3




Figure 6: Product Dimensions. The image illustrates the physical dimensions of the keyboard case and highlights the removable nature of the keyboard, which weighs 1.1 lbs.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Doohoeek

customer service directly. Contact details can typically be found on the manufacturer's official website or through your purchase platform.