

Manuals.plus /

› AOLIKES /

› AOLIKES 330mAh 602030 Rechargeable Battery Replacement Manual for Bousnic Dog Training Collar Remotes

## AOLIKES 602030

# AOLIKES 330mAh 602030 Rechargeable Battery Replacement Manual

For Bousnic Dog Training Collar Remote Models: RS2, RS8, VS2, RS1, OT2, OT3, OT6, P20, P30

## 1. PRODUCT OVERVIEW

---

This manual provides instructions for the AOLIKES 330mAh 602030 Polymer Lithium-ion Rechargeable Battery. This battery is designed as a direct replacement for various Bousnic Dog Training Collar Remote models, ensuring optimal performance and compatibility.

### Key Features:

- **Capacity:** 330mAh
- **Nominal Voltage:** 3.7V
- **Fully Charged Voltage:** 4.2V
- **Cutoff Voltage:** 2.95V
- **Safety Features:** Built-in protection against overcharging, overheating, and short circuits.
- **Compatibility:** Specifically designed for Bousnic Dog Training Collar Remote models RS2, RS8, VS2, RS1, OT2, OT3, OT6, P20, P30.

## 3.7v 330mAh rechargeable battery

The battery replacement for Bousnic Dog Training Collar Remote Models for RS2 / RS8 / VS2 / RS1 / OT2 / OT3 / OT6 / P20 / P30




*Image 1.1: Front view of the AOLIKES 602030 330mAh rechargeable battery, showing the model number, voltage, capacity, and attached red and black wires with a white connector.*

## 2. INSTALLATION INSTRUCTIONS

Before proceeding with the installation, ensure the Bousnic Dog Training Collar Remote is powered off and disconnected from any charging source. Exercise caution and follow these steps carefully.

- 1. Prepare the Remote:** Locate the battery compartment on your Bousnic Dog Training Collar Remote. This may require removing screws or opening a cover. Refer to your Bousnic remote's original manual for specific instructions on accessing the battery.
- 2. Remove Old Battery:** Carefully disconnect the old battery's connector from the remote's circuit board. Gently remove the old battery from its compartment. Note its orientation for correct placement of the new battery.
- 3. Install New Battery:** Insert the new AOLIKES 602030 battery into the compartment, ensuring it fits securely and matches the orientation of the old battery.
- 4. Connect New Battery:** Align the connector of the new AOLIKES battery with the corresponding port on the remote's circuit board. Gently push the connector until it is fully seated. Do not force the connection.
- 5. Secure Compartment:** Close the battery compartment cover and secure it with any screws that were removed.

6. **Initial Charge:** It is recommended to fully charge the new battery before its first use. Connect the remote to its charger and allow it to charge until the charging indicator shows a full charge.



*Image 2.1: Side view of the AOLIKES 602030 330mAh rechargeable battery, highlighting its compact size and the attached wiring. This view helps in understanding the battery's physical dimensions for installation.*

### 3. OPERATING AND CHARGING

---

Once installed, the AOLIKES 602030 battery operates seamlessly with your Bousnic Dog Training Collar Remote. Proper charging practices will extend the battery's lifespan.

#### Charging the Battery:

- Use only the original charger provided with your Bousnic Dog Training Collar Remote.
- Connect the charger to the remote and a power source.
- Monitor the charging indicator on your remote. Disconnect the charger once the battery is fully charged to prevent overcharging, although the battery has built-in protection.
- Avoid charging in extreme temperatures. Charge at room temperature for optimal battery health.

#### Battery Usage:

- The battery is designed for regular use in your Bousnic remote.
- Avoid completely draining the battery frequently, as this can reduce its overall lifespan.
- If the remote will not be used for an extended period, store it with a partial charge (around 50%) in a cool, dry place.

### 4. MAINTENANCE AND STORAGE

---

Proper maintenance and storage are essential for maximizing the lifespan and performance of your AOLIKES 602030 battery.

- **Cleaning:** Keep the battery and its contacts clean and dry. Use a soft, dry cloth to wipe away any dust or debris.
- **Temperature:** Store the battery in a cool, dry environment, ideally between 0°C and 25°C (32°F and

77°F). Avoid exposure to extreme heat or cold.

- **Long-Term Storage:** If storing the battery for more than a month, charge it to approximately 50% capacity. Recharge it to 50% every 3-6 months to prevent deep discharge, which can permanently damage the battery.
- **Avoid Physical Damage:** Do not puncture, drop, or expose the battery to strong impacts. Physical damage can lead to internal short circuits or leakage.

## 5. TROUBLESHOOTING

---

If you encounter issues with your AOLIKES 602030 replacement battery, refer to the following common troubleshooting steps:

- **Battery Not Charging:**
  - Ensure the charger is properly connected to both the remote and a working power outlet.
  - Verify that the battery connector is securely seated in the remote's circuit board.
  - Try using a different compatible charger (if available) to rule out a faulty charger.
  - Inspect the charging port on the remote for any debris or damage.
- **Short Battery Life:**
  - Ensure the battery is being fully charged each time.
  - Check for any background processes or settings on the remote that might be consuming excessive power.
  - Battery capacity naturally degrades over time and with charge cycles. If the battery is old, replacement may be necessary.
- **Remote Not Powering On:**
  - Confirm the battery is correctly installed and its connector is firmly attached.
  - Attempt to charge the battery for at least 30 minutes, then try powering on the remote again.
  - If possible, test the remote with a known working battery to isolate the issue.

If these steps do not resolve the issue, please contact customer support.

## 6. PRODUCT SPECIFICATIONS

---

<b>Battery Type</b>	Polymer Lithium-ion Rechargeable Battery
<b>Model Number</b>	602030
<b>Capacity</b>	330mAh
<b>Nominal Voltage</b>	3.7V
<b>Fully Charged Voltage</b>	4.2V
<b>Cutoff Voltage</b>	2.95V
<b>Item Weight</b>	0.317 ounces (approximately 9 grams)
<b>Manufacturer</b>	AOLIKES

## 7. SAFETY INFORMATION AND WARNINGS

---

Lithium-ion batteries require careful handling. Please read and adhere to the following safety guidelines to prevent injury or damage.

- **Do Not Disassemble:** Never attempt to disassemble, open, or service the battery. This can lead to short circuits, fire, or exposure to hazardous materials.
- **Avoid Puncture/Impact:** Do not puncture, crush, bend, or expose the battery to strong impacts.
- **Temperature Extremes:** Do not expose the battery to heat sources (e.g., direct sunlight, heaters, fire) or extremely cold temperatures. Store and operate within recommended temperature ranges.
- **Water Exposure:** Keep the battery dry. Do not immerse in water or expose to rain or moisture.
- **Charging:** Use only compatible chargers designed for lithium-ion batteries. Overcharging or using incompatible chargers can be dangerous.
- **Disposal:** Dispose of batteries responsibly according to local regulations. Do not dispose of batteries in household waste or fire.
- **Children and Pets:** Keep batteries out of reach of children and pets.
- **Leakage:** If the battery leaks, avoid contact with the fluid. If contact occurs, rinse thoroughly with water and seek medical attention.

## 8. WARRANTY AND SUPPORT

---

AOLIKES stands behind the quality of its products. For warranty information, technical support, or any questions regarding your AOLIKES 602030 replacement battery, please contact the seller or manufacturer directly through your purchase platform.

When contacting support, please have your product model number (602030) and purchase details readily available.

**Manufacturer:** AOLIKES

**Seller:** AOLIKES-US (via Amazon)