



[Manuals.plus](#) /

› [Fluest](#) /

› Fluest Queen Bed Frame FL24-0473D User Manual

Fluest FL24-0473D

Fluest Queen Bed Frame FL24-0473D User Manual

Model: FL24-0473D

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Fluest Queen Bed Frame Model FL24-0473D. Please read all instructions carefully before assembly and use to ensure safe and proper functioning of the product. Keep this manual for future reference.

IMPORTANT SAFETY INFORMATION

- Exercise caution around sharp edges during assembly and use.
- Do not load the bed frame with more than 800 pounds. Exceeding this weight limit may cause damage to the frame and potential injury.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Keep small parts away from children during assembly to prevent choking hazards.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the detailed installation manual included in the box for a complete list of parts.



Image: Various parts and components of the Fluest Queen Bed Frame.

ASSEMBLY INSTRUCTIONS

The Fluest Queen Bed Frame is designed for straightforward assembly. All necessary parts and a detailed installation manual are included in one package. Assembly typically takes an adult about half an hour.

General Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the numbered labels and the provided manual.
3. Follow the step-by-step instructions in the included manual to connect the frame sections.
4. Attach the upholstered headboard to the main frame.
5. Install the metal slats and secure them.
6. Assemble and insert the two storage drawers under the bed frame.
7. Ensure all connections are tight and stable before placing a mattress on the frame.



2 Oversize Storage Drawers with flexible Rollers

Image: Detailed view of the bed frame's metal structure and headboard.

Assembly Overview Video:

Your browser does not support the video tag.

Video: An overview of the Fluest Queen Bed Frame, highlighting its features and assembly process. This video demonstrates the upholstered headboard, charging station, and storage drawers.

OPERATING INSTRUCTIONS

Charging Station Usage:

The headboard features a built-in charging station with 2 AC outlets, 1 USB port, and 1 Type-C port. To use, simply plug your devices into the appropriate ports. Ensure the bed frame is connected to a power source.



Image: Fluest Queen Bed Frame with charging station on the headboard.

Storage Drawers:

The two spacious drawers located under the bed frame are designed for organizing bedding, off-season clothing, or other items. They feature smooth-rolling wheels for easy access. To open a drawer, simply lift it slightly to disengage the screw mechanism and pull it out. Push it back in and lower it to secure.



Image: Storage drawers under the bed frame.

Under-Bed Storage:

In addition to the drawers, the bed frame provides 12.6 inches of clearance underneath, offering extra room for suitcases or other essentials.



Image: Under-bed storage space.

MAINTENANCE

Cleaning:

- **Metal Frame:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Upholstered Headboard:** For the faux leather headboard, gently wipe with a damp cloth and mild soap if necessary. Test any cleaning solution on an inconspicuous area first.

Regular Checks:

- Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as needed to maintain stability and prevent noise.
- Check the EVA foam strips on the slats for any wear or damage. These strips are crucial for noise reduction.

TROUBLESHOOTING

Noise Issues:

If you experience squeaking or noise, check the following:

- Ensure all bolts and screws are securely tightened. Loose connections are a common cause of noise.
- Verify that the EVA foam strips are correctly positioned on the metal slats. These strips are designed to reduce friction and noise between the mattress and the frame.



Image: EVA foam strips for noise reduction.

Mattress Sliding:

The bed frame features an embedded design to prevent the mattress from sliding. If your mattress is still sliding, ensure it is properly centered and fits within the frame's dimensions.

Drawer Operation:

If a drawer is difficult to open or close, check for any obstructions. Ensure the screw mechanism is properly aligned when closing the drawer.

SPECIFICATIONS

Feature	Detail
Model Number	FL24-0473D
Size	Queen
Product Dimensions	81"L x 61"W x 41"H
Color	Black
Material	Metal, Faux Leather (Headboard)
Weight Capacity	Up to 800 lbs
Special Features	Charging Station, 2 Storage Drawers, Noise-Reducing Foam, Embedded Mattress Design, Curved Edges
Box Spring Required	No
Assembly Required	Yes
Item Weight	50 pounds

QUEEN SIZE



Image: Dimensional diagram of the Fluest Queen Bed Frame.

WARRANTY INFORMATION

For specific warranty details regarding your Fluest Queen Bed Frame, please refer to the documentation included with your purchase or contact Fluest customer support directly. Standard warranties typically cover manufacturing defects for a limited period from the date of purchase.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Fluest customer support. You can typically find contact information on the product packaging or the official Fluest website.

For general inquiries or to explore other products, visit the [Fluest Store on Amazon](#).