

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SENIX](#) /

› [SENIX 60V Max 810 CFM Cordless Brushless Electric Leaf Blower Instruction Manual](#)

SENIX BLAX6-M1

SENIX 60V Max 810 CFM Cordless Brushless Electric Leaf Blower Instruction Manual

Model: BLAX6-M1

1. INTRODUCTION

Thank you for choosing the SENIX 60V Max Cordless Brushless Electric Leaf Blower. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new tool. Please read all instructions carefully before use and retain this manual for future reference.



The SENIX 60V Max Cordless Leaf Blower, including the main unit, 4.0Ah battery, and charger, ready for use.

Official product video showcasing the SENIX 60V MAX 810 CFM Leaf Blower in action.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Keep the work area clean and well-lit. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Keep children and bystanders away while operating a power tool. Always wear appropriate personal protective equipment, including eye protection, hearing protection, and sturdy footwear.

3. PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- SENIX 60V Max Cordless Leaf Blower Unit
- Blower Tube
- Blower Nozzle
- 60V 4.0Ah Lithium-Ion Battery
- 3A Battery Charger
- Instruction Manual

4. PRODUCT FEATURES


- **High Performance:** Up to 810 CFM (Cubic Feet per Minute) air volume and 170 MPH (Miles Per Hour) air speed for efficient clearing of leaves and debris.
- **Brushless Motor:** High-intensity brushless motor provides maximum power, extended runtime, and longer motor life.
- **Adjustable Speed:** Variable speed setting with stepless control allows for precise blowing. Cruise control function for extended use.
- **X6 Battery System:** 60V 4.0Ah Lithium-Ion battery with charge level indicator. Compatible with all SENIX X6 power tools.
- **Ergonomic Design:** Lightweight (12.5 lbs) and balanced design for comfortable, one-handed operation.



LIGHTWEIGHT & ERGONOMIC HANDLE DESIGN

A user demonstrating the lightweight (5.5 lbs) and ergonomic handle design of the SENIX Leaf Blower, emphasizing comfort and ease of use.

60V HIGH-PERFORMANCE POWERFUL BLOWER



FUNCTION COMPARISON

Brushless Motor
Stepless Speed
4000MAH
810CFM
170MPH

Motor Design
Speed Mode
Battery Capacity
Air Flow Capacity
Maximum Air Speed

Ordinary Motor
2 Speed Mode
2000MAH
360CFM
110MPH

A side-by-side comparison highlighting the SENIX 60V blower's brushless motor, stepless speed, 4000mAh battery, 810 CFM, and 170 MPH, versus an ordinary blower's specifications.

5. SETUP AND ASSEMBLY

Follow these steps to assemble your leaf blower:

- Connect the Blower Tube:** Align the blower tube with the main unit's air outlet and push until it clicks into place. Twist slightly to secure.
- Attach the Blower Nozzle:** Connect the blower nozzle to the end of the blower tube, ensuring it is firmly attached.
- Install the Battery:** Slide the fully charged 60V 4.0Ah battery into the battery slot on the main unit until it locks securely.

3 STEPS TO INSTALL



A clear, step-by-step visual guide showing how to connect the blower tube and machine, install the battery, and connect the blower nozzle and tube.

Official installation video for the SENIX 810CFM Leaf Blower, demonstrating the assembly process.

6. OPERATING INSTRUCTIONS

6.1 Battery Charging and Status

The 60V 4.0Ah Lithium-Ion battery features a charge level indicator. To charge, connect the battery to the provided 3A charger. The LED indicators will show the charging progress. Ensure the battery is fully charged before first use.

60V 4000MAH LITHIUM BATTERY

Longer working hours

Battery
LED
indicator
light:
25%
50%
75%
100%



The 60V 4000mAh Lithium Battery and its charger, illustrating the LED indicator lights for 25%, 50%, 75%, and 100% charge levels.

6.2 Powering On/Off and Speed Control

To power on the blower, press and hold the power button. The blower features a variable speed setting with stepless control. Adjust the dial to increase or decrease the airflow. For sustained operation at a desired speed, engage the cruise control function. Select higher speeds for heavy or wet debris and lower speeds for delicate areas.



STEPLESS SPEED

The transmission ratio can be continuously adjusted through the cooperation of the main and driven wheels, achieving the best match between the transmission system and the engine.

A user's hand operating the SENIX Leaf Blower, with an inset diagram explaining the stepless speed transmission ratio for continuous adjustment.

6.3 Usage Scenarios

The SENIX Leaf Blower is versatile for various outdoor tasks:

- **Leaf Cleaning:** Efficiently clear dry or wet leaves from lawns, patios, and driveways.
- **Dust Blowing:** Remove dust and light debris from workshops, garages, and other surfaces.
- **Grass Cleaning:** Clear grass clippings after mowing.
- **Snow Blowing:** Suitable for blowing light, powdery snow from pathways and small areas.

MEET VARIOUS SCENARIOS



SNOW BLOWING



DUST BLOWING



LEAF CLEANING



GRASS CLEANING

A collage of images demonstrating the versatility of the SENIX Leaf Blower for different tasks, including clearing snow, dust, leaves, and grass clippings.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your blower:

- **Battery Care:** Store batteries in a cool, dry place. Charge fully before storage and periodically during long storage periods.
- **Cleaning:** Keep the air intake vents clear of debris to prevent overheating. Wipe the exterior with a damp cloth. Do not use harsh chemicals.
- **Storage:** Store the blower in a dry, secure location away from children and unauthorized users.

8. TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

- **Blower not starting:** Ensure the battery is fully charged and properly installed. Check that the power button is pressed correctly.
- **Reduced airflow:** Check for blockages in the blower tube or nozzle. Ensure air intake vents are clear.

- **Short battery life:** Ensure the battery is fully charged. Operating at maximum speed or in turbo mode will reduce runtime.

9. SPECIFICATIONS

Feature	Specification
Brand	SENIX
Model Name	X6 Leaf Blower
Item Model Number	BLAX6-M1
Power Source	Battery Powered (60V Max)
Motor Type	Brushless, 1300W
Air Volume	Up to 810 CFM
Air Speed	Up to 170 MPH
Speed Control	Stepless Variable Speed, Cruise Control
Battery	1 x 60V 4.0Ah Lithium Ion (included)
Charger	3A Fast Charger (included)
Item Weight	12.5 Pounds
Product Dimensions	34.1" L x 7.7" W x 10.4" H

10. WARRANTY AND SUPPORT

SENIX offers a 5-year warranty on the tool and a 3-year warranty on the battery. For warranty claims, technical support, or replacement parts, please contact SENIX customer service through their official website or the retailer where the product was purchased. Please have your model number (BLAX6-M1) and proof of purchase ready.




60V 4.0Ah BATTERY & CHARGER

**BUSHLESS
MOTOR**

**HIGH-POWER
AIRFLOW**


**810CFM
170MPH**



34.1*7.7*10.4inch


An illustration of the SENIX 60V Max Leaf Blower showing its dimensions (34.1"x7.7"x10.4" inches), 5-year tool warranty, and 3-year battery warranty.

Related Documents - BLAX6-M1



[SENIX BLAX6-M1 60V Cordless Leaf Blower Instruction Manual](#)

Comprehensive instruction manual for the SENIX BLAX6-M1 60V Cordless Leaf Blower, covering safety guidelines, unit identification, specifications, assembly, operation, maintenance, troubleshooting, and warranty information.

	<p>SENIX BLAX6-M1 Cordless Leaf Blower Instruction Manual</p> <p>Comprehensive instruction manual for the SENIX BLAX6-M1 cordless leaf blower, covering safety, assembly, operation, maintenance, and warranty information. Includes detailed descriptions of parts and procedures.</p>
	<p>SENIX BLAX2-M2 Cordless Leaf Blower Instruction Manual</p> <p>Comprehensive instruction manual for the SENIX BLAX2-M2 Cordless Leaf Blower, covering essential safety guidelines, unit identification, specifications, assembly procedures, operation instructions, maintenance, troubleshooting, and warranty information.</p>
	<p>SENIX X2 20V Max* Cordless Leaf Blower (BLAX2-M3) - Instruction Manual</p> <p>Comprehensive instruction manual for the SENIX X2 20V Max* Cordless Leaf Blower (Model BLAX2-M3). Covers safety instructions, product features, specifications, assembly, operation, maintenance, troubleshooting, and warranty information.</p>
	<p>SENIX BLAX2-M2 40V Cordless Leaf Blower Instruction Manual</p> <p>Comprehensive instruction manual for the SENIX BLAX2-M2 40V Cordless Leaf Blower, covering safety, assembly, operation, maintenance, troubleshooting, and warranty information.</p>
	<p>SENIX BLVE22-M-EU Electric Leaf Blower/Vacuum Operator's Manual</p> <p>Operator's manual for the SENIX BLVE22-M-EU Electric Leaf Blower/Vacuum. Provides comprehensive safety instructions, assembly guides, operating procedures, maintenance tips, troubleshooting advice, and a detailed parts list for this 2200W garden tool.</p>