

## TAMAGOTCHI 43423

# Tamagotchi Bandai Paradise Cielo Virtual Pet Instruction Manual

Model: 43423

## INTRODUCTION

Welcome to the world of Tamagotchi Paradise Cielo! This electronic virtual pet allows you to raise and care for your own digital companion. This manual provides essential information on setting up, operating, and maintaining your Tamagotchi device to ensure a fulfilling experience. The Paradise Cielo model features a unique Sky environment and interactive elements designed for engaging gameplay.

## SAFETY INFORMATION

### Warning:

- Not suitable for children under 36 months due to small parts.
- Contains small parts that can be swallowed. Adult supervision is recommended for young children.
- Always follow battery safety guidelines. Do not mix old and new batteries, or different types of batteries.

## PACKAGE CONTENTS

- 1 x Tamagotchi Paradise Cielo Device (Model 43423)
- Instruction Manual (this document)

Note: 2 x AAA batteries are required and sold separately.

## SETUP

### 1. Installing Batteries



## Zoom Wheel Functionality


The Tamagotchi Paradise device features a unique Zoom Wheel. Turn the wheel to navigate through different environments and levels of interaction, from the microscopic "Tama Cellula" to the expansive "Tama Spazio" (Tama Space). This allows for an immersive game experience as you explore new worlds and care for your Tamagotchi.



This diagram demonstrates the Zoom Wheel, allowing you to care for your Tamagotchi across four levels: Tama Cellula (Cell), Tama (Pet), Tama Campo (Field), and Tama Spazio (Space), enabling exploration of different worlds.

The Paradise Cielo model starts your adventure in the Sky environment. As your character grows and you progress, you will unlock other fields and areas to explore.

# VIAGGIA OLTRE!




## FAI IL PIENO ED ESPLORA NUOVI PIANETI TAMA!

This image highlights the "Travel Beyond" feature, where the Zoom Wheel allows you to explore new Tama planets and expand your virtual world.

### Connecting with Friends

You can connect your Tamagotchi Paradise Cielo device with a friend's compatible device. This allows your virtual pets to interact, fostering friendship or even friendly confrontation. Explore new possibilities by connecting and creating hybrid characters.

# GIOCA CON GLI AMICI!



## CONNETTITI, CREA IBRIDI & DIVERTITI CON GLI AMICI!

This image shows two Tamagotchi devices connected, illustrating how you can play with friends, connect, create hybrids, and enjoy interactive experiences together.

### Mini-Games and Laboratory Mode

Engage in various mini-games available through the Laboratory Mode. Playing mini-games allows you to earn Gotchi currency, which can be used to purchase items and customize your Tamagotchi's environment. These activities provide fun and exclusive functions to enhance your pet care experience.

# MINI-GIOCHI, MAXI PREMI!



**GIOCA,  
VINCI  
& SBLOCCA  
FUNZIONI  
ESCLUSIVE!**

This image depicts three Tamagotchi devices showcasing various mini-games, emphasizing the opportunity to play, win, and unlock exclusive features.

## Character Evolution and Customization

The way you care for your Tamagotchi character, including feeding and interaction, influences its evolution. You can raise over 50 different characters from 12 species. Additionally, you can combine your virtual animals to create new ones. The Paradise series allows you to customize your Tama world in each version, including the Paradise Sky model.

# PERSONALIZZA TUTTO!

## CREA IL TUO MONDO TAMA IN OGNI VERSIONE



TERRA



CIELO



ACQUA

This image illustrates the customization options across different Tamagotchi Paradise versions (Earth, Sky, Water), allowing users to create their unique Tama world.

## MAINTENANCE

### Cleaning Your Device

To clean your Tamagotchi device, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water, as this can cause damage.

### Storage

When not in use for extended periods, remove the batteries to prevent leakage and store the device in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

- **Device not turning on:** Check if batteries are installed correctly and are not depleted. Replace with fresh AAA batteries if necessary.
- **Screen is blank or frozen:** Try removing and reinserting the batteries. If the issue persists, contact customer support.

- **Tamagotchi is unresponsive:** Ensure you are interacting with the device regularly. If the pet is neglected, it may become sick or leave.

## SPECIFICATIONS

<b>Model Number</b>	43423
<b>Brand</b>	TAMAGOTCHI
<b>Sub Brand</b>	PARADISE
<b>Color</b>	Purple and Pink
<b>Material</b>	Plastic
<b>Device Dimensions</b>	50 x 20 x 100 millimeters
<b>Packaging Dimensions</b>	5L x 14W x 22H Centimetres
<b>Item Weight</b>	0.3 Kilograms
<b>Power Source</b>	2 x AAA batteries (sold separately)
<b>Display Type</b>	Digital
<b>Operation Mode</b>	Manual (Button Control)
<b>Recommended Age</b>	8 - 99 years
<b>Release Date</b>	July 12, 2025

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Bandai website or contact your local retailer. Keep your proof of purchase for any warranty claims.

For additional resources and community support, you may find online forums and fan communities dedicated to Tamagotchi products helpful.