Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pokin 06900

Pokin 06900 Probe Temperature Control Thermostat Cord Instruction Manual

Model: 06900

Introduction

This manual provides instructions for the proper installation, operation, and maintenance of your Pokin 06900 Probe Temperature Control Thermostat Cord. Please read this manual thoroughly before use to ensure safe and efficient operation.

Product Overview

The Pokin 06900 Probe Temperature Control Thermostat Cord is a replacement part designed to provide precise temperature control for various Presto kitchen appliances, including electric skillets, griddles, and frypans. It features a probe control with 1 & 3/8" spacing between terminals for compatibility with specific Presto models.



Image: The Pokin 06900 Probe Temperature Control Thermostat Cord, showing the temperature dial, probe, and power plug.

Compatibility

This thermostat cord is compatible with a wide range of Presto griddles, frypans, and other kitchen appliances. Ensure your appliance requires a probe control with 1 & 3/8" spacing between terminals. Refer to the list below for specific compatible Presto models:

- 0216001, 0590001, 0662001, 0662502, 0662602, 0671109, 0671310, 0684001, 0684101, 0684201, 0685001, 0685101, 0685202, 0685503, 0685607, 0685704, 0685806, 0686001
- 0702306, 0702406, 0703016, 0703207, 0703716, 0703807, 0703907, 0704205, 0704405, 0704506, 0704512, 0704608, 0704609, 0704610, 0704707, 0704717, 0705501, 0705606
- 0706201, 0707103, 0707202, 0707304, 0708001, 0711107, 0711308, 0711508, 0711609, 0711709, 0711711, 0711909, 0721101, 0721103, 0901001, 0902001



Image: The 06900 thermostat cord shown alongside a Presto griddle, illustrating its compatibility.



Image: Close-up view of the probe control, highlighting the 1 & 3/8 inch spacing between terminals for proper fit.



Image: The thermostat cord shown with a Presto deep fryer and an electric skillet, demonstrating broad compatibility.

Setup and Installation

The 06900 Probe Temperature Control Thermostat Cord features a simple plug-and-play design for easy installation.

1. **Verify Compatibility:** Before installation, ensure your Presto appliance requires a probe control with 1 & 3/8" spacing between terminals and is listed in the compatible models section.
2. **Power Off:** Ensure the appliance is unplugged from the electrical outlet before attempting to install or remove the thermostat cord.
3. **Insert Probe:** Align the probe of the thermostat cord with the receptacle on your Presto appliance. Gently push the probe into the receptacle until it is firmly seated. The connection should be secure.
4. **Connect to Power:** Once the probe is securely connected to the appliance, plug the power cord into a standard electrical outlet.



Image: The thermostat cord with its plug and probe, illustrating its simple plug-and-play design for straightforward installation.

Operating Instructions

The 06900 Probe Temperature Control Thermostat Cord allows for precise temperature regulation of your Presto appliance.

1. **Set Temperature:** Rotate the dial on the thermostat cord to select the desired cooking temperature. The dial typically includes settings such as "WARM," "200," "250," "300," "350," and "400" degrees Fahrenheit.
2. **Preheating:** Allow the appliance to preheat to the selected temperature. A pilot light on the thermostat cord may indicate when the desired temperature has been reached or when the heating element is active.
3. **Cooking:** Place food onto the preheated appliance. Monitor the cooking process and adjust the temperature as needed.
4. **After Use:** Once cooking is complete, turn the dial to the "OFF" position and unplug the cord from the electrical outlet. Allow the appliance to cool completely before cleaning.



Image: A Presto skillet with food cooking, demonstrating the use of the thermostat cord for precise temperature control.

Maintenance

Proper maintenance ensures the longevity and performance of your thermostat cord.

- **Cleaning:** Before cleaning, always ensure the thermostat cord is unplugged and completely cool. Wipe the exterior of the control unit and the probe with a damp cloth. Do not immerse the control unit in water or any other liquid.
- **Storage:** Store the cord in a dry place, away from extreme temperatures and direct sunlight. Avoid wrapping the cord too tightly to prevent damage.
- **Inspection:** Periodically inspect the cord for any signs of damage, such as cuts, fraying, or exposed wires. If damage is observed, discontinue use and replace the cord.

Troubleshooting

If you encounter issues with your 06900 Probe Temperature Control Thermostat Cord, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not heat up.	◦ Cord not properly plugged in. ◦ Probe not fully inserted into appliance. ◦ Electrical outlet malfunction. ◦ Cord damage.	◦ Ensure both ends of the cord are securely plugged in. ◦ Push the probe firmly into the appliance receptacle. ◦ Test the outlet with another device. ◦ Inspect the cord for damage; replace if necessary.
Temperature is inaccurate or inconsistent.	◦ Probe not making full contact. ◦ Internal component issue.	◦ Ensure the probe is clean and fully inserted. ◦ If the issue persists, the cord may need replacement.

Specifications

- **Model Number:** 06900
- **Brand:** Pokin
- **Probe Spacing:** 1 & 3/8 inches between terminals
- **Package Dimensions:** 7.01 x 2.68 x 2.28 inches
- **Item Weight:** 6.4 ounces
- **Material:** Durable construction, 100% copper wiring
- **Compatibility:** Designed for over 40 specific Presto models (refer to Compatibility section)

Warranty and Support

This product is designed for durability and reliability. While specific warranty details are not provided in this manual, Pokin offers after-sales support.
If you have any questions, experience issues, or require a replacement, please contact Pokin customer service. They aim to respond within 24 hours to assist with problem resolution.
For support, please refer to the contact information provided with your purchase or visit the official Pokin store page on Amazon: Pokin Store

© 2025 Pokin. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F93VWX6S

More documents and user manuals: **https://manuals.plus/**