XINFUTE J1-06(E) DG11J1-06

XINFUTE J1-06(E) DG11J1-06 AC Remote Control User Manual

Model: J1-06(E) DG11J1-06

Introduction

This manual provides comprehensive instructions for the XINFUTE J1-06(E) DG11J1-06 AC Remote Control. This remote is designed as a replacement for compatible Hisense Nihon air conditioning units, specifically model DG11J1-08. Please read this manual carefully before using the remote control to ensure proper operation and longevity.



Image: Back view of the remote control, displaying the model number J1-06(E).

Setup

Battery Installation

The XINFUTE J1-06(E) DG11J1-06 AC Remote Control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for use with compatible Hisense Nihon AC units.



Image: Front view of the remote control, showing the button layout and LCD display.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the AC unit.

Button Functions:

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **FAN:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **▲ / ▼ (Temperature Up/Down):** Adjusts the desired temperature setting.
- **SWING:** Controls the louver swing function for air direction.
- **SLEEP:** Activates or deactivates the sleep mode, which adjusts temperature for comfort during sleep.
- **SUPER:** Engages a powerful cooling or heating mode for rapid temperature change.
- **SMART:** Activates an intelligent mode that automatically selects the best operating settings.
- **IFEEL:** Activates the "I Feel" function, which senses the temperature at the remote's location.
- **DIMMER:** Adjusts the brightness of the AC unit's display.
- **TIMER ON:** Sets a timer for the AC unit to turn on automatically.
- **TIMER OFF:** Sets a timer for the AC unit to turn off automatically.
- **CLOCK:** Sets the current time on the remote control's display.

Maintenance

Battery Replacement

Replace batteries when the remote control's display becomes dim or the remote fails to operate the AC unit. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the AC unit's receiver.
  - Confirm the remote is pointed directly at the AC unit.
- **AC unit not responding to specific commands:**
  - Verify that the remote control model J1-06(E) DG11J1-06 is compatible with your specific Hisense Nihon AC unit model DG11J1-08.
  - Some functions may be specific to certain AC unit models.

Specifications

Feature	Detail
Model Number	J1-06(E) DG11J1-06
Compatible AC Model	Hisense Nihon DG11J1-08
Brand	XINFUTE
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Product Dimensions	Approximately 4 x 3 x 1 inches
Item Weight	Approximately 2.82 ounces
Special Feature	Ergonomic design

Warranty Information

XINFUTE provides a one-year warranty on all purchases of this remote control. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or issues regarding your XINFUTE J1-06(E) DG11J1-06 AC Remote Control, please contact XINFUTE customer service. If you are not satisfied with your purchase, you may contact us within 24 hours of receipt for assistance.
For further support, please refer to the official XINFUTE store or contact information provided at the point of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question