

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TECKNET](#) /

› [TECKNET Wireless Backlit Keyboard and Mouse Combo User Manual](#)

TECKNET TECKNET Wireless Backlit Keyboard and Mouse Combo

TECKNET Wireless Backlit Keyboard and Mouse Combo User Manual

Model: TECKNET Wireless Backlit Keyboard and Mouse Combo

1. INTRODUCTION

Thank you for choosing the TECKNET Wireless Backlit Keyboard and Mouse Combo. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new wireless peripheral set. This combo offers a comfortable typing experience, adjustable backlighting, and broad compatibility for various operating systems.



Image 1.1: The TECKNET Wireless Backlit Keyboard and Mouse Combo, featuring a black keyboard with illuminated keys and a matching black wireless mouse, alongside the USB receiver.

2. PACKAGE CONTENTS

- TECKNET Wireless Backlit Keyboard
- TECKNET Wireless Mouse
- 2-in-1 USB Receiver (stored inside the mouse)
- USB-C Charging Cable



Image 2.1: The TECKNET keyboard, mouse, USB charging cable, and user manual laid out on a marble surface, indicating the items included in the package.

3. SETUP INSTRUCTIONS

Follow these steps to set up your TECKNET Wireless Keyboard and Mouse Combo:

1. **Charge the Devices:** Before first use, ensure both the keyboard and mouse are fully charged using the provided USB-C cable. The keyboard and mouse have built-in rechargeable batteries.
2. **Locate the USB Receiver:** The 2-in-1 USB receiver is conveniently stored in a compartment on the underside of the mouse. Gently open the compartment and remove the receiver.
3. **Connect the Receiver:** Insert the USB receiver into an available USB-A port on your computer (desktop, laptop, or tablet). If your device only has USB-C ports, use a USB-A to USB-C adapter (not included).
4. **Power On:** Locate the power switch on the top right edge of the keyboard and on the underside of the mouse. Slide both switches to the "ON" position.
5. **Automatic Connection:** The keyboard and mouse should automatically connect to your device. No additional drivers are typically required for Windows, Mac, or Android systems.



Image 3.1: A visual representation of the easy plug-and-play setup, showing the keyboard and mouse connecting wirelessly via a 2.4GHz USB receiver to a computer, highlighting the 33ft wireless range.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Features

- **Scissor-Switch Keys:** Designed for a comfortable, responsive, and quiet typing experience.
- **Ergonomic Tilt:** Features a 7% ergonomic tilt angle to reduce wrist strain during extended use.
- **Compact Design:** The slim profile (15 x 5.35 x 0.78 inches) saves desk space and enhances portability.



Image 4.1: A close-up of the keyboard highlighting the scissor-switch key mechanism and the 7-degree ergonomic tilt for comfortable and quiet typing.

4.2 Mouse Features

- **Ultra-Thin Design:** The mouse is designed to be slim and lightweight, ideal for portability.
- **Silent Clicks:** Left and right buttons feature silent click technology to minimize noise.
- **Plug and Play:** Connects instantly via the shared USB receiver without additional setup.



Image 4.2: The ergonomic design of the mouse, illustrating its sleek curvature for comfortable hand placement and silent click functionality.

4.3 Backlight Control

The keyboard features adjustable backlighting for enhanced visibility in various lighting conditions.

- **Change Backlight Color:** Press **Fn + Alt** simultaneously to cycle through 7 vibrant color options.
- **Adjust Brightness:** Press **Fn + Light Bulb Icon Key** to cycle through 4 adjustable brightness levels (High, Medium, Low, Off).



Image 4.3: A visual guide demonstrating how to switch between 7 backlight colors using Fn+Alt and adjust 4 brightness levels using the Fn+Light Bulb key.

4.4 System Switching

The keyboard is compatible with multiple operating systems. Switch between layouts as needed:

- **Mac Layout:** Press **Fn + Q**
- **Windows Layout:** Press **Fn + E**
- **Android Layout:** Press **Fn + W**



Image 4.4: The keyboard and mouse combo connected to various devices (tablet, desktop, laptop) demonstrating wide compatibility with Android, Windows, and Mac operating systems.

4.5 Function Keys

The keyboard includes 13 function keys for quick access to common commands. To use these, press the **Fn** key in combination with the desired function key.

Keyboard Function Key Combinations

Combination	Function
Fn + F1	Mute/Unmute
Fn + F2	Volume Down
Fn + F3	Volume Up
Fn + F4	Previous Track
Fn + F5	Play/Pause
Fn + F6	Next Track

Combination	Function
Fn + F7	Decrease Screen Brightness
Fn + F8	Increase Screen Brightness
Fn + F9	Select All
Fn + F10	Copy
Fn + F11	Paste
Fn + F12	Cut
Fn + Delete	Lock/Unlock Fn Key




Image 4.5: An illustration of the keyboard highlighting the F1-F12 keys and their corresponding functions when used with the Fn key, such as volume control, media playback, and screen brightness adjustment.

5. POWER MANAGEMENT AND BATTERY LIFE

The combo is designed for energy efficiency and extended battery life.

- **Rechargeable Batteries:** Both the keyboard and mouse feature built-in rechargeable batteries.
- **Auto-Sleep Mode:** To conserve power, the keyboard enters auto-sleep mode after 10 minutes of inactivity. Press any key to wake it up. The keyboard backlight automatically turns off after 1 minute of inactivity.
- **Extended Standby:** The keyboard supports up to 180 days of standby time.
- **Low Battery Alert:** A low battery indicator will flash to notify you when charging is required.
- **Optimization Tip:** For maximum battery life, especially during travel, set the backlight to the lowest brightness level or turn it off when not needed.



Image 5.1: The keyboard and mouse connected via charging cables, illustrating features like automatic sleep mode, memory function for settings, low battery alert, and an impressive 180-day standby time.

6. MAINTENANCE

To ensure the longevity and optimal performance of your TECKNET Wireless Keyboard and Mouse Combo, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Charging:** Charge the devices regularly, especially when the low battery indicator flashes. Avoid completely draining the battery frequently to prolong its lifespan.
- **Storage:** When not in use for extended periods, turn off both the keyboard and mouse to conserve battery. Store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **USB Receiver:** Keep the USB receiver in a safe place, preferably in its designated storage slot within the mouse, to prevent loss or damage.

7. TROUBLESHOOTING

If you encounter issues with your TECKNET Wireless Keyboard and Mouse Combo, refer to the following troubleshooting tips:

- **No Connection/Lag:**

- Ensure both the keyboard and mouse are powered on.
- Verify the USB receiver is securely plugged into a working USB port on your computer.
- Check the battery levels of both devices and recharge if necessary.
- Move the keyboard and mouse closer to the USB receiver (within 33 feet/10 meters).
- Avoid placing the receiver near other wireless devices or large metal objects that might cause interference.
- Try plugging the USB receiver into a different USB port on your computer.

- **Keys Not Responding/Double Presses:**

- Recharge the keyboard battery. Low battery can affect key responsiveness.
- Ensure no debris is lodged under the keys. Gently clean the keyboard.
- Restart your computer and reconnect the USB receiver.

- **Mouse Not Moving/Erratic Cursor:**

- Check the mouse battery level and recharge if needed.
- Ensure the mouse optical sensor is clean and free from obstructions.
- Use the mouse on a suitable surface; reflective or uneven surfaces can affect tracking.
- Reconnect the USB receiver.

- **Backlight Not Working:**

- Ensure the keyboard is charged.
- Press **Fn + Light Bulb Icon Key** to adjust brightness or turn the backlight on.

8. SPECIFICATIONS

Product Specifications

Feature	Detail
Brand	TECKNET
Model	Wireless Backlit Keyboard and Mouse Combo
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Wireless Range	Up to 33 feet (10 meters)
Keyboard Backlight	7 Colors, 4 Brightness Levels
Keyboard Key Type	Scissor-Switch Low-Profile
Keyboard Dimensions	Approximately 15 x 5.35 x 0.78 inches
Item Weight	1.72 pounds (combo)
Batteries	Rechargeable (1 Nonstandard Battery included for each device)

Feature	Detail
Standby Time (Keyboard)	Up to 180 days
Compatible Devices	Laptop, Personal Computer, Tablet (Windows, Android, Mac)

9. WARRANTY AND SUPPORT

TECKNET products are designed to meet high-quality standards. For warranty information or technical support, please refer to the warranty card included in your package or visit the official TECKNET website. Please have your product model and purchase details ready when contacting support.

For further assistance, you may also refer to the product page on Amazon:[TECKNET Wireless Keyboard and Mouse Combo](#)