



Manuals.plus /

› FEETMOR /

› FEETMOR FH02 Heated Gloves User Manual

FEETMOR FH02

FEETMOR FH02 Heated Gloves User Manual

MODEL: FH02

Brand: FEETMOR

Introduction

Thank you for choosing FEETMOR Heated Gloves. These gloves are designed to provide warmth and comfort in cold weather conditions, featuring dual heating elements and a rechargeable battery system. This manual provides essential information for the proper setup, operation, and maintenance of your gloves.

Key Features:

- **Enhanced Heating Area:** Integrated heating elements cover the entire hand, including the palm, back, and fingertips, for comprehensive warmth.
- **Adjustable Heat Settings:** Six heat settings with dual-button control allow independent or combined heating of the palm and back of the hand.
- **Upgraded Battery System:** Equipped with USB-C 7.4V 22.2Wh Li-Polymer batteries and a 20W PD adapter for efficient charging and stable performance.
- **Touchscreen Compatibility:** Thumb and index fingertips are designed for use with touchscreen devices, allowing operation without removing gloves.
- **Durable and Comfortable Materials:** Constructed from 93% Polyester and 7% Elastane, offering lightweight comfort and weather resistance.

What's in the Box

- 1 Pair of FEETMOR Heated Gloves
- 1 Pair of 7.4V 3000mAh Li-Polymer Batteries
- 1 Type-C Charger
- 1 User Manual (this document)
- 1 Storage Box

Setup Instructions

1. Charging the Batteries

Before first use, fully charge both batteries. Use the provided Type-C charger and adapter. The indicator light on the battery will show charging status.

Video: Demonstrates the correct method for charging the glove batteries using the provided Type-C charger.

2. Installing the Batteries

Locate the zippered pocket on the cuff of each glove. Insert a fully charged battery into each pocket. Connect the glove's power cable to the battery. Securely close the zipper.

Video: Illustrates the process of installing the battery into the glove's designated pocket and connecting it to the power cable.

3. Sizing and Fit

Ensure a proper fit for optimal comfort and heating performance. Refer to the size chart below. If your hand measurement is between sizes, it is recommended to choose the larger size.

SIZE	INCH	CM
S	6.7-7.5	17-19
M	7.5-8.1	19-20.5
L	8.1-9.1	20.5-23
XL	9.1-10.1	23-25.5
XXL	10.1-10.7	25.5-27



Note:

If your size is on the larger side, it is recommended to choose a larger size.



Motorcycle



Ice fishing

Image: A size chart detailing hand circumference measurements in inches and centimeters for various glove sizes (S, M, L, XL, XXL).

Operating Instructions

1. Powering On/Off

Press and hold the power button on the cuff of each glove for approximately 3 seconds to turn the heating system on or off. The indicator lights will illuminate when powered on.

2. Adjusting Heat Settings

The gloves feature dual-button control for independent heating of the palm and back of the hand. Each zone has three heat levels:

- **Red Light:** High heat setting.
- **White Light:** Medium heat setting.
- **Green Light:** Low heat setting.

Press the respective button for the palm or back of the hand to cycle through the heat settings. You can operate both zones simultaneously or individually.



Image: A detailed view of the glove's control panel, showing the power buttons and indicator lights for heat settings.

3. Touchscreen Functionality

The thumb and index fingertips of these gloves are designed with touch-sensitive material. This allows you to operate most touchscreen devices, such as smartphones and tablets, without needing to remove your gloves.

Rechargeable Heated Gloves



Image: A user wearing the heated gloves successfully operating a smartphone, showcasing the touchscreen-compatible fingertips.

Maintenance

Cleaning Instructions

- Always remove batteries before cleaning.
- Hand wash the gloves gently with mild detergent in cold water. Do not machine wash, tumble dry, or bleach.
- Do not wring the gloves. Hang to air dry completely before reinserting batteries or storing.
- Avoid direct heat or sunlight during drying.

Storage

When not in use, store the gloves and batteries in a cool, dry place. Ensure batteries are partially charged (around 50%) before long-term storage to prolong their lifespan. Recharge batteries every 3-6 months during storage.

Troubleshooting

- **Gloves not heating:**
 - Ensure batteries are fully charged and correctly inserted into the glove pockets.
 - Verify that the power cable inside the glove is securely connected to the battery.
 - Press and hold the power button for 3 seconds to ensure the gloves are powered on. Check if indicator lights are illuminated.
- **Short battery life:**
 - Battery life varies with heat setting. Higher settings consume more power.
 - Ensure batteries are fully charged before each use.
 - Cold temperatures can reduce battery efficiency. Keep batteries as warm as possible when not in use.
 - Over time, battery capacity may decrease. Consider replacing batteries if performance significantly degrades.
- **Uneven heating:**
 - Check that both the palm and back heating elements are activated via the dual-button control.
 - Ensure the gloves fit properly. Loose gloves may not distribute heat effectively.
- **Touchscreen not responding:**
 - Ensure the touch-sensitive fingertips are clean and dry.
 - Apply firm, direct pressure with the fingertip to the screen.
 - Some screen protectors or device settings may affect touchscreen sensitivity.

Specifications

Feature	Detail
Brand	FEETMOR
Model Name	FH02
Material	Polyester (93%), Elastane (7%)
Battery Type	7.4V 3000mAh Li-Polymer
Charger	Type-C, 20W PD adapter
Heating Zones	Palm, Back of Hand, Fingertips
Heat Settings	6 (3 for palm, 3 for back)
Special Features	Adjustable Strap, Touch Screen Support, Windproof
Hand Orientation	Ambidextrous
Closure Type	Adjustable Strap
Intended Use	Skiing, Hiking, Cycling, Fishing, Outdoor Work

Warranty & Support

Warranty Information

FEETMOR Heated Gloves Model FH02 come with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance.

Customer Support

For any questions, concerns, or warranty claims, please contact FEETMOR customer support. Refer to the contact information provided on the product packaging or the official FEETMOR website. Please have your purchase receipt and product model number (FH02) ready when contacting support.

