

[Manuals.plus](#) /

› [Effireli](#) /

› Effireli KFR-26GW Replacement Remote for Changhong Air Conditioner User Manual

Effireli YK-KFR-26GW

Effireli KFR-26GW Replacement Remote User Manual

Model: YK-KFR-26GW

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Effireli KFR-26GW Replacement Remote Control for Changhong Air Conditioners. This remote is designed for direct use without the need for complex programming or setup, offering a convenient solution for controlling your air conditioning unit.

PRODUCT OVERVIEW



MODE HEALTH SLEEP



I FEEL V-SWEEP TIMER



CLEAN H-SWEEP DISPLAY

Figure 1: Effireli KFR-26GW Replacement Remote Control. This image displays the full remote control, featuring a rectangular LCD screen at the top showing temperature (26°C), mode indicators (snowflake for cooling, fan icon), and signal strength. Below the screen are three circular buttons labeled MODE, HEALTH, and SLEEP. A central directional pad includes a large circular power button in the middle, with 'TURBO' above it and 'SPEED' below. The directional arrows are for temperature or setting adjustments. Further down are three more circular buttons labeled I FEEL, V-SWEEP, and TIMER. The bottom row of circular buttons includes CLEAN, H-SWEEP, and DISPLAY. The remote is white with black text and icons.

SETUP AND INSTALLATION

The Effireli KFR-26GW Replacement Remote is designed for immediate use with compatible Changhong Air Conditioners. No programming or complex setup procedures are required.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote is ready for operation. Simply point it towards your Changhong Air Conditioner and begin using its functions.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions to effectively control your air conditioner.

Button Functions:

- **Power Button** (Central button with circle and vertical line): Turns the air conditioner ON or OFF.
- **MODE Button** (Top left circular button): Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto. The current mode is typically displayed on the remote's LCD screen.
- **HEALTH Button** (Top middle circular button with leaf icon): Activates or deactivates the health/purification function of the air conditioner, if available.
- **SLEEP Button** (Top right circular button with moon and stars icon): Engages the sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
- **TURBO Button** (Above central directional pad): Activates rapid cooling or heating for quick temperature changes.
- **SPEED Button** (Below central directional pad): Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Temperature Adjustment Arrows** (Up/Down arrows on central directional pad): Increases or decreases the set temperature.
- **I FEEL Button** (Bottom left circular button in middle row): Activates the "I Feel" function, where the remote's built-in sensor measures the ambient temperature and sends it to the AC unit for more precise temperature control around the remote's location.
- **V-SWEEP Button** (Bottom middle circular button in middle row with vertical fan icon): Controls the vertical swing of the air conditioner's louvers, directing airflow up and down.
- **TIMER Button** (Bottom right circular button in middle row with clock icon): Sets the timer for automatic ON/OFF operations. Refer to your air conditioner's manual for specific timer setting procedures.
- **CLEAN Button** (Bottom left circular button in bottom row with broom icon): Initiates the self-clean function of the air conditioner, if supported.
- **H-SWEEP Button** (Bottom middle circular button in bottom row with horizontal fan icon): Controls the horizontal swing of the air conditioner's louvers, directing airflow left and right.

- **DISPLAY Button** (Bottom right circular button in bottom row with light bulb icon): Toggles the display light on the air conditioner unit ON or OFF.

For detailed instructions on specific functions like setting the timer or advanced modes, please refer to the original user manual of your Changhong Air Conditioner unit.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your remote control.

Cleaning the Remote:

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- Ensure no liquid enters the remote's internal components.

Battery Replacement:

- Replace batteries when the remote's response becomes sluggish or the display fades.
- Always replace both batteries at the same time with new ones of the same type (AAA).
- Remove batteries if the remote will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

TROUBLESHOOTING

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote and the air conditioner's receiver.
 - Verify that the air conditioner unit is powered on and plugged in.
- **Limited range:**
 - Ensure the remote is pointed directly at the air conditioner's receiver.
 - Replace batteries if they are low.
 - Reduce the distance between the remote and the air conditioner.
- **Specific functions not working:**
 - Confirm that your Changhong Air Conditioner model supports the specific function (e.g., Health, Clean, I Feel).
 - Some functions may require the air conditioner to be in a specific mode (e.g., heating for heat-related functions).
- **Remote looks different from original:**
 - This remote is a replacement and may not be identical in appearance to your original remote, but it is designed to be functionally compatible with the listed models.
 - If your air conditioner model number is not KFR-26GW or if you are unsure about compatibility, please contact customer support for assistance.

SPECIFICATIONS

Brand	Effireli
Model Number	YK-KFR-26GW
Compatible Devices	Changhong Air Conditioner (KFR-26GW and other compatible models)
Connectivity Technology	Infrared (IR)
Special Feature	No Programming Required
Max Number of Supported Devices	1
Item Weight	2.11 ounces
Package Dimensions	6.3 x 1.57 x 0.59 inches
ASIN	B0F94GJKP1
Date First Available	May 19, 2025
Manufacturer	Effireli

WARRANTY AND SUPPORT

Your Effireli KFR-26GW Replacement Remote comes with a comprehensive warranty and support to ensure your satisfaction.

- **Money-Back Guarantee:** Enjoy a 30-day money-back guarantee from the date of purchase.
- **Warranty Period:** A 12-month warranty covers manufacturing defects from the date of purchase.
- **Returns and Exchanges:** Returns and exchanges are accepted within the warranty period for manufacturing defects.
- **Compatibility Inquiries:** If your air conditioner model number is not explicitly listed as compatible (e.g., KFR-26GW) or if your original remote appears significantly different, please contact us directly to confirm compatibility before purchase or for troubleshooting assistance.

For warranty claims, technical support, or compatibility questions, please refer to the contact information provided by your retailer or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F94GJKP1>

More documents and user manuals: <https://manuals.plus/>