

Thermaltake View i1470S-170 (V17S-B760-570-LCS)

Thermaltake LCGS View i1470S-170 Gaming Desktop User Manual

Model: View i1470S-170 (V17S-B760-570-LCS)

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Thermaltake LCGS View i1470S-170 Gaming Desktop. The View i1470S-170 is designed for high performance, featuring an Intel Core i7-14700F CPU, NVIDIA GeForce RTX 5070 graphics card, 32GB DDR5 6000MT/s RGB Memory, and a 1TB NVMe M.2 SSD. It comes pre-installed with Windows 11 and includes an ARGB Tower Air Cooler for efficient thermal management and visual appeal.

Key features include:

- Intel Core i7-14700F CPU and B760 chipset motherboard
- NVIDIA GeForce RTX 5070 graphics card with DisplayPort/HDMI outputs
- 32GB DDR5 6000MT/s RGB Memory
- 1TB NVMe M.2 Solid State Drive
- Integrated WiFi and Windows 11 operating system
- ARGB Tower Air Cooler for CPU cooling
- Front panel connectivity: 2x USB 3.0, 1x Headphone, 1x Microphone
- Panoramic viewing with front and side tempered glass panels

2. SETUP

2.1 Unpacking and Placement

Carefully remove the desktop from its packaging. Ensure all protective materials are removed from inside and outside the case. Place the desktop on a stable, flat surface with adequate ventilation around all sides.

2.2 Connecting Peripherals

Connect your monitor, keyboard, and mouse to the appropriate ports on the back and front of the desktop. For display, use the DisplayPort or HDMI outputs on the graphics card. The front panel provides convenient access to USB 3.0 ports, a headphone jack, and a microphone jack.



Image: Front panel connectivity, including USB 3.0, headphone, and microphone ports.

2.3 Power Connection and Initial Boot

Connect the power cable to the desktop's power supply unit and then to a wall outlet. Press the power button located on the front panel. The system will boot up, and you will be guided through the initial Windows 11 setup process. Follow the on-screen instructions to configure your operating system.

3. OPERATING

3.1 Power On/Off

To power on, press the power button once. To power off, click the Start button in Windows, then select Power > Shut down. Avoid directly holding the power button to shut down the system unless absolutely necessary, as this can lead to data loss or system instability.

3.2 Understanding Your System Components

Your desktop is equipped with high-performance components:

- **CPU:** Intel Core i7-14700F for powerful processing.
- **GPU:** NVIDIA GeForce RTX 5070 for advanced graphics performance.
- **Memory:** 32GB DDR5 6000MT/s RGB RAM for efficient multitasking.
- **Storage:** 1TB NVMe M.2 SSD for fast boot times and application loading.



Image: Internal components and key specifications.

3.3 Windows 11 Operating System

Your desktop runs on Windows 11, offering a modern interface and enhanced features. Familiarize yourself with the Start Menu, Taskbar, and Settings to customize your experience. Regular Windows updates are recommended for security and performance.

4. MAINTENANCE

4.1 Cleaning the Exterior

Use a soft, dry, anti-static cloth to clean the exterior surfaces, including the tempered glass panels. For stubborn smudges on glass, a small amount of glass cleaner applied to the cloth (not directly to the glass) can be used. Avoid abrasive cleaners.

4.2 Internal Cleaning and Airflow

Periodically, it is recommended to clean the internal components, especially the fans and heatsinks, to ensure optimal airflow and prevent dust buildup. Power off and unplug the desktop before opening the side panel. Use compressed air to gently remove dust from fans, CPU cooler, and GPU heatsink. Ensure proper airflow by keeping the desktop's vents unobstructed.




Image: Airflow diagram within the desktop case.

5. TROUBLESHOOTING

If you encounter issues with your desktop, consider the following common troubleshooting steps:

- **No Power:** Ensure the power cable is securely connected to both the desktop and the wall outlet. Check if the power supply switch on the back of the desktop is in the 'On' position.
- **No Display:** Verify that your monitor is powered on and correctly connected to the graphics card's DisplayPort or HDMI output. Try a different cable or monitor if available.
- **Peripheral Not Working:** Ensure USB devices (keyboard, mouse) are plugged into functional USB ports. Try different ports or devices to isolate the issue.
- **System Instability/Crashes:** Ensure your system drivers (especially graphics drivers) are up to date. Check for Windows updates. Monitor system temperatures to ensure components are not overheating.

For more complex issues or persistent problems, refer to the Thermaltake support website or contact customer service.

6. SPECIFICATIONS

Component	Specification
Brand	Thermaltake
Model Name	View i1470S-170
Model Number	V17S-B760-570-LCS
Operating System	Windows 11
CPU Model	Intel Core i7-14700F
CPU Speed	2.1 GHz
Graphics Coprocessor	NVIDIA GeForce RTX 5070
Graphics Card RAM	12 GB GDDR7
Memory (RAM)	32 GB DDR5 6000 MT/s RGB
Maximum RAM Supported	128 GB
Storage	1 TB NVMe M.2 SSD
Connectivity	HDMI, DisplayPort, USB, Wi-Fi (802.11ac)
USB Ports	2 (Total)
Cooling Method	Air (ARGB Tower Air Cooler)
Color	White
Power Plug Type	Type A - 2 pin (North American)
UPC	840480300746

6.1 Case Dimensions



Image: Case dimensions (Width: 8.35" / 212mm, Depth: 14.86" / 377.5mm, Height: 17.24" / 438mm).

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The Thermaltake LCGS View i1470S-170 Gaming Desktop comes with a 1-Year Warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

7.2 Technical Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please visit the official Thermaltake support website or contact their customer service department. Have your model name and serial number ready when contacting support.