

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [NIZUZONE](#) /

> [NIZUZONE Electronic Drum Set User Manual](#)

NIZUZONE NIZUZONEsv15zqano2

NIZUZONE Electronic Drum Set User Manual

Model: NIZUZONEsv15zqano2

INTRODUCTION

This user manual provides essential information for the proper setup, operation, and maintenance of your NIZUZONE Electronic Drum Set. Please read this manual thoroughly before using the product to ensure optimal performance and safety.

The NIZUZONE Electronic Drum Set is a versatile and portable instrument designed for both beginners and experienced players. It features a roll-up design, dual built-in speakers, and a USB rechargeable battery, making it ideal for practice sessions, creative music making, and on-the-go use.

PACKAGE CONTENTS

Upon unboxing, please verify that all the following items are included in your package:

- 2 x Drum Sticks
- 1 x User Manual (this document)
- 1 x Electronic Drum Pad
- 1 x Accessories (likely foot pedals, etc., as implied by images)
- 1 x USB Charging Cable



Image: The NIZUONE Electronic Drum Set laid out with its accompanying drum sticks and USB charging cable, demonstrating the complete package contents.

SETUP

Initial Charging

Before first use, ensure the electronic drum set is fully charged. Connect the provided USB charging cable to the drum set's charging port and to a compatible USB power source (e.g., power bank, laptop, wall adapter). The built-in 2000mAh rechargeable battery provides hours of continuous playtime.

Connecting Accessories

Connect the included drum sticks to the drum set. If foot pedals are included (as suggested by some product images), connect them to their respective ports on the drum unit.

Placement

Unroll the drum pad and place it on a flat, stable surface. Its lightweight and compact design allows for easy setup in various locations, whether at home, outdoors, or during travel.

OPERATING INSTRUCTIONS

Powering On/Off

To power on the device, locate the power button on the control panel and press it. To power off, press the power button again.



Image: A detailed view of the control panel and integrated speakers, highlighting the various buttons for operation.

Using the Drum Pads

The drum set features soft silicone drum pads that are responsive to touch. Use the provided drum sticks to strike the pads. Each pad corresponds to a different drum or cymbal sound, providing an authentic musical experience.



Image: The full layout of the electronic drum set, displaying the various drum and cymbal pads for playing.

Control Panel Functions

The central control panel offers various functions to enhance your drumming experience:

- **V+/V- (Volume Control):** Adjust the overall volume of the drum set.
- **DEMO:** Play pre-recorded demo songs to hear different styles and rhythms.
- **STYLE:** Cycle through various drum styles or genres.
- **RHY (Rhythm):** Select different rhythm patterns to play along with.
- **REC (Record):** Record your own drumming sequences.
- **PLAY:** Play back your recorded sequences or selected rhythms.
- **START/STOP:** Start or stop playback of demos, rhythms, or recorded tracks.
- **T+/T- (Tempo Control):** Adjust the tempo of rhythms or demo songs.

Built in double speakers Clear and shocking sound quality



Image: A close-up view of the control panel, highlighting the buttons for volume, demo, style, rhythm, record, play, start/stop, and tempo.

Immersive Sound Experience

The dual built-in speakers deliver crisp, clear, and dynamic sound quality. For a more personal experience, you can connect headphones to the drum set's audio output jack (if available, not explicitly mentioned but common for electronic drums).



Image: An individual actively playing the electronic drum set, illustrating its practical application and portability.

MAINTENANCE

Cleaning

To clean the drum set, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using abrasive cleaners, solvents, or strong chemicals, as these can damage the silicone pads and electronic components.

Storage

When not in use, roll up the drum pad gently to prevent creases or damage. Store it in a cool, dry place away from direct sunlight and extreme temperatures. Its compact design makes storage convenient.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the device regularly, even if not in constant use. If storing for an extended period, charge the battery to approximately 50% capacity.

TROUBLESHOOTING

If you encounter any issues with your NIZUUONE Electronic Drum Set, please refer to the following common troubleshooting steps:

- **No Sound:**
 - Ensure the device is powered on.
 - Check the volume level (V+ button).
 - Verify that no headphones are connected if you expect sound from the speakers.
- **Pads Not Responding:**
 - Ensure the drum pad is fully unrolled and flat.
 - Check for any visible damage to the pads or connections.
 - Restart the device.
- **Device Not Charging:**
 - Ensure the USB cable is securely connected to both the drum set and the power source.
 - Try a different USB port or power adapter.
 - Verify the power source is active.

If the issue persists after attempting these steps, please contact NIZUUONE customer support for further assistance.

SPECIFICATIONS

Product Specifications

Feature	Detail
Item Type	Electronic Drum Set
Material	Silicone + ABS
Battery Type	Aluminum cell (Built-in)
Battery Capacity	2000mAh
Item Weight	2.38 pounds
Package Dimensions	16.54 x 9.06 x 1.97 inches
Model Number	NIZUUONEsv15zqano2
Brand	NIZUUONE
Manufacturer	NIZUUONE



Image: Visual representation of the drum set's dimensions, indicating its compact and portable size.

SAFETY INFORMATION

Warm Tip: Children should play under adult supervision to avoid swallowing small toy parts.

Always ensure the product is used in a safe environment. Keep the device away from water and excessive heat. Do not attempt to disassemble or modify the product, as this may void the warranty and pose safety risks.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact NIZUUONE customer service. Keep your purchase receipt as proof of purchase.

For the most up-to-date support information, please visit the official NIZUUONE store on Amazon:

[NIZUUONE Store](#)