Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- BEISHI /
- > BEISHI Full Motion TV Wall Mount (Model: B0F98ZTHGF) Instruction Manual

BEISHI B0F98ZTHGF

BEISHI Full Motion TV Wall Mount (Model: B0F98ZTHGF) Instruction Manual

1. Introduction

This manual provides detailed instructions for the safe and proper installation, operation, and maintenance of your BEISHI Full Motion TV Wall Mount. This mount is designed to securely hold TVs ranging from 37 to 75 inches, with a maximum weight capacity of 132 lbs (60 kg), and supports VESA patterns up to 600x400mm. It offers extensive adjustability including 180° swivel, +5°/-20° tilt, and 90° screen rotation for optimal viewing flexibility.

Please read this manual thoroughly before beginning installation to ensure a safe and successful setup. Keep this manual for future reference.

2. SAFETY INFORMATION

Improper installation or use of this product can result in serious injury or damage. Please observe the following safety precautions:

- Weight Capacity: Do not exceed the maximum weight capacity of 132 lbs (60 kg). Ensure your TV's weight, including accessories, is within this limit.
- Screen Size: This mount is suitable for TVs between 37 and 75 inches.
- Wall Type: This mount is designed for installation on wood studs (8", 12", 14" spacing), concrete, or brick walls. DO NOT install on drywall alone.
- **VESA Compatibility:** Verify your TV's VESA mounting pattern (distance between mounting holes on the back of the TV) is compatible with this mount (Min 100x100mm to Max 600x400mm).
- Professional Installation: If you are unsure about the installation process or wall type, consult a
 qualified professional.
- Tools: Use appropriate tools and follow all instructions carefully.
- Children: Keep children away from the installation area during setup.
- Damage: Do not use the mount if any parts are damaged or missing. Contact customer support for replacement parts.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged before beginning installation. Refer to the image below for a visual representation of the included parts.



Image 3.1: All components included with the BEISHI Full Motion TV Wall Mount.

- · Wall Plate Assembly
- TV Bracket Arms (2 pieces)
- Extension Arms (2 pieces)
- Mounting Hardware Kit (screws, anchors, washers, spacers)
- Bubble Level
- Cable Ties
- Installation Template

4. Installation Instructions

4.1 Pre-Installation Checklist

- Confirm your TV's weight is less than 132 lbs (60 kg).
- Verify your TV's VESA pattern is between 100x100mm and 600x400mm.

- Identify your wall type (wood stud, concrete, or brick). Ensure stud spacing is compatible (8", 12", or 14").
- Gather necessary tools: drill, stud finder, pencil, measuring tape, screwdriver, socket wrench.



Image 4.1: VESA compatibility and supported wall types for installation.

4.2 Step-by-Step Installation

The following video provides a visual guide for the installation process:

Your browser does not support the video tag.

Video 4.1: Step-by-step product installation guide for the BEISHI TV Wall Mount.

- 1. **Marking Drill Holes:** Use the provided installation template to mark the desired drilling locations on your wall. Ensure the template is level.
- 2. **Drilling Holes:** Drill pilot holes at the marked locations. The drill bit size will depend on your wall type and the anchors provided.
- 3. **Inserting Anchors:** Insert the appropriate wall anchors into the drilled holes. For wood studs, lag bolts are typically used directly.
- 4. **Mounting Wall Plate:** Secure the wall plate assembly to the wall using the provided screws and a socket wrench. Use the bubble level to ensure it is perfectly horizontal.
- 5. Attaching Extension Arms: If your TV requires a wider VESA pattern, attach the extension arms to the

- main wall plate assembly. Secure them with the provided screws.
- 6. **Attaching TV Brackets to TV:** Lay your TV face down on a soft, clean surface. Attach the TV bracket arms to the back of your TV using the appropriate screws and spacers from the hardware kit. Ensure they are securely fastened.
- 7. **Mounting TV to Wall Plate:** Carefully lift the TV and hook the TV bracket arms onto the wall plate assembly. Secure the TV to the mount using the safety screws or locking mechanisms.




Image 4.2: The BEISHI TV wall mount fully installed and extended.

5. OPERATING YOUR TV WALL MOUNT

Your BEISHI Full Motion TV Wall Mount offers versatile adjustments for optimal viewing. The following video demonstrates the key features:

Your browser does not support the video tag.

Video 5.1: Overview of the BEISHI TV Wall Mount's features, including extension, swivel, and tilt capabilities.

5.1 Extension and Retraction

The mount features an extra-long extension arm that allows the TV to extend from 2.6 inches to 40.9 inches from the wall. Gently pull or push the TV to achieve the desired distance. Ensure smooth movement and avoid sudden forceful actions.



Image 5.1: The mount's extension capability, ranging from 2.4 to 36.4 inches.

5.2 Swivel Adjustment

The mount allows for a 180° left-right swivel. Gently pivot the TV to the desired viewing angle. This feature is useful for viewing from different areas within a room.



Image 5.2: The 180° swivel feature of the TV wall mount.

5.3 Tilt Adjustment

Adjust the TV's vertical angle by tilting it +5° upwards or -20° downwards. This helps reduce glare and optimize viewing comfort. The tilt mechanism can be adjusted using the provided tools or by hand, depending on the specific design.



Image 5.3: The tilt adjustment range of $+5^{\circ}$ to -20° .

5.4 Screen Rotation

The TV screen can be rotated 90° for switching between horizontal and vertical orientations. This feature is useful for specific applications like live broadcasting, online meetings, or gaming. Ensure the rotation mechanism is securely locked after adjustment.



Image 5.4: The 90° screen rotation capability of the mount.

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV wall mount:

- Cleaning: Wipe the mount with a soft, dry cloth to remove dust. Avoid abrasive cleaners or solvents.
- **Periodic Checks:** Periodically check all screws and bolts to ensure they are tight. Over time, vibrations or adjustments can cause fasteners to loosen.
- **Movement:** If the mount's movement becomes stiff, apply a small amount of silicone-based lubricant to the pivot points. Do not use oil-based lubricants.
- **Damage Inspection:** Inspect the mount for any signs of wear, corrosion, or damage. If any issues are found, discontinue use and contact customer support.

7. TROUBLESHOOTING

If you encounter any issues with your BEISHI TV Wall Mount, refer to the following common problems and solutions:

- **Mount is not level:** Use the integrated bubble level or a separate level to check the wall plate. If it's off, slightly loosen the mounting bolts, adjust, and re-tighten.
- **Difficulty moving the TV:** Ensure all adjustment screws are not overtightened. If movement is still stiff, apply a small amount of silicone lubricant to the joints.
- TV feels unstable: Double-check all mounting screws on both the wall plate and the TV brackets.

 Ensure they are securely tightened. Verify that the wall type and anchors used are appropriate for the TV's weight.
- **Missing parts:** Refer to the 'Package Contents' section. If parts are missing, contact BEISHI customer support immediately.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	BEISHI
Model	B0F98ZTHGF
TV Size Compatibility	37-75 inches
Maximum Load Capacity	132 lbs (60 kg)
VESA Compatibility	100x100mm to 600x400mm
Swivel Range	180° (left-right)
Tilt Range	+5° / -20°
Screen Rotation	90°
Extension from Wall	2.6 inches to 40.9 inches
Material	Alloy Steel
Color	Black
Item Weight	18.46 pounds
Wall Compatibility	Wood Studs (8", 12", 14"), Concrete, Brick

9. WARRANTY AND CUSTOMER SUPPORT

BEISHI products are manufactured to high-quality standards. For warranty information, technical support, or to inquire about replacement parts, please refer to the product packaging or contact BEISHI customer service through their official channels. You can also visit the BEISHI Store on Amazon for more information.

	BEISHI TV Wall Mount Installation Guide - Full Motion Articulating Bracket Comprehensive installation instructions for the BEISHI TV Wall Mount, featuring full-motion articulating arm capabilities. Learn how to safely mount your 32-70 inch flat or curved TV with VESA compatibility. Includes mounting accessories, tools required, step-by-step guidance, and important safety precautions.
	BEISHI Full Motion TV Wall Mount Installation Guide Detailed installation instructions for the BEISHI Full Motion TV Wall Mount. Covers preparation, base and hook installation, cable management, angle adjustments, and compatibility with various wall types. Includes essential safety warnings and points to consider for proper setup.
The first property of the control of	BEISHI Telescopic Rotating Hanger Installation Guide (VESA 400x400mm) Installation instructions for the BEISHI Telescopic Rotating Hanger. This full-motion bracket supports 26-55 inch TVs with VESA 400x400mm, offering swivel, tilt, and articulating features for optimal viewing.
	BEISHI Full Motion TV Wall Mount Installation Guide Step-by-step installation instructions for the BEISHI Full Motion TV Wall Mount, compatible with 26-43 inch TVs up to 30KG and VESA 200x200mm. Includes details on mounting to wooden and solid walls, hardware list, and adjustment options.
	BEISHI Rolling Floor Mobile TV Stand Installation Guide Step-by-step installation instructions for BEISHI Rolling Floor Mobile TV Stands, covering four distinct styles. Includes detailed parts lists, safety precautions, and assembly guidance for LCD/LED TVs.
	BEISHI Mobile TV Cart Installation Guide and Parts List Official installation guide and comprehensive parts list for the BEISHI Mobile TV Cart, a rolling TV stand designed for 32-75 inch televisions with adjustable height and VESA 600x400mm compatibility.