Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YITAHOME MAYIHyT33A

YITAHOME Queen Bed Frame Instruction Manual

Model: MAYIHyT33A | Brand: YITAHOME

1. Introduction

Thank you for choosing the YITAHOME Queen Bed Frame. This upholstered platform bed features an adjustable vertical channel wingback headboard, integrated LED lights, and solid wood slat support, designed for comfort and modern aesthetics. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure a seamless experience with your new bed frame.



The YITAHOME Queen Bed Frame, showcasing its elegant design and integrated LED lighting.

2. Safety Information

Please read all safety warnings and instructions carefully before assembly and use. Keep this manual for future reference.


- Ensure all components are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
- Assemble the bed frame on a soft, clean surface to prevent scratching.
- Tighten all bolts and screws securely, but do not overtighten. Periodically check and re-tighten fasteners.
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not stand or jump on the bed frame.

- Ensure the mattress size is compatible with the bed frame dimensions.
- For LED lights, use only the provided power adapter. Do not expose the LED strip or controller to water or excessive moisture.

3. Package Contents

Before starting assembly, verify that all the following components are included in your package:

- Headboard (with integrated LED lights and adjustable mechanism)
- Side Rails
- Footboard
- Solid Wood Slats
- Support Legs
- Hardware Pack (screws, bolts, Allen wrench, etc.)
- Installation Manual (this document)
- LED Remote Control



Key design features highlighting ease of assembly and robust support structure.

4. Specifications


Feature	Detail
Size	Queen

Feature	Detail
Product Dimensions (L x W x H)	84" x 61.8" x 47.4" (214cm x 155cm x 120.4cm)
Color	Beige
Material	Upholstered (Corduroy Fabric), Solid Wood Slats
Special Features	Adjustable Vertical Channel Wingback Headboard, Integrated RGB LED Lights, Remote Control, APP Control, Squeak Resistant, No Box Spring Needed
Compatible Mattress Size	8-10 inches (without box spring)
Weight Capacity	1100 lbs
Underbed Clearance	6.3 inches (16cm)
Assembly Required	Yes

QUEEN SIZE

Recommended Mattress Size:8″-10″

Weight Capacity:1100lbs



Detailed dimensions of the YITAHOME Queen Bed Frame.

5. Setup and Assembly

Assembly is required for this bed frame. Follow the step-by-step instructions provided in the included installation manual. It is recommended to have two people for assembly.

5.1 General Assembly Steps

1. Unpack all components and lay them out on a clean, soft surface.
2. Attach the side rails to the headboard and footboard using the provided hardware.
3. Install the central support beam and its legs.
4. Place the solid wood slats onto the support rails and secure them as instructed.
5. Connect the LED light power cable to the designated port on the headboard.

5.2 Adjustable Headboard

The headboard features an adjustable height mechanism to accommodate mattresses of varying thicknesses. You can adjust the headboard height to ensure a snug fit with your mattress and achieve your desired aesthetic.



The headboard can be adjusted to suit mattress heights between 8-12.5 inches.

5.3 Underbed Clearance

The bed frame is designed with an optimized 6.3-inch clearance, allowing for easy access for cleaning robots or underbed storage solutions.



The 6.3-inch underbed clearance provides convenient space for storage or cleaning.

6. Operating LED Lights

The integrated RGB LED lights can be controlled via a dedicated remote control or a smartphone application.

6.1 Remote Control Operation

Use the provided remote control to power on/off the lights, change colors, adjust brightness, and select dynamic modes. Refer to the remote control's specific button functions for detailed operation.

6.2 APP Control

Download the compatible smartphone application (details typically found in the included LED light manual or QR code). Once installed and connected via Bluetooth, the app allows for more advanced customization, including:

- Access to over 60,000 colors.
- Mic Mode: Lights react to sound.
- Music Mode: Lights synchronize with music.
- Timing Function: Schedule light on/off times.
- Dynamic Modes: Various pre-set lighting effects.



Control your LED lights with both the remote and the dedicated smartphone application.

7. Care and Maintenance

Proper care will extend the life and appearance of your YITAHOME bed frame.

7.1 Cleaning Instructions

- **Upholstered Fabric:** Wipe with a dry cloth to remove dust. For spills, blot immediately with a clean, dry cloth. Do not use harsh chemicals or abrasive cleaners. Spot clean with a mild fabric cleaner if necessary, testing on an inconspicuous area first.
- **Wood Slats/Frame:** Wipe with a dry cloth.
- **LED Lights:** Gently wipe the LED strip with a dry, soft cloth. Ensure the power is off before cleaning.



The bed frame features soft, skin-friendly, and breathable corduroy fabric.

7.2 General Care

- Avoid direct sunlight exposure to prevent fading of the fabric.
- Keep away from excessive heat or moisture.
- Periodically check and re-tighten all assembly hardware to maintain stability and prevent squeaking.

8. Troubleshooting

If you encounter any issues with your bed frame, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose hardware.	Check and tighten all bolts and screws. Ensure all legs are firmly on the ground.
Squeaking noises.	Loose connections, friction between slats and frame.	Re-tighten all hardware. Ensure slats are properly seated. Consider adding felt pads between slats and frame if squeaking persists.
LED lights not working.	Power connection issue, remote battery dead, app not connected.	Ensure the power adapter is securely plugged into the wall and the headboard. Check if the remote control battery needs replacement. Re-pair the app via Bluetooth if necessary.
Headboard adjustment is difficult.	Mechanism obstruction or tight fasteners.	Ensure no fabric or objects are obstructing the adjustment mechanism. Check if any bolts related to the adjustment are overtightened.

9. Support and Warranty

For any questions, missing parts, or issues not covered in this manual, please contact YITAHOME customer support. While specific warranty details are not provided here, YITAHOME products typically come with a manufacturer's warranty covering defects in materials and workmanship. Please retain your purchase receipt for warranty claims.
You may also refer to theYITAHOME Store on Amazon for additional product information and support.

© 2025 YITAHOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F996KPPP

More documents and user manuals: **https://manuals.plus/**