

[manuals.plus](#) /

› [KEMEI](#) /

› [KEMEI 1743 Professional Cordless Hair Clipper and Beard Trimmer User Manual](#)

KEMEI 1743

KEMEI 1743 Professional Cordless Hair Clipper and Beard Trimmer User Manual

Model: 1743 | Brand: KEMEI

1. INTRODUCTION

Thank you for choosing the KEMEI 1743 Professional Cordless Hair Clipper and Beard Trimmer. This device is designed for precise and comfortable hair trimming, suitable for various styles and personal grooming needs. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

2. PRODUCT OVERVIEW

The KEMEI 1743 features advanced technology for an efficient grooming experience. Key components and features include:

- Professional Trimming Blades:** Equipped with DLC precision carbon steel blades for sharp, safe, and comfortable trimming. Ideal for fine trimming, fading, gradients, and beard shaping.
- Large Battery Capacity:** A fast USB Type-C charging system allows for 120 minutes of operation after 2.5 hours of charging.
- Powerful Motor:** A 7000 RPM high-speed motor ensures powerful and durable performance with low noise.
- LED Display:** An intelligent LED display shows remaining power and provides timely reminders for charging and blade lubrication.
- Ergonomic Design:** Designed for comfortable handling and precise control.



Figure 2.1: KEMEI 1743 Hair Clipper and included accessories.



Figure 2.2: Key components of the KEMEI 1743 Hair Clipper.

3. SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions:

- Avoid using near water sources, such as bathtubs, showers, basins, or other vessels containing water.
- Keep blades away from eyes and sensitive skin areas.
- Do not use on infants or individuals with sensitive skin without extreme caution.
- Always unplug the device and allow it to cool before cleaning or storing.

- Always follow recommended maintenance procedures as outlined in this manual.
- Do not disassemble the device beyond what is instructed in this manual.
- Keep out of reach of children.

4. SETUP

1. **Initial Charge:** Before first use, fully charge the clipper for approximately 2.5 hours using the provided USB Type-C cable. The LED display will indicate charging status and battery percentage.
2. **Blade Inspection:** Ensure the blades are clean and properly aligned. Apply a small drop of lubricating oil to the blades if needed.
3. **Attach Guide Comb:** Select the desired guide comb (1.5mm, 3mm, 6mm, or 9mm) and securely attach it to the clipper head. Ensure it clicks into place.

USB Charging

Multiple charging options



Mobile Power



Plug



Laptop

150 Minutes
Charging time

120 Minutes
Running time



Figure 4.1: The KEMEI 1743 supports multiple USB charging options.

4 Size Guide Combs



Figure 4.2: The KEMEI 1743 includes four guide combs for various lengths.

5. OPERATING INSTRUCTIONS

The KEMEI 1743 is versatile for various grooming tasks. Always ensure hair is clean and dry before trimming.

5.1 Power On/Off

Press the power button located on the front of the device to turn it on or off. The LED display will illuminate upon activation.

5.2 Hair Cutting and Styling

1. Select the appropriate guide comb for your desired hair length.

2. Hold the clipper with the blades pointing downwards, moving against the direction of hair growth.
3. Use smooth, even strokes. For fading or blending, gradually change comb lengths.
4. For detailing and creating fine lines (zero-gap trimming), remove the guide comb and use the T-blade carefully.

5.3 Beard Trimming

1. For overall beard length, attach a guide comb. Start with a longer comb and gradually reduce the length until desired.
2. For precise lines and edges, remove the guide comb. Hold the clipper at a slight angle and carefully define your beard and neckline.



Figure 5.1: The KEMEI 1743 is suitable for various grooming applications.



Professional Trimmer

Figure 5.2: Demonstrating the KEMEI 1743 for professional trimming.

Video 5.1: Demonstration of the KEMEI 1743 for professional hair trimming.

Video 5.2: KEMEI 1743 hair trimmer in action for men's grooming.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your KEMEI 1743 clipper.

6.1 Cleaning the Blades

1. Turn off and unplug the clipper.
2. Use the provided cleaning brush to remove any loose hairs from the blades and the clipper head.

3. For a more thorough clean, the blades can be rinsed under running water. Ensure the clipper body remains dry.
4. Allow blades to air dry completely before reattaching or storing.

6.2 Oiling the Blades

After every few uses or after cleaning, apply 1-2 drops of lubricating oil (included) to the blades. Turn the clipper on for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and reduces friction.

7. TROUBLESHOOTING

If you encounter issues with your KEMEI 1743, refer to the following common solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Low battery or no charge.	Charge the clipper fully. Ensure the USB cable and adapter are working correctly.
Clipper pulls hair or cuts poorly.	Dull blades, dirty blades, or insufficient lubrication.	Clean the blades thoroughly. Apply lubricating oil. If blades are dull, consider professional sharpening or replacement.
Excessive noise or vibration.	Blades not properly aligned or lubricated.	Check blade alignment. Lubricate blades. If problem persists, contact customer support.
LED display not working.	Device malfunction.	Ensure the device is charged. If still not working, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model	1743
Power Source	Battery Powered
Blade Material	DLC Precision Carbon Steel
Motor Speed	7000 RPM
Battery Type	1 A battery (included)
Charging Time	Approx. 2.5 hours
Running Time	Approx. 120 minutes
Charging Interface	USB Type-C
Guide Combs	4 (1.5mm, 3mm, 6mm, 9mm)
Item Weight	330 Grams
Color	Black

Feature	Detail
Manufacturer	KEMEI






Figure 8.1: Physical dimensions of the KEMEI 1743 Hair Clipper.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact KEMEI customer service directly. Keep your purchase receipt as proof of purchase.

10. LEGAL DISCLAIMER

Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. The manufacturer is not responsible for any damage or injury caused by improper use or failure to follow the instructions in this manual.