

SMP-10

Generic Steammaster Pro Handheld Steam Cleaner

MODEL: SMP-10

1. Introduction

Thank you for choosing the Generic Steammaster Pro Handheld Steam Cleaner. This versatile 10-in-1 device is designed for effective multi-purpose cleaning using high-temperature steam. Please read this manual thoroughly before operating the appliance to ensure safe and efficient use.



Figure 1: Steammaster Pro Handheld Steam Cleaner

2. Safety Information

WARNING: Failure to follow these safety instructions may result in fire, electric shock, or other injury.

- Always ensure the appliance is unplugged from the power outlet before filling with water or performing maintenance.
- Do not open the safety cap while the unit is pressurized or hot. Allow the unit to cool down completely before refilling or opening the cap.
- Keep hands, face, and body parts away from the steam nozzle when the unit is operating. Steam is extremely hot and can cause severe burns.
- Do not immerse the appliance in water or any other liquid.
- Use only clean tap water. Do not add cleaning solutions, perfumes, or other chemicals to the water tank, as this can damage the unit or create hazardous fumes.
- This appliance is for household use only. Do not use outdoors or for commercial purposes.
- Keep out of reach of children and pets.

3. Product Components and Accessories

The Steammaster Pro comes with a versatile 9-piece accessory kit to address various cleaning needs. Familiarize yourself with each component before use.

- Steammaster Pro Main Unit
- Extension Hose
- Measuring Cup
- Funnel
- Angled Nozzle
- Round Brush (various types)
- General Spray Nozzle
- Long Spray Nozzle
- Bent Spray Nozzle
- Spray Nozzle for Window/Door
- Rag
- Glove



Figure 2: Main unit and some accessories



Figure 3: Detailed view of various attachments

DETAILS OF STEAM CLEANER



Figure 4: Key features of the Steammaster Pro

4. Setup and First Use

Follow these steps to prepare your Steammaster Pro for use:

1. **Unscrew Safety Valve:** Turn the safety valve counter-clockwise to open the water tank.
2. **Fill Water Tank:** Use the provided measuring cup and funnel to add up to 200ml of clean tap water into the tank. Do not overfill the 350ml capacity. Screw the safety valve back on tightly.
3. **Attach Nozzle:** Select the appropriate spray head or attachment for your cleaning task and securely attach it to the main unit.
4. **Power On:** Plug the power cable into a suitable electrical outlet. The red power indicator light will illuminate, indicating the unit is heating up. Heating time is approximately 3-5 minutes.
5. **Begin Cleaning:** Once the red light extinguishes, the steam is ready. Push the steam valve to release high-temperature steam and direct it towards the area to be cleaned.



Figure 5: Step-by-step guide for initial setup and use

5. Operating Instructions

The Steammaster Pro generates high-temperature steam up to 221°F (105°C) and operates at 2.6-3.2 BAR pressure, providing 8-12 minutes of continuous steam. It is suitable for various hard surfaces including ceramic, marble, sealed hardwood, tile, sinks, stoves, windows, and can also be used for sofas, toys, and car interiors.

General Cleaning Tips:

- Always test the steam cleaner on an inconspicuous area first to ensure no damage occurs to the surface.
- Hold the nozzle close to the surface for maximum steam penetration and cleaning power.
- For stubborn dirt, allow the steam to penetrate for a few seconds before wiping with a clean cloth or using a brush attachment.
- Use the appropriate attachment for the task. For example, the window/door nozzle for glass, and brush attachments for grout or textured surfaces.
- Wipe surfaces immediately after steaming to remove loosened dirt and moisture.

WIDE APPLICATION



Figure 6: Wide application areas for the steam cleaner

Your browser does not support the video tag.

Video 1: Demonstration of the Laytic Steammaster Pro in action.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

- **After Each Use:** Unplug the unit and allow it to cool completely. Carefully open the safety cap and empty any remaining water from the tank. Wipe the exterior of the unit with a damp cloth.
- **Cleaning Accessories:** Wash all removable attachments with warm, soapy water and rinse thoroughly. Allow them to air dry completely before storing.
- **Descaling:** Depending on water hardness, mineral deposits may build up inside the tank. To descale, fill the tank with a solution of equal parts white vinegar and water. Let it sit for 30 minutes (do not heat). Empty the solution and rinse the tank thoroughly with fresh water several times.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

7. Troubleshooting

If you encounter issues with your Steammaster Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank is empty or low. Unit not heated sufficiently. Nozzle clogged.	Refill water tank. Wait for the indicator light to turn off. Clean the nozzle.
Water leaking from nozzle	Condensation build-up. Nozzle not securely attached.	This is normal at the start of steaming. Ensure nozzle is firmly attached.
Unit not turning on	Not plugged in. Power outlet issue.	Check power connection. Test outlet with another appliance.

8. Specifications

Technical details for the Generic Steammaster Pro Handheld Steam Cleaner:

Brand: Generic

Model Name: Steammaster Pro

Model Number: SMP-10

Color: Red

Voltage: 110V (US standard)

Frequency: 50/60HZ

Power: 1000W (as per product description) / 1200 watts (as per specifications) *-Please refer to product labeling for exact wattage.*

Steam Intensity: 2.6-3.2 BAR

Heating Time: 3-5 minutes (as per product description) / 30 Seconds (as per specifications) *-Please refer to product labeling for exact heating time.*

Continuous Working Time: 8-10 minutes

Steam Temperature: 221°F (105°C) (as per product description) / 230 Degrees Celsius (as per specifications) *- Please refer to product labeling for exact temperature.*

Water Tank Capacity: 350 ml (11.8 ounces)

Shell Material: PP

Boiler Material: Aluminum

Power Cable Length: Approximately 2.8m / 9.2ft

Item Weight: 2.5 Pounds

Item Dimensions (D x W x H): 4.5"D x 6"W x 12"H

Special Features: 10-in-1 Functionality, Multi-purpose Use, Portable Design, Pressure Steam Cleaning

Surface Recommendation: Multiple Surfaces

9. Warranty and Support

Specific warranty details for the Generic Steammaster Pro Handheld Steam Cleaner are not provided in this manual. For warranty information, technical support, or service inquiries, please contact the manufacturer or your retailer directly. Keep your purchase receipt as proof of purchase.

