

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [DWVO](#) /
- › [DWVO 18" Crystal Caged Ceiling Fan with Light - Instruction Manual](#)

DWVO MADWV5vB4g

DWVO 18" Crystal Caged Ceiling Fan with Light

INSTRUCTION MANUAL

[Safety Information](#) [Package Contents](#) [Setup & Installation](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

Introduction

This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your DWVO 18" Crystal Caged Ceiling Fan with Light. Please read this manual thoroughly before installation and retain it for future reference.

Safety Information

- Always turn off power at the circuit breaker before beginning installation or maintenance.
- Ensure all electrical connections comply with local codes and ordinances. If you are unsure, consult a qualified electrician.
- Do not bend the fan blades when installing or cleaning.
- Ensure the mounting structure can support the weight of the fan.
- Use only E12 base bulbs, not exceeding 40 watts. Bulbs are not included.
- Keep the remote control away from children.

Package Contents

Carefully unpack your ceiling fan and ensure all components are present and undamaged. The package includes:


- Crystal Caged Ceiling Fan Unit
- Remote Control
- Mounting Bracket
- Downrods (4.9" and 11.8" options)
- Hardware Kit (screws, wire nuts, etc.)

- Spare K5 Crystals (2 pieces)
- White Glove for handling crystals
- Instruction Manual

Setup & Installation

Follow these steps to install your DWVO Crystal Caged Ceiling Fan. It is recommended to have two people for installation.

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Clear the installation area.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box. Ensure the junction box is securely fastened to the building structure and can support the fan's weight.
3. **Assemble Downrod:** Choose the appropriate downrod (4.9 inches for standard ceilings, 11.8 inches for vaulted ceilings or higher clearance) and attach it to the fan motor assembly.
4. **Wiring Connections:** Connect the fan's electrical wires to the household wiring according to the provided wiring diagram in the manual. Ensure all connections are secure using wire nuts.
5. **Attach Fan to Mounting Bracket:** Carefully lift the fan assembly and attach it to the mounting bracket. Ensure all screws are tightened.
6. **Install Light Bulbs:** Insert E12 base bulbs (not included) into the sockets.
7. **Final Checks:** Double-check all connections and ensure the fan is securely mounted. Restore power at the circuit breaker.



MOUNTING OPTION



Downrod (4.9")



Tilt 15°

Angled (11.8")

Image: Dimensions of the DWVO 18" Crystal Caged Ceiling Fan with options for a 4.9" downrod (standard mount) or an 11.8" downrod (angled mount for vaulted ceilings).



Image: The DWVO Crystal Caged Ceiling Fan installed in rooms with both low and high ceilings, demonstrating the versatility of the included downrods.

Operating Instructions

Your ceiling fan is controlled by the included remote. Ensure the remote has fresh batteries (not included).

Remote Control Functions:

- **Fan ON/OFF:** Press the "FAN/OFF" button to turn the fan on or off.
- **Fan Speed:** Select from 6 fan speeds (1-6) to adjust airflow.
- **Light ON/OFF:** Press "LIGHT ON/OFF" to control the light.
- **Light Color Temperature:** Cycle through Warm White, Clear White, and Cool White light settings.
- **Reversible Blades (F/R):** Use the "F" (Forward) and "R" (Reverse) buttons to change the fan's direction.
 - **Forward Mode (Summer):** Creates a downward airflow, producing a cooling effect.
 - **Reverse Mode (Winter):** Creates an upward airflow, circulating warm air trapped near the ceiling.
- **Timer Settings:** Set the fan to turn off automatically after 1, 2, or 4 hours using the respective

buttons.



Remote Control



Timing Setting



Quiet Operation



3-Speed Setting

Image: The remote control allows for easy adjustment of fan speeds, light settings, and timer functions.



Image: The fan light offers three color temperature options: Warm White, Clear White, and Cool White, to suit different moods and needs.



WARM WHITE



CLEAR WHITE



COOL WHITE

18" CEILING FAN LIGHTS



E12*4 Bulb Base
(Bulb not included)



Max 40W

Image: The reversible motor allows for both summer (downdraft) and winter (updraft) modes to optimize air circulation year-round.




Image: The fan features multiple speed settings, from a gentle 'Sleeping Wind' to a powerful 'Strong Wind', for personalized comfort.




Image: The fan operates quietly (under 35dB) and includes a timer function (1, 2, or 4 hours) for undisturbed sleep or energy saving.

Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Before cleaning, ensure power is off at the circuit breaker. Use a soft, damp cloth to wipe down the fan housing and crystals. Do not use abrasive cleaners or solvents. Use the provided white glove when handling crystals to avoid smudges.
- **Bulb Replacement:** When replacing bulbs, ensure power is off. This fan uses E12 base bulbs, with a maximum wattage of 40W per bulb.



MOUNTING OPTION



Image: The fan uses E12 bulb bases. Ensure power is off before replacing bulbs.

Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; remote control battery dead.	Check circuit breaker. Ensure all wiring connections are secure. Replace remote control batteries.
Light does not turn on	Loose bulb; faulty bulb; incorrect wiring.	Tighten or replace bulbs. Check wiring connections.
Remote control not working	Dead batteries; remote not paired; obstruction.	Replace batteries. Ensure no obstructions between remote and fan. Refer to pairing instructions in the full manual if available.
Excessive wobbling	Loose mounting screws; unbalanced blades.	Ensure all mounting screws are tight. Check if blades are securely attached.

Specifications

Feature	Detail
Brand	DWVO
Model Number	MADWV5vB4g
Product Dimensions	18"L x 18"W x 11"H
Material	Iron, Crystal
Color	Gold
Style	Crystal Gold
Power Source	AC
Voltage	120 Volts
Wattage	40 watts (max per bulb)
Bulb Base	E12 (bulbs not included)
Light Output	400 Lumens
Control Method	Remote
Fan Speeds	6
Special Features	Adjustable Height, Reversible Blades, Timer, 3 Color Temperatures
Item Weight	12.34 Pounds

Warranty & Support

This DWVO ceiling fan comes with a **1-year manufacturer's warranty**. For warranty claims or technical support, please contact DWVO customer service through the retailer's platform or the official DWVO website. Please have your model number (MADWV5vB4g) and purchase date available when contacting support.