

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [CAROMIO](#) /

› CAROMIO Heated Electric Blanket Twin Size (Model SQB-TBD) Instruction Manual

CAROMIO SQB-TBD

CAROMIO Heated Electric Blanket Twin Size

Model: SQB-TBD

INTRODUCTION

This instruction manual provides important information for the safe and efficient use of your CAROMIO Heated Electric Blanket, Twin Size. Please read all instructions carefully before use and retain this manual for future reference.



Image: The CAROMIO Heated Electric Blanket in cow print design, draped over a bed.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this blanket.
2. Do not use this blanket with an infant, a child, an invalid, or any person insensitive to heat.
3. Do not use this blanket on an adjustable bed unless the blanket is designed for such use.
4. Do not use this blanket if the power cord or plug is damaged.
5. Do not use pins or other metallic objects with this blanket. They may damage the wiring.

6. Do not use this blanket with alcohol or sedatives, as this may increase heat sensitivity.
7. Ensure the controller is always placed in a position where it will not be covered by the blanket or other bedding.
8. This blanket is equipped with intelligent NTC&PTC heating wires that continuously monitor and regulate temperature in real-time to prevent overheating. The product is ETL certified for safety.

OVERHEAT PROTECTION

WARM PROTECTION

Expanded Heating Coverage


VS

Faster Warm-Up

The diagram compares CAROMIO and other blankets. On the left, 'Expanded Heating Coverage' shows a person on a blanket with a wider heating area (indicated by more vertical lines) compared to 'Others'. On the right, 'Faster Warm-Up' shows a temperature graph. The y-axis ranges from 84°F to 115°F. The x-axis is labeled 'mins'. The CAROMIO curve (red) rises more steeply than the 'Others' curve (blue), reaching a higher temperature faster. A color scale on the left of the graph indicates temperature levels from blue (84°F) to red (115°F).

Image: Diagram illustrating the overheat protection and faster warm-up features of the CAROMIO electric blanket compared to others.

FAST HEATING



Upgraded PTC/NTC heating wires, safer and more reliable.

Overheat Protection & Fast Heating.

OTHERS



VS

OURS



Image: Cross-section view showing the layers of the electric blanket, highlighting the 220 GSM milk velvet, double layer non-woven fabric, PTC/NTC heating wires, and 210 GSM sherpa, emphasizing upgraded safety features.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the electric blanket from its packaging.
2. **Inspect:** Check the blanket, power cord, and controller for any signs of damage. Do not use if damaged.
3. **Position:** Lay the blanket flat on your bed or desired surface. Ensure the controller cord can reach a power outlet without being stretched or pinched.
4. **Connect:** Plug the blanket's connector into the controller. Ensure a secure connection.
5. **Power On:** Plug the power cord into a standard 120V AC electrical outlet.

OPERATING INSTRUCTIONS

Your CAROMIO electric blanket features an LCD controller for easy temperature and timer adjustments.

10 TEMP MODES × 1-12H TIMER SETTINGS

Customize Your Perfect Sleep Climate

84°F → 115°F

 **1-12**
Hours Auto Off

 **10**
Heating Settings

 **ETL**
Certified



Image: Close-up of the LCD controller, showing buttons for temperature adjustment (Temp +/-, Power), and timer settings (Timer +/-). The display shows "9" for heat level.

Controller Functions:

- **Power Button:** Press to turn the blanket ON or OFF.
- **Temperature Settings (Temp +/-):**
 - Press **Temp +** to increase the heat level.
 - Press **Temp -** to decrease the heat level.
 - There are 10 heat levels available, ranging from 84°F to 115°F.

- The current heat level will be displayed on the LCD screen.

- **Timer Settings (Timer +/-):**

- Press **Timer +** to increase the auto-off timer duration.
- Press **Timer -** to decrease the auto-off timer duration.
- The timer can be set from 1 to 12 hours.
- The blanket will automatically shut off after the set time has elapsed.

Usage Recommendations:

- For best results, pre-heat the blanket for approximately 15 minutes before use.
- The blanket is suitable for various uses including reading, napping, travel, camping, and working.



Image: The electric blanket shown in three different usage scenarios: draped over a chair for working, on a sofa, and on a bed, illustrating its versatility.

CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your electric blanket.

Washing Instructions:

1. **Disconnect:** Always unplug the power connection from the wall outlet and detach the controller from the blanket before washing.
2. **Machine Wash:** Machine wash the blanket in cold water on a gentle cycle.
3. **Drying:** Tumble dry on low heat. Do not bleach or iron the blanket.
4. **Reshape:** After washing and drying, gently stretch the blanket back to its original size for optimal performance.
5. **Storage:** Store the blanket in a cool, dry place when not in use.




Image: A woman placing the cow print electric blanket into a washing machine, demonstrating the machine washable feature. An inset shows the detached power cord.

TROUBLESHOOTING

If you experience issues with your electric blanket, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Blanket does not heat.	Not plugged in, controller not connected, power outage, or internal safety shut-off.	Ensure power cord is securely plugged into a working outlet. Verify controller is firmly connected to the blanket. Check household circuit breaker. Unplug and re-plug the blanket to reset.
Controller display is off or flashing.	Loose connection or internal error.	Check all connections. Unplug the blanket from the wall outlet for 5 minutes, then plug it back in to reset the controller.
Blanket heats unevenly.	Blanket is bunched or folded, or internal wiring issue.	Ensure the blanket is spread flat without folds or bunches. If the problem persists, discontinue use.
Blanket is too hot or not warm enough.	Incorrect heat setting.	Adjust the temperature setting using the "Temp +/-" buttons on the controller.

SPECIFICATIONS

Feature	Detail
Brand	CAROMIO
Model Name	SQB-TBD
Size	Twin (62"L x 84"W)
Color	Cow-brown
Material	Milk Velvet (220GSM) and Sherpa (210GSM)
Heat Settings	10 Levels (84°F - 115°F)
Auto-Off Timer	1-12 Hours
Safety Features	ETL Certified, NTC&PTC Heating Wires, Overheat Protection
Control Cord Length	10.3 FT
Power Cord Length	6 FT
Product Weight	5.77 pounds
Care Instructions	Machine Washable (remove controller)
UPC	199414225908

MACHINE WASHABLE

Unplug the power connection before washing.



Image: A table showing different blanket sizes (Throw, Twin, Full, Queen, King) with their corresponding control cord and power cord lengths. The Twin size is highlighted with 62"x84" dimensions, 10.3 FT control cord, and 6 FT power cord.

WARRANTY AND SUPPORT

Specific warranty details and direct support contact information were not provided in the product data. For warranty claims or technical assistance, please refer to the product packaging or contact CAROMIO customer service through their official channels or the retailer where the product was purchased.

