

Manuals.plus /

- › K MAG /
- › K MAG PR-01 Bluetooth Speaker User Manual

KMAG PR-01

KMAG PR-01 Bluetooth Speaker User Manual

Model: PR-01

INTRODUCTION

Thank you for choosing the KMAG PR-01 Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.





Image: The KMAG PR-01 Bluetooth Speaker, showcasing its vertical design and vibrant LED lighting around the speaker cones.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- KMAG PR-01 Bluetooth Speaker
- Power Cable
- User Manual
- 3.5mm AUX Cable
- 3.5mm Extension Cable Male to Female
- 6.35mm Extension Cable Male to Female
- USB to Type-C Charging Cable
- Type-C to Type-C Charging Cable



Image: The K MAG PR-01 speaker, its packaging box, and all included cables and the user manual laid out.

PRODUCT FEATURES

- **Powerful Audio Output:** 260W peak power with deep bass from four high-performance speaker units.
- **Advanced Bluetooth Connectivity:** Features Bluetooth 5.3 for faster pairing, stable transmission, and extended range.
- **Dynamic Light Modes:** Six intelligent RGB lighting modes that synchronize with music.
- **Extended Playtime:** Up to 15 hours of audio playback on a full charge, with fast charging support.
- **Durable Design:** IPX4 splashproof and dustproof silicone cover protects ports from water and dust.
- **True Wireless Stereo (TWS):** Pair two PR-01 speakers for an immersive 360° stereo sound experience.
- **Versatile Connectivity:** Includes two microphone interfaces (3.5mm and 6.35mm), 3.5mm Aux input, and USB input for various devices.



Image: The K MAG PR-01 speaker with an overlay graphic emphasizing its 260W powerful sound and bass boost capabilities.

CONTROLS AND INDICATORS

The KMAG PR-01 speaker features an intuitive control panel and various ports for connectivity.



Image: A detailed view of the KMAG PR-01 speaker's top control panel, showing buttons for power, Bluetooth, light modes, and playback, along with the covered input ports.

Control Panel Functions:

- **Power Button (U):** Press and hold to power on/off. Short press to play/pause music.
- **Bluetooth Button (BT):** Short press to enter Bluetooth pairing mode.
- **Light Mode Button (*):** Short press to cycle through 6 light modes. Press and hold to turn lights on/off.

- **Volume Up/Next Track (+):** Short press for volume up. Long press for next track.
- **Volume Down/Previous Track (-):** Short press for volume down. Long press for previous track.
- **Bass Boost Button (BASS):** Short press to activate/deactivate bass boost.
- **TWS Button:** Short press to initiate True Wireless Stereo pairing.

Input Ports (under silicone cover):

- **MIC (3.5mm):** For connecting a 3.5mm microphone.
- **MIC (6.35mm):** For connecting a 6.35mm microphone.
- **USB:** For connecting a USB drive for music playback.
- **AUX (3.5mm):** For connecting external audio devices via a 3.5mm audio cable.
- **Charging Port (Type-C):** For charging the speaker.

SETUP

1. Charging the Speaker

1. Locate the Type-C charging port under the silicone cover on the control panel.
2. Connect the provided Power Cable or USB to Type-C/Type-C to Type-C charging cable to the speaker's charging port.
3. Connect the other end of the cable to a suitable power adapter (not included) or USB power source.
4. The LED indicators on the speaker will show charging status. A full charge provides up to 15 hours of playtime (at medium volume).

Fast-charging Supported

Non-stop beats, endless party

Up to
15H
Playtime

Come with two charging cables:



USB to Type-C | Type-C to Type-C



Image: The K MAG PR-01 speaker with a graphic indicating 'Up to 15H Playtime' and 'Fast-charging Supported', showing the included USB to Type-C and Type-C to Type-C charging cables.

2. Power On/Off

- To power on, press and hold the Power Button (⏻) for approximately 3 seconds until you hear an audible prompt and the lights activate.
- To power off, press and hold the Power Button (⏻) again for approximately 3 seconds.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and within 10 meters (32.81 feet) of your Bluetooth device.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing blue light or audible prompt. If not, short press the Bluetooth Button (**BT**).
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "KMAG PR-01" from the list of devices.
5. Once paired, the speaker will emit an audible confirmation, and the Bluetooth indicator light will become solid.

Latest Upgraded Bluetooth 5.3

Faster speed, wider range, smoother transmission



Image: The KMAG PR-01 speaker positioned horizontally on a beach, with a graphic highlighting 'Latest Upgraded Bluetooth 5.3' and its benefits.

4. True Wireless Stereo (TWS) Pairing

To achieve 360° stereo surround sound, you can pair two KMAG PR-01 speakers (sold separately).

1. Ensure both KMAG PR-01 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), short press the TWS Button. The speaker will emit an audible prompt, indicating it's searching for another speaker.
3. The primary speaker will automatically connect to the secondary speaker. Once connected, both speakers will emit an audible confirmation.
4. Now, connect your Bluetooth device to the primary speaker as described in the Bluetooth Pairing section. Audio will play through both speakers in stereo.



True Wireless Stereo Surround

Elevate Your Stage. Pair Two Speakers (Same Model) for an Immersive Sound Experience.

Image: Two KMAG PR-01 speakers shown in a party setting, illustrating the True Wireless Stereo (TWS) pairing feature for an immersive sound experience.

5. Wired Connections (AUX, USB, Microphone)

The speaker supports various wired connections for enhanced versatility.

- **AUX Input:** Connect an external audio device (e.g., MP3 player, computer, TV) using the provided 3.5mm AUX cable to the speaker's 3.5mm AUX port. The speaker will automatically switch to AUX mode.
- **USB Input:** Insert a USB flash drive containing audio files into the USB port. The speaker will automatically detect and play music from the drive.
- **Microphone Input:** Connect a 3.5mm or 6.35mm microphone to the corresponding MIC port for vocal input.



IPX4 Splashproof Keeps Your Beats

A little rain won't stop the fun when you're partying with friends in the park, camping or by the seaside

Image: The KMAG PR-01 speaker with graphics illustrating its compatibility with various devices and inputs, including 3.5mm Mic, 3.5mm Aux, 6.35mm Mic, and USB Disk.

OPERATING INSTRUCTIONS

1. Music Playback

- **Play/Pause:** Short press the Power Button (⏻).
- **Volume Adjustment:** Short press the Volume Up (⏮) or Volume Down (⏭) buttons.
- **Next Track:** Long press the Volume Up (⏮) button.
- **Previous Track:** Long press the Volume Down (⏭) button.

2. Light Modes

The KMAG PR-01 features 6 dynamic RGB light modes that enhance your listening experience.

- **Change Mode:** Short press the Light Mode Button (💡) to cycle through the available light modes.
- **Turn On/Off Lights:** Press and hold the Light Mode Button (💡) to toggle the lights on or off.

Futuristic Lightshow Dynamic Beats

Light your party whenever



Image: The K MAG PR-01 speaker with a graphic illustrating its 'Futuristic Lightshow Dynamic Beats' and the six distinct light modes (A-F).

3. Bass Boost

Activate the Bass Boost feature for deeper, more resonant bass.

- **Activate/Deactivate:** Short press the Bass Boost Button (**BASS**) on the control panel.

MAINTENANCE

1. Cleaning

- Ensure the speaker is powered off and disconnected from all power sources before cleaning.
- Use a soft, dry cloth to wipe the exterior of the speaker.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the surface.

2. Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% every few months to maintain battery health.

3. Water and Dust Resistance (IPX4)

The KMAG PR-01 speaker is rated IPX4, meaning it is resistant to splashing water from any direction. It is not designed to be submerged in water.

- Ensure the silicone cover over the input ports is securely closed to maintain splashproof and dustproof protection.
- Avoid exposing the speaker to heavy rain or direct jets of water.
- If the speaker gets wet, wipe it dry with a soft cloth before charging or using the ports.

TROUBLESHOOTING

If you encounter issues with your KMAG PR-01 speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; incorrect input mode; device not connected.	Increase volume on speaker and connected device. Ensure correct input mode (Bluetooth, AUX, USB). Re-pair Bluetooth device.
Bluetooth pairing fails.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode. Turn on Bluetooth on your device. Move device closer to speaker (within 10m). Forget previous pairings and try again.
TWS pairing fails.	Speakers already connected to other devices; not both PR-01 models.	Ensure both speakers are disconnected from other Bluetooth devices. Confirm both are KMAG PR-01 models. Follow TWS pairing steps carefully.
Lights are not working.	Lights are turned off.	Press and hold the Light Mode Button (☼) to turn lights on.

SPECIFICATIONS



Image: The K MAG PR-01 speaker shown with its dimensions: 18.31 inches (height) x 9.25 inches (width) x 9.25 inches (depth).

Feature	Detail
Model Name	PR-01 Party Boom
Speaker Type	Party Speaker
Speaker Maximum Output Power	260 Watts (Peak)
Woofer Diameter	5.25 Inches x 2
Tweeter Diameter	2.15 Inches x 2
Frequency Response	35 Hz
Signal-to-Noise Ratio	85 dB
Wireless Communication Technology	Bluetooth 5.3
Bluetooth Range	32.81 Feet (10 meters)
Connectivity Technology	Auxiliary, Bluetooth, USB
Power Source	Battery Powered (6 Nonstandard Battery batteries included)
Battery Capacity	15000 Milliamp Hours
Playtime	Up to 15 Hours (at medium volume)
Waterproof Rating	IPX4 (Splashproof)
Product Dimensions	18.31"D x 9.25"W x 9.25"H
Item Weight	11 Pounds
Material	Acrylonitrile Butadiene Styrene (ABS), Polycarbonate (PC)
Color	Black
Included Components	3.5mm AUX Cable, 3.5mm Extension Cable Male to Female, 6.35mm Extension Cable Male to Female, Power Cable, User Manual

WARRANTY AND SUPPORT

KMAG is committed to providing high-quality products and customer satisfaction.

- **Lifetime Warranty:** The KMAG PR-01 speaker comes with a lifetime warranty.
- **3-Year Free Replacement:** Enjoy a free replacement within 3 years of purchase for manufacturing defects.

- **30-Day Return Policy:** You may return the product within 30 days for any reason.
- **24-Hour Customer Support:** KMAG offers 24-hour support via phone or email for any inquiries or assistance.



KMAG





 24 Hours Quick reply via phone or email	 30 Days 30 days no reason to return
 3 Years Free replacement within 3 Years	 Lifetime Lifetime customer support

Image: Icons representing KMAG's customer service commitments: Lifetime Warranty, 3-Year Free Replacement, 30-Day Return, and 24-Hour Support.

For further assistance, please visit the official KMAG Store: [KMAG Store on Amazon](#)