

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Logitech](#) /

› [Logitech Bolt USB-C Receiver Instruction Manual](#)

Logitech 956-000156

Logitech Bolt USB-C Receiver Instruction Manual

Model: 956-000156

INTRODUCTION

The Logitech Bolt USB-C Receiver provides a secure, high-performance wireless connection for your Logi Bolt wireless mouse, keyboard, or combo devices to your computer. This receiver is designed for reliability, even in congested wireless environments, offering a stable connection up to 10 meters (33 feet).

What's in the Box

- Logi Bolt USB-C Receiver

SETUP

Follow these steps to set up your Logitech Bolt USB-C Receiver and pair it with your compatible Logi Bolt devices.

1. **Insert the Receiver:** Plug the Logi Bolt USB-C Receiver into an available USB-C port on your computer.
2. **Install Logi Options+ Software:** For optimal functionality and device management, download and install the Logi Options+ software from the official Logitech website. This software allows you to pair and manage multiple Logi Bolt devices.
3. **Pair Your Devices:** Open the Logi Options+ software. Follow the on-screen instructions to add and pair your Logi Bolt compatible mouse, keyboard, or other devices with the receiver. Ensure your device is in pairing mode as per its specific instructions.



Image: The Logi Bolt USB-C Receiver inserted into a laptop's USB-C port, demonstrating its compact and discrete design.

Video: A comparison between Logitech Bolt and Unifying receivers, explaining their differences and compatibility. This video helps users understand the specific technology of the Bolt receiver.

OPERATING INSTRUCTIONS

Once paired, your Logi Bolt devices will automatically connect to the receiver when powered on and within range.

- **Multi-Device Connectivity:** A single Logi Bolt receiver can connect up to six compatible Logi Bolt wireless keyboards and mice simultaneously. This eliminates the need for multiple USB receivers, simplifying your workspace.
- **Secure Connection:** Logi Bolt technology provides a strong, secure, and drop-off-free wireless connection, even in environments with high wireless interference.
- **Operating Range:** Maintain a reliable connection with your devices up to 10 meters (33 feet) from the receiver.
- **Compatibility:** The Logi Bolt receiver is compatible with Windows, macOS, Linux, and Chrome OS.




Image: A visual representation of the Logi Bolt receiver's ability to connect up to six compatible wireless devices, including mice and keyboards, to a single computer.

MAINTENANCE

The Logi Bolt USB-C Receiver requires minimal maintenance.

- **Keep it Plugged In:** For continuous and convenient use, it is recommended to keep the receiver plugged into your computer's USB-C port. Its discrete size allows it to remain installed without obstruction.
- **Cleaning:** If necessary, gently wipe the receiver with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, or during transport, you may remove the receiver and store it in a safe place to prevent loss or damage.

TROUBLESHOOTING

If you encounter issues with your Logi Bolt USB-C Receiver, try the following troubleshooting steps:

1. Device Not Connecting:

- Ensure the receiver is securely plugged into a functioning USB-C port.
- Verify that your Logi Bolt device is powered on and has sufficient battery charge.
- Open the Logi Options+ software and attempt to re-pair your device with the receiver.
- Try plugging the receiver into a different USB-C port on your computer.

2. Intermittent Connection or Lag:

- Ensure the distance between your device and the receiver is within the 10-meter (33 feet) operating range.
- Minimize obstructions between the device and receiver, such as large metal objects.

- Avoid placing the receiver near other sources of wireless interference (e.g., Wi-Fi routers, cordless phones).
- Update your computer's operating system and Logi Options+ software to the latest versions.

3. Receiver Not Recognized by Computer:

- Restart your computer.
- Try plugging the receiver into a different USB-C port.
- Check your computer's Device Manager (Windows) or System Information (macOS) to see if the USB device is listed.

SPECIFICATIONS

| | |
|---------------------------|--|
| Product Dimensions | 1.08 x 0.65 x 0.36 inches |
| Item Weight | 0.352 ounces |
| Item Model Number | 956-000156 |
| Manufacturer | Logitech |
| Compatible Devices | Desktop, Headphone, Keyboard, Laptop, Mouse (Logi Bolt compatible devices) |
| Connector Type | USB Type C |
| Color | Graphite |
| First Available | June 4, 2025 |



Image: Front view of the compact Logitech Bolt USB-C Receiver, highlighting its design.




Image: Side view of the Logitech Bolt USB-C Receiver, showing its profile.

WARRANTY AND SUPPORT

This Logitech product is covered by a limited hardware warranty. For detailed warranty information, technical support, and customer service, please visit the official Logitech support website. You can find resources, FAQs, and contact options to assist with any product-related inquiries.