Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RUSTOWN PDPX8074BK

RUSTOWN Farmhouse Bathroom Wall Cabinet (Model PDPX8074BK) Instruction Manual

Model: PDPX8074BK

1. Introduction

This manual provides comprehensive instructions for the assembly, installation, operation, and maintenance of your RUSTOWN Farmhouse Bathroom Wall Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. Safety Information

- **Warning:** Safety warnings related to installation are provided with the product. Always follow these warnings to prevent injury or damage.
- Ensure all hardware is securely fastened before use.
- Do not overload the cabinet shelves. Refer to specifications for weight limits.
- For wall mounting, ensure the cabinet is secured to appropriate wall studs or use suitable drywall anchors for stability.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Cabinet Panels (top, bottom, sides, back, shelves)
- Sliding Barn Doors
- Sliding Door Hardware (track, rollers, handles)
- Adjustable Shelf Pins
- Towel Bar
- S-shaped Hooks (5 pieces)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Wall Mounting Hardware (mounting panel, screws, anchors)
- Instruction Manual

4. Assembly and Installation

Assembly is required for this product. Follow the detailed step-by-step instructions provided in the included assembly guide. Pay close attention to panel orientation, as some panels have specific front and back sides.

4.1. Assembly Steps

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the diagrams in the assembly guide.
3. Assemble the main cabinet frame according to the instructions, ensuring all connections are secure.
4. Install the sliding door track and attach the barn doors.
5. Insert adjustable shelf pins and place shelves as desired.
6. Attach the bottom towel bar and S-shaped hooks.

4.2. Wall Mounting Instructions

The cabinet features a 3-step quick mount system for secure installation.



Image: Three-step quick mount installation guide.

1. **Step 1: Secure Mounting Panel.** Level and fix the provided mounting panel to your wall using appropriate screws and anchors. It is recommended to secure into wall studs where possible for maximum stability.
2. **Step 2: Align & Engage.** Lift the assembled cabinet and carefully align its rear grooves with the secured mounting panel. Gently slot the cabinet into place.
3. **Step 3: Hang & Lock.** Once engaged, ensure the cabinet is securely seated and locked onto the mounting panel. Verify stability before placing items inside.

For visual guidance on product features and installation, please refer to the official product video:

[redacted]

Video: Official product video demonstrating the features and functionality of the RUSTOWN Farmhouse Bathroom Wall Cabinet.

5. Operation

5.1. Sliding Barn Doors

The cabinet features two sliding barn doors that move along a top track. Gently slide the doors left or right using the handcrafted metal handles to access or conceal the storage compartments. The doors are designed to slide smoothly within the bottom grooves to protect the frame.



Image: Sliding barn door mechanism and handle.

5.2. Adjustable Shelves

The cabinet includes adjustable shelves on both sides, allowing for customized storage configurations. To adjust a shelf, remove any items, lift the shelf, reposition the shelf pins to the desired height, and then place the shelf back onto the pins. Ensure all four pins are securely in place before loading the shelf.



Image: Key features including adjustable height divider.

5.3. Towel Bar and Hooks

The bottom of the cabinet features a towel bar and five removable S-shaped hooks. These can be used for hanging towels, washcloths, or other small items.

6. Maintenance

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Sliding Mechanism:** Keep the sliding door tracks clean and free of debris to ensure smooth operation.

7. Troubleshooting

- **Doors not sliding smoothly:** Check the top track and bottom grooves for any obstructions or debris. Ensure the doors are

properly seated on the rollers and within the bottom grooves.

- **Doors not staying on track:** Verify that the top track is securely installed and level. Ensure the rollers are correctly attached to the doors and are not damaged.
- **Cabinet feels unstable after mounting:** Recheck all wall mounting hardware. Ensure the mounting panel is securely fastened to wall studs or appropriate heavy-duty drywall anchors are used. Confirm the cabinet is fully engaged and locked onto the mounting panel.
- **Missing parts or damaged components:** Refer to the package contents list. If any items are missing or damaged upon arrival, contact RUSTOWN customer service for assistance.

8. Specifications

Attribute	Detail
Brand	RUSTOWN
Model Number	PDPX8074BK
Color	Black
Material	Engineered Wood
Product Dimensions (D x W x H)	7.9" x 31.5" x 30.7" (20cm x 80cm x 78cm)
Item Weight	15.4 Kilograms
Mounting Type	Wall Mount
Number of Doors	2 (Sliding Barn Doors)
Number of Shelves	8 (including fixed and adjustable sections)
Additional Features	Adjustable Shelves, Towel Bar, 5 S-shaped Hooks
Assembly Required	Yes



Image: Detailed product dimensions.

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact RUSTOWN customer service directly. Contact details can typically be found on the manufacturer's website or through your point of purchase.

© 2026 RUSTOWN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9DXX5NB

More documents and user manuals: **https://manuals.plus/**