

[Manuals.plus](#) /

› [HP](#) /

› HP 15.6-inch Touchscreen Laptop (Model: HP 15.6 Touch laptop) User Manual

HP HP 15.6 Touch laptop

HP 15.6-inch Touchscreen Laptop User Manual

Model: HP 15.6 Touch laptop

INTRODUCTION

This manual provides comprehensive instructions for the HP 15.6-inch Touchscreen Laptop. It covers initial setup, basic operation, maintenance guidelines, and troubleshooting tips to ensure optimal performance and user experience. Please read this manual thoroughly before using your device.

WHAT'S IN THE BOX


Carefully unpack your HP laptop and verify that all items are present. The package should contain the following:

- HP 15.6 Touchscreen Laptop
- Mouse
- External DVD Drive
- Windows 11 Pro & Microsoft Office Lifetime License (pre-installed)



HP 15.6" Laptop

Best for entertainment
and personal use



Intel® Core™ i3-1315U
processor



Intel® UHD
Graphics



2 TB SSD



64 GB RAM

Image: The HP 15.6-inch Touchscreen Laptop shown with its included mouse and external DVD drive.

SETUP

1. Initial Power On

1. Connect the power adapter to the laptop's AC Smart pin port and then to a power outlet.
2. Open the laptop lid and press the power button, typically located on the keyboard deck.
3. Follow the on-screen prompts to complete the initial Windows 11 Pro setup, including language, region, network connection, and user account creation.

2. Connecting Peripherals

- **Mouse:** Connect the included mouse to any available USB Type-A port.
- **External DVD Drive:** Connect the external DVD drive to an available USB Type-A port for use.

3. Microsoft Office Activation

Your laptop comes with a pre-installed Microsoft Office Lifetime license. **Important:** Do not install Office 365, as this may

deactivate the included lifetime license. The Office suite is pre-activated and ready for use.

OPERATING YOUR LAPTOP

Display and Touchscreen

The laptop features a 15.6-inch HD touchscreen display (1366 x 768 resolution) with 250 nits brightness. This allows for intuitive navigation using touch gestures such as pinch, zoom, swipe, and tap, in addition to traditional mouse and keyboard input.

Built for the speed of life



Get lost in your flow with a flicker-free Full HD display and plenty of ports for connecting devices.



Image: The HP laptop display showcasing its ability to handle multiple applications simultaneously.

Keyboard and Touchpad

The full-size keyboard includes a numeric keypad for efficient data entry. The integrated touchpad supports multi-touch gestures for precise control and navigation.

Ports and Connectivity

The laptop offers various ports for connecting external devices and accessories:

- 1 x USB Type-C 3.0 (5Gbps signaling rate)
- 2 x USB Type-A 3.0 (5Gbps signaling rate)
- 1 x HDMI 1.4b (for external display connection)
- 1 x AC Smart pin (for power adapter)
- 1 x Headphone/Microphone Combo jack

Wireless connectivity includes Wi-Fi 5 (802.11ac) and Bluetooth 4.2 for connecting to networks and wireless peripherals.

Designed to reduce environmental impact



Designed using ocean-bound plastic¹ and post-consumer recycled plastics²



EPEAT® Gold³



ENERGY STAR® Certified

¹Percentage of ocean-bound plastic contained in each component varies by product.

²Keyboard components contain post-consumer recycled plastic. Percentage of post consumer recycled contained in each component varies by product.

³Based on U.S. EPEAT® registration according to IEEE 16801-2018 EPEAT®. EPEAT® status varies by country. Visit www.epeat.net for more information.




Image: A detailed view of the laptop's side ports, including USB Type-A, HDMI, USB Type-C, AC smart pin, and headphone/microphone combo jack.

Webcam and Audio

The integrated HP True Vision 720p HD Camera and digital microphone facilitate clear video calls and online meetings. Dual speakers with HP Audio Boost provide enhanced sound quality for multimedia and communication.

Be seen. Be heard. On your terms.



Get the point across with advanced noise reduction software and a high quality camera you can close when not in use.



Image: The HP laptop screen showing a video conference in progress, highlighting the webcam functionality.

Microsoft Copilot

The laptop includes Microsoft Copilot, an AI-powered assistant designed to enhance productivity and creativity by providing intelligent answers and assistance.

Microsoft Copilot



Copilot kickstarts your creative and productive capabilities with intelligent answers.*



* Requires Windows 11. Some features require an NPU. Timing of feature delivery and availability varies by market and device. Requires Microsoft account to log in. Where Copilot is not available, the Copilot key will lead to the Bing search engine. See <http://aka.ms/WindowsAIFeatures>.

Image: The HP laptop screen showing the Microsoft Copilot interface, ready to assist with tasks.

Product Overview Video

Your browser does not support the video tag.

Video: A brief overview of the HP 15.6-inch Touchscreen Laptop, demonstrating its design and key features.

MAINTENANCE

Cleaning Your Laptop

- Use a soft, lint-free cloth slightly dampened with water or a screen cleaner to clean the display.
- For the keyboard and chassis, use a soft, dry cloth. Avoid harsh chemicals or abrasive materials.

Software Updates

Regularly check for and install operating system updates (Windows Update) and driver updates (HP Support Assistant) to ensure system stability, security, and optimal performance.

Battery Care

To prolong battery life, avoid extreme temperatures and fully discharging the battery frequently. For long-term storage, charge the battery to about 50% and store the laptop in a cool, dry place.

TROUBLESHOOTING

General Troubleshooting Steps

- **Restart:** A simple restart can resolve many minor software glitches.
- **Check Connections:** Ensure all cables (power, peripherals) are securely connected.
- **Software Conflicts:** If an issue arises after installing new software, try uninstalling it or performing a system restore.

Fan Operation

The laptop's internal fan is designed to regulate temperature. If you notice unusual fan noise or the laptop overheating, ensure that the vents are not obstructed. If the issue persists, contact HP Support.

SPECIFICATIONS

Feature	Specification
Brand	HP
Model Name	HP 15.6 Touch laptop
Screen Size	15.6 Inches
Display Resolution	1366x768 Pixels (HD Touchscreen)
Processor	Intel 13th Gen Core i3-1315U (6 Cores, up to 4.5 GHz)
RAM Memory	32 GB DDR4 (3200 MHz)
Storage	1 TB SSD
Graphics	Intel UHD Graphics (Integrated)
Operating System	Windows 11 Pro
Wireless Connectivity	Wi-Fi 5 (802.11ac), Bluetooth 4.2
Ports	1x USB Type-C 3.0, 2x USB Type-A 3.0, 1x HDMI 1.4b, 1x AC Smart pin, 1x Headphone/Microphone Combo
Webcam	HP True Vision 720p HD Camera
Audio	Dual speakers with HP Audio Boost
Weight	3.52 Pounds (approx. 1.6 kg)
Dimensions (L x W x Thickness)	14.17" x 9.29" x 0.73" (358.5mm x 242mm x 18mm)

WARRANTY AND SUPPORT

Warranty Information

This HP laptop is covered by a **1 Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty documentation included with your product or visit the official HP support website.

Contacting Support

If you encounter issues that cannot be resolved using the troubleshooting steps in this manual, or for further assistance, please contact HP Customer Support. You can find contact information and online resources on the official HP website:

- **HP Support Website:** support.hp.com
- Refer to your product's serial number and model for faster service.

© 2025 HP Inc. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question