**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**IRONCK FG-DH-03**

# IRONCK Farmhouse Shoe Storage Cabinet (Model FG-DH-03) Instruction Manual

Your guide to assembly, operation, and care.

## 1. Introduction

Thank you for choosing the IRONCK Farmhouse Shoe Storage Cabinet, Model FG-DH-03. This manual provides detailed instructions for the safe assembly, proper operation, and effective maintenance of your new shoe cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.




*Figure 1.1: Assembled IRONCK Farmhouse Shoe Storage Cabinet.*

## 2. Product Features

- **Large Capacity Storage:** Features four flip-down drawers, each with two levels of storage space.
- **Adjustable Internal Dividers:** Internal dividers are adjustable and removable to accommodate various shoe types, including canvas shoes, slippers, and sandals. Dividers can be removed for high-top shoes.
- **Space-Saving Design:** Flip-up drawer mechanism is practical for small spaces, keeping shoes organized and protected from dust.
- **Durable Construction:** Made from high-quality MDF for excellent durability and load-bearing capacity.
- **Safety Features:** Equipped with an anti-tipping device for enhanced stability and safety.
- **Ventilation:** Two ventilation holes on the back promote air circulation to keep shoes dry and clean.
- **Farmhouse Aesthetic:** Diagonal design elements contribute to a clean, sophisticated, and rustic appearance.




*Figure 2.1: Space-saving design and shoe compatibility.*

## 3. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Top, Bottom, Sides, Back, Dividers)
- Flip-Down Drawer Mechanisms
- Metal Handles
- Legs/Base Supports
- Anti-Tipping Device
- Assembly Hardware (Screws, dowels, cam locks, etc.)
- Assembly Tool (Hex key, if required)
- Instruction Manual

## 4. Safety Information

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload the cabinet. Refer to specifications for weight limits.
- Install the anti-tipping device as instructed to prevent accidental tipping, especially in households with children or pets.
- Keep small parts and hardware away from children to avoid choking hazards.
- Do not stand or climb on the cabinet.



*Figure 4.1: Anti-tipping device installation.*

## 5. Setup and Assembly Instructions

Assembly typically requires two adults. Follow the numbered steps provided in the included assembly guide. Ensure you have a Phillips head screwdriver and the provided hex key.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a protected surface. Refer to the parts list in your assembly guide to identify each piece.
2. **Assemble the Main Frame:** Attach the side panels to the bottom panel using the designated hardware. Ensure proper alignment.
3. **Install Back Panel:** Secure the back panel to the main frame. Note the ventilation holes.
4. **Attach Legs/Base:** Fasten the metal legs or base supports to the bottom of the cabinet.
5. **Assemble Flip Drawers:** Construct each of the four flip drawers. This involves attaching the front panel, side panels, and the internal divider mechanism.
6. **Insert Drawers:** Carefully insert the assembled flip drawers into the cabinet frame. Ensure they operate smoothly.
7. **Attach Handles:** Secure the metal handles to the front of each flip drawer.
8. **Install Anti-Tipping Device:** Position the cabinet in its desired location. Attach the anti-tipping strap or bracket to the back of the cabinet and then securely fasten it to a wall stud using appropriate hardware.

**Note:**

**The divider must be removed to accommodate high-top shoes, high heels, boots, or other tall footwear.**





*Figure 5.1: Product dimensions for planning placement.*



*Figure 5.2: Cabinet with drawers open, illustrating storage capacity.*

## 6. Operating Instructions

### 6.1 Using the Flip Drawers

To access your shoes, gently pull the handle on the desired drawer. The drawer will flip down, revealing the two storage levels. To close, push the drawer upwards until it clicks securely into place.

### 6.2 Adjusting or Removing Shelves

Each flip drawer contains an internal divider. This divider can be adjusted to three different positions or completely removed to accommodate various shoe heights.

- **To Adjust:** Locate the adjustment points on the side of the drawer mechanism. Carefully lift and reposition the divider to the desired height.

- **To Remove:** For high-top shoes, boots, or taller footwear, the divider can be fully removed. Gently unclip or slide out the divider from its supports.




*Figure 6.1: Adjustable shelf mechanism.*

## 7. Maintenance

### 7.1 Cleaning

Wipe the cabinet surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. Dry immediately with a clean cloth.

### 7.2 General Care

- Periodically check all screws and fasteners to ensure they remain tight.
- Keep the cabinet away from direct sunlight and excessive moisture to prevent warping or discoloration.

- Ensure the ventilation holes on the back are not obstructed to maintain air circulation.

## 8. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Drawers do not close smoothly. | Misalignment during assembly; obstruction. | Check drawer mechanism for proper installation. Ensure no items are blocking the drawer's path. |
| Cabinet feels unstable. | Loose fasteners; anti-tipping device not installed. | Tighten all assembly screws. Ensure the anti-tipping device is securely anchored to the wall. |
| Shoes do not fit in drawers. | Internal divider is in place for tall shoes. | Adjust or remove the internal divider to accommodate larger footwear. |

## 9. Specifications

| Feature | Detail |
|---|---|
| Brand | IRONCK |
| Model Name | Shoe Cabinet |
| Model Number | FG-DH-03 |
| Color | Grey |
| Product Dimensions (D x W x H) | 9.4"D x 40.1"W x 36.4"H |
| Item Weight | 53 Pounds |
| Special Features | Adjustable Shelf, Anti-Tipping |
| Mounting Type | Floor Mount |
| Room Type | Entryway, Hallway, Living Room |
| Assembly Required | Yes |
| UPC | 791137308854 |

## 10. Warranty and Support

IRONCK products are designed for quality and durability. For any questions regarding assembly, missing parts, or product issues, please contact IRONCK customer support. Refer to your purchase documentation for specific warranty details and contact information.
Customer support inquiries are typically answered within 24 hours.

© 2025 IRONCK. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0F9F67HZD**

More documents and user manuals: **https://manuals.plus/**