



[Manuals.plus](#) /

> [RUSTOWN](#) /

> RUSTOWN Farmhouse Bathroom Wall Cabinet (Model PDPX8074GY) Instruction Manual

RUSTOWN PDPX8074GY

RUSTOWN Farmhouse Bathroom Wall Cabinet Instruction Manual

Model: PDPX8074GY

1. INTRODUCTION

This manual provides detailed instructions for the assembly, installation, and proper use of your RUSTOWN Farmhouse Bathroom Wall Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This wall-mounted cabinet is designed to offer versatile storage solutions in various home environments, featuring a rustic design with sliding barn doors and adjustable shelving.



Image 1.1: The RUSTOWN Farmhouse Bathroom Wall Cabinet, showcasing its rustic design and storage capabilities.

2. PRODUCT FEATURES

- **Farmhouse Rustic Design:** Features a vintage barn door style, enhancing aesthetic appeal.
- **Space-Saving Wall Mount:** Designed to utilize narrow wall spaces effectively.
- **Sliding Barn Doors:** Two smooth-gliding doors allow for flexible open or concealed storage.
- **Adjustable Shelves:** Interior shelves can be adjusted to three different positions to accommodate various item heights.
- **Integrated Towel Bar & Hooks:** A bottom towel bar and five S-shaped hooks provide additional organization for towels and other items.
- **Durable Construction:** Made from engineered wood with a washed oak finish.

Improved Way Of Mounting More Convenient To Mount

3-Step Quick Mount, Effortless Setup

Step 1

**Secure Mounting Panel:
Level & fix to wall**



Step 2

**Align & Engage:
Lift cabinet, slot into place**



Step 3

**Hang & Lock:
Securely mounted, done**



Image 2.1: Visual representation of key features including the simple top plate, handmade black metal accessories, adjustable height divider, and practical towel bar with removable hooks.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Cabinet Panels (top, bottom, sides, back, shelves)
- Sliding Barn Doors
- Sliding Door Hardware (track, rollers, handles)
- Towel Bar and S-shaped Hooks
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Wall Mounting Hardware (mounting panel, screws, drywall anchors)
- Instruction Manual

4. SETUP AND INSTALLATION

Assembly and installation require careful attention to detail. Follow the provided step-by-step instructions

included with your product. Some panels may have specific front and back sides; ensure correct orientation as indicated in the manual.

4.1 Assembly Steps

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the provided diagrams in the product's assembly guide.
3. Assemble the main cabinet frame according to the instructions, ensuring all connections are secure.
4. Install the adjustable shelves into your desired positions.
5. Attach the sliding barn door hardware and doors.
6. Secure the bottom towel bar and attach the S-shaped hooks.

4.2 Wall Mounting Instructions

The cabinet features an improved mounting system for easier installation. It is crucial to secure the cabinet to wall studs where possible for maximum stability. If studs are not available for all mounting points, use appropriate drywall anchors.



Image 4.1: Visual guide for the 3-step quick mount installation process.

1. **Secure Mounting Panel:** Level and fix the mounting panel to the wall. Use a stud finder to locate wall

studs. Mark the positions for drilling.

2. **Drilling and Anchoring:** For stud locations, pre-drill pilot holes. For non-stud locations, use appropriate drywall anchors. Ensure the screws used with drywall anchors are long enough to engage the anchor but not so long as to puncture through the back of the anchor or into hidden pipes/wires.
3. **Align and Engage:** Lift the assembled cabinet and align it with the secured mounting panel.
4. **Hang and Lock:** Slot the cabinet securely into place on the mounting panel. Verify that the cabinet is stable and level.

Important Note on Drywall Anchors: If using drywall anchors, pre-drill the hole to the recommended size for the anchor. Insert the anchor until it is flush with the wall. Ensure at least two screws are secured into wall studs for optimal support.

5. OPERATING INSTRUCTIONS

Once installed, your RUSTOWN wall cabinet is ready for use.

- **Sliding Doors:** Gently slide the barn doors along the top track to access or conceal the cabinet compartments. The doors are designed for smooth operation.
- **Adjustable Shelves:** To adjust shelf height, remove the shelf, reposition the shelf pins to the desired slots, and reinsert the shelf.
- **Towel Bar and Hooks:** Use the bottom bar for hanging towels and the S-shaped hooks for smaller items like brushes, loofahs, or keys.



Image 5.1: The cabinet providing storage over a toilet, demonstrating practical placement.

6. MAINTENANCE

To ensure the longevity and appearance of your cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.
- **Sliding Mechanism:** Keep the sliding door tracks clean and free of debris to ensure smooth operation.

7. TROUBLESHOOTING

- **Difficulty Sliding Doors:** Check the track for any obstructions or debris. Ensure the rollers are properly seated in the track. If the track is dirty, clean it with a soft cloth.
- **Cabinet Feels Unstable:** Re-check all wall mounting points. Ensure screws are fully tightened and, if using drywall anchors, that they are correctly installed and supporting the weight. Verify that at least two mounting points are secured into wall studs.

- **Loose Parts:** If any parts feel loose after assembly, refer to the assembly instructions and tighten all fasteners. Avoid over-tightening, which can strip screws or damage the wood.

8. SPECIFICATIONS

Brand	RUSTOWN
Model Name	PDPX8074
Color	Washed Oak
Product Dimensions (D x W x H)	7.9"D x 31.5"W x 30.7"H (20cm D x 80cm W x 78cm H)
Item Weight	33.9 pounds (15.4 Kilograms)
Material	Engineered Wood
Mounting Type	Wall Mount
Number of Shelves	3 (adjustable)
Number of Compartments	8
Assembly Required	Yes




Image 8.1: Dimensional drawing of the cabinet, showing width, height, and depth measurements.

9. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product functionality, please contact RUSTOWN customer service. While specific warranty details are not provided in this manual, RUSTOWN is committed to customer satisfaction. Please refer to your purchase documentation or the RUSTOWN official website for the most current warranty information.

You can visit the RUSTOWN store for more information: [RUSTOWN Store on Amazon](#)