

[Manuals.plus](#) /

> [Mia&Coco](#) /

> Mia&Coco Electric Blanket Twin (Model OB27-001) - User Manual

Mia&Coco OB27-001

Mia&Coco Electric Blanket Twin (Model OB27-001) - User Manual

Model: OB27-001 | Brand: Mia&Coco

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Mia&Coco Electric Blanket Twin. Please read this manual thoroughly before first use and retain it for future reference. This electric blanket features 10 heat levels, a 10-hour auto-off timer, fast heating, and overheat protection, designed for comfort and safety.

Soft, Skin-Friendly Flannel Material



Non-Pilling



Soft



Durable



Clean edges




Image: A woman enjoying the soft, skin-friendly flannel material of the Mia&Coco electric blanket, emphasizing its comfort and luxurious feel.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this electric blanket.
- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use if wet.
- Do not use with a damaged cord or plug. If the cord or plug is damaged, contact customer support.
- Do not use with pointed objects.
- Do not use if folded, bunched, or creased.
- Always disconnect the blanket from the power outlet when not in use or before cleaning.
- Ensure the controller is not covered or placed under the blanket during operation to prevent overheating.


- This blanket is equipped with an overheat protection system for your safety.
- Do not dry clean this product. Dry cleaning solvents may damage the insulation of the heating element.




Temperature-Sensitive Heating Wire

SAFE AND DURABLE


Self-recovery of wire overheating damage




Overheat Protection




Real-time temperature Monitoring



Fast Heating



Abrasion-resistant PVC Protective Layer








Image: Internal structure of the NTC temperature-sensitive heating wire, highlighting safety features like safety wire, main wire, safety coating layer, and PVC insulation layer. This design ensures safe and durable operation with overheat protection and real-time temperature monitoring.

3. PACKAGE CONTENTS

Please check the package contents upon receipt. If any items are missing or damaged, contact customer support.

- Mia&Coco Electric Blanket Twin (62"x84")
- Detachable Controller with Power Cord
- User Manual

4. SETUP INSTRUCTIONS

Follow these steps to set up your electric blanket:

1. Unroll the electric blanket and spread it flat on your bed or desired surface. Ensure there are no folds or creases.
2. Locate the connector on the blanket.
3. Connect the controller cable securely to the blanket's connector. Ensure it clicks into place.
4. Plug the power cord from the controller into a standard 120V AC electrical outlet.



Image: A diagram showing the internal heating element layout of the Mia&Coco electric blanket, demonstrating how it heats up quickly and evenly across the surface, retaining heat effectively.

5. OPERATING INSTRUCTIONS

Your Mia&Coco Electric Blanket is controlled by an intuitive, ergonomic controller. Familiarize yourself with its functions:

INTUITIVE AND USER-FRIENDLY CONTROLLER



1 Digital display
Heating level
and timing indication



3 Pre-Heat
Highest heating level, returns to the
original setting level after 1 hour



2 Power switch
After powering on, the
heating level and timer
default to the settings
you last used.



4 Heating/Timing
1, 2 to 10 hour auto-off timer



5 Decrease/Increase
10 heat settings/10-Hour auto off

Image: A detailed view of the Mia&Coco electric blanket controller, showing the digital LED display, power switch, pre-heat button, heating/timing button, and increase/decrease buttons. The display shows heating level in red and timer in green.

Controller Functions:

- **Digital Display:** Shows the current heating level (red digits) and timer setting (green digits).
- **Power Switch:** Press to turn the blanket on or off. Upon powering on, the blanket defaults to the last used settings.
- **Pre-Heat:** Activates the highest heating level for 1 hour, then automatically returns to the original setting.
- **Heating/Timing:** Press to cycle through temperature levels (1-9, H) or timer settings (1, 2, 9, 10 hours).
- **Decrease/Increase Buttons:** Use these buttons to adjust the heat level or timer duration.

Temperature Settings:

The blanket offers 10 adjustable temperature levels, ranging from 77°F to 127°F. Levels are indicated as 1, 2, ..., 9, and H (highest).

Auto-Off Timer:

The blanket features a programmable timer from 1 to 10 hours. A 3-hour default auto-off feature is also present for dual

automatic protection. Once the set timer is reached, the blanket will automatically shut off.



Image: A couple comfortably using the Mia&Coco electric blanket. The image highlights the controller with its digital display and the blanket's 1-10 hour auto-off timer feature.

6. MAINTENANCE AND CLEANING

Proper care ensures the longevity and performance of your electric blanket.

Before Cleaning:

- Always unplug the blanket from the wall outlet.
- Detach the controller cable from the blanket by gently squeezing the sides of the connector and pulling apart.

Machine Washing:

- Machine wash on a gentle cycle with cold water (below 86°F / 30°C).
- Use a mild detergent.

- Do not bleach.
- Do not iron.
- Do not dry clean.

Drying:

- Tumble dry on low heat or line dry.
- Ensure the blanket is completely dry before reconnecting the controller and using it.

EASY TO CLEAN AND MAINTAIN

The wiring structure is durable enough that the electric blanket remains soft and warm even after multiple washings

MACHINE WASHABLE

NOTE: PLEASE DETACH THE CORD BEFORE WASHING

Image: Instructions for cleaning the electric blanket, showing it being placed into a washing machine. An important note emphasizes detaching the cord before washing to maintain the blanket's softness and durability after multiple washes.

7. TROUBLESHOOTING

If your electric blanket is not functioning as expected, please refer to the following common issues and solutions:

- **Blanket not heating:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Verify the controller cable is firmly connected to the blanket.
- Check if the power switch on the controller is turned on.
- If the blanket has been folded or bunched, spread it flat and wait a few minutes. The overheat protection might have activated.

- **Controller display not working:**

- Ensure the blanket is plugged in and powered on.
- Try plugging the blanket into a different outlet.

- **Uneven heating:**

- Ensure the blanket is spread flat and not bunched up.
- Allow sufficient time for the blanket to heat evenly across the entire surface.

If the issue persists after following these steps, please contact Mia&Coco customer support for further assistance.

8. SPECIFICATIONS

Brand	Mia&Coco
Model Name	OB27-001
Size	Twin (62"x84")
Material	Flannel, Fleece
Color	Grey
Heat Levels	10 (77-127°F)
Auto-Off Timer	1-10 Hours (3-hour default)
Special Features	Overheat Protection, Machine Washable, Skin Friendly
Product Dimensions	84"L x 62"W
Item Weight	4.95 pounds (2.25 Kilograms)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Mia&Coco customer service. Refer to the product packaging or the official Mia&Coco website for contact details.

Website: [Mia&Coco Official Store on Amazon](#)