

YenLove MJ-01

YenLove Cordless Electric Nail File and UV Lamp Kit (Model MJ-01) Instruction Manual

Brand: YenLove | **Model:** MJ-01

1. INTRODUCTION

This manual provides essential information for the safe and effective operation and maintenance of your YenLove Cordless Electric Nail File and UV Lamp Kit, Model MJ-01. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INFORMATION

WARNING:

- This device is intended solely for nail drilling and nail curing purposes.
- Keep out of reach of children.
- Do not use if the device or charging cable is damaged.
- Avoid contact with water.
- Do not disassemble or attempt to repair the device yourself.
- Always unplug the device before cleaning.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Cordless Electric Nail File
- 1 x Charging Base with Integrated UV Nail Lamp
- 1 x USB Type-C Charging Cable
- 6 x Professional Nail Drill Bits (various types)
- Sanding Bands (multiple pieces)
- 1 x Cleaning Brush

UV Mini Nail Lamp Quick drying and portable One button with two modes

Short press the nail enhancement light switch, Press once to activate the 30 second mode Both indicator lights come on simultaneously Press twice in a row Activate 90 second mode

● 30S
● 60S
● 90S



Image: All components included in the YenLove Cordless Electric Nail File and UV Lamp Kit, including the nail drill, charging base with UV lamp, USB cable, various drill bits, sanding bands, and cleaning brush.

4. PRODUCT FEATURES

- **Professional Nail Care:** Suitable for filing, shaping, buffing, and polishing natural, acrylic, gel, and dip powder nails.
- **Integrated UV Nail Lamp:** Combines nail polishing and curing functions. Quickly cures gel polish in 30-90 seconds.
- **Two-Way Charging:** Supports charging via the base or directly via the in-line Type-C port. Can be used while charging.
- **Cordless Charging Base:** Features 8 integrated jacks with a dust cover for convenient storage of frequently used drill bits.
- **Adjustable Speeds:** 5 speed modes for precise control, from delicate areas to tough calluses.
- **Dual Rotation:** Clockwise and counter-clockwise rotation for versatile use.
- **Portable Design:** Compact and lightweight, ideal for home use, salon use, or travel.
- **Automatic Pause:** Device automatically pauses after 10 minutes of inactivity to conserve battery. Restart to resume use.

Image: An exploded view of the YenLove Cordless Nail Drill highlighting its internal motor, rechargeable battery, UV light, charging base, and dual charging modes.

5. SETUP

5.1 Charging the Device

Before first use, fully charge the nail drill. The device supports two charging methods:

1. **Via Charging Base:** Place the nail drill into the charging base. Connect the USB Type-C cable to the base and a suitable power adapter (not included). The indicator lights on the base will show charging status.
2. **Direct Type-C Charging:** Connect the USB Type-C cable directly to the charging port on the nail drill and a suitable power adapter.

The nail drill can be used while charging.



Image: Close-up of the nail drill showing the Type-C charging port, emphasizing its portability and direct charging capability.




Image: Depicts the two charging modes: placing the drill in the base for charging and using the integrated UV lamp, and direct Type-C charging.

5.2 Inserting/Changing Drill Bits

1. Ensure the device is turned off.
2. Gently pull out the current drill bit from the tip of the device.

3. Insert the desired new drill bit firmly into the opening until it clicks into place.
4. The charging base also provides storage for up to 8 drill bits.

Multifunctional Nail Drill Kit

Suitable for different nails,
Optional replacement

- Suitable for different fingernails
Can be easily replaced



Image: Illustrates the various types of drill bits included in the kit, such as Conical Bit, Needle Bit, Large Barrel, Safety Bit, Small Barrel, and Mandrel + Sanding Band, along with their specific uses.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off and Speed Adjustment

1. Press and hold the power button to turn the device on or off.
2. Once on, short press the speed adjustment button to cycle through 5 speed modes. The current speed level will be displayed on the screen.

6.2 Adjusting Rotation Direction

Press the rotation direction button to switch between clockwise and counter-clockwise rotation, allowing for comfortable use with either hand.

Adjustable Direction & Speed

5 speed adjustment
Adjustable forward turn

- **Adjustable clockwise/counterclockwise, strong/weak, Manicure more at will**




Image: Shows the nail drill with controls for adjusting speed (1-5) and rotation direction (clockwise/counter-clockwise).

6.3 Using the UV Nail Lamp

The charging base features an integrated UV nail lamp for curing gel polish:

1. Place the nail drill into the charging base.
2. Short press the nail enhancement light switch on the base once to activate the 30-second curing mode. Both indicator lights will illuminate.
3. Press the switch twice in a row to activate the 90-second curing mode.
4. Place your finger under the UV light to cure your gel polish.

Professional Manicure & Pedicure Kit

Enjoy a salon manicure at home




Image: Demonstrates the UV nail lamp function on the charging base, showing a finger placed under the light for curing gel polish.

7. MAINTENANCE

- **Cleaning:** After each use, turn off the device and remove the drill bit. Use the provided cleaning brush to remove any dust or debris from the drill bit and the device's tip. Wipe the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the nail drill and its accessories in a cool, dry place, away from direct sunlight and moisture. Use the charging base to store drill bits securely.

8. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. If charging via the base, check the cable connection.
- **Drill bit not rotating:** Verify that the drill bit is correctly inserted and secured. Check the speed setting.
- **UV lamp not working:** Ensure the device is properly connected to power via the charging base and the light switch is pressed correctly for the desired curing time.
- **Automatic pause:** The device will pause after 10 minutes of inactivity. Simply restart the device to continue use.

9. SPECIFICATIONS

Feature	Detail
Model Name	MJ-01
Brand	YenLove
Power Source	Battery Powered (1 Lithium Ion battery included)
Voltage	5 Volts (DC)
Material	Plastic
Package Dimensions	6.61 x 3.58 x 2.32 inches
Item Weight	8.47 ounces

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official YenLove website. Keep your purchase receipt as proof of purchase.

11. PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video demonstrating the features and use of the YenLove Electric Nail Drill. This video provides a visual guide to the product's functionality and benefits.